# Speed Tx

# Low Power Wireless Data Link

FCC ID: SPEEDTx433L1

# User Manual

Miltel Communications Ltd.

June 1998

# **Table of Contents**

Chapte	er 1 Introduction	3
1.1	Purpose and Use	3
1.2	System General Description	3
Chapte	er 2 Theory of Operation	4
2.1	General Description	4
2.2	Block Diagram Description	6
2.2.1	General	6
2.2.1	Digital Section	7
2.2.3	RF Section	8
Chapte	er 3 Technical Characteristics	9
3.1	Technical Specification	9
3.1.1	Electrical	9
3.1.2	Physical	9
3.2	Label Contents	10
Chapte	er 4 Installation Instructions	11
4.1	General	11
4.2	Installation	11

# Chapter 1

# Introduction

### 1.1 Purpose and Use

The *Speed Tx* (FCC ID: SPEEDTx433L1) is a low-power data link transmitter that is used for data acquisition in Miltel's water consumption readings collection system. This device is installed on-site by a professional field technician, thus it includes technical terms. The equipment is not to be installed by a non-professional individual. The information in this manual is provided only as instructions for installation and does not entitle user to make any modifications or adjustments.

## 1.2 System General Description

The *Speed Tx* system is a computerized fully automatic radio device. It requires no human intervention after initial installation. The system enables remote, continuous and accurate reading of water consumption. The *Speed Tx* transmits the data acquired from water meters to a regional concentrator (directly or via a repeater). The concentrator transfers the data to the central computer for data collection and for further analysis and reporting.

- Note: 1) The system, including transmitters, transceivers and concentrators, is installed and maintained only by qualified professional technicians.
  - 2) The device is not adjustable by user and is supplied by manufacturer ready for installation witout provisions for adjustment.

## **Chapter 2**

# **Theory of Operation**

#### 2.1 General Description

The  $Speed\ Tx$  is the first link in the water readings collection system. It is an independent unit that does not require an external power source, wiring, or the preparation of an infrastructure.

The *unit* is installed in proximity to the water meter/s and is connected to several adjacent meters.

Figure 2-1 (see next page) shows a typical installation of a *Speed Tx* unit, connected to several meters (of various types) at a single location. The unit can be connected to any type of meter which has a pulsed output (a passive magnetic open/short reed relay).

The *Speed Tx* acquires the consumption data from the water meters and stores this data in its memory. The unit includes a miniature low-power RF transmitter which transmits data on a periodic basis to a regional concentrator (directly or through a relay station).




Figure 2-1: Speed Tx Typical Installation

## 2.2 Block Diagram Description

#### 2.2.1 General

Figure 2-2 describes the block diagram of the Speed Tx unit. This device consists of two major sections, all using a common power source:

- Digital section (Micro Controller)
- RF section

A 3.6 volts Lithium battery provides power to all parts of the device. The power supply for the RF section is controlled via the Tx switch (not shown), thus cutting of power to the transmitter unless necessary for actual data transmission (standby mode).




Figure 2-2: Speed Tx Block Diagram

#### 2.2.2 Digital Section

The digital section of the **Speed** Tx performs the following functions:

- Samples reed switches to detect short/open from each meter.
- Accumulates number of pulses for each meter separately
- Stores data (including battery and tamper alarms) and stores information internal memory
- Interfaces the data to the RF section

The digital section is based on a central controller which accepts the following inputs:

- a. Analog inputs (from reed-relay contacts) designated INPUT1 through INPUTn, each indicating the advance of a single water meter. These are the only inputs of the controller which are connected to the external source.
- b. Magnetic switch input is utilized only for test.
- c. The TAMPER SWITCH input is connected to a micro-switch that senses an opening of the unit's box. This enables the *Speed Tx* to generate and transmit an alarm signal in the event of unauthorized opening of the unit casing.
- d. The LOW VOLTAGE input of the controller is connected to battery via a Low Voltage Detector in order to sense and generate a low battery alarm.

Each of the external analog inputs to the controller advances a separate counter in singular steps. The counters in the controller are not pre-settable or resettable to avoid unauthorized tampering (counter matching is thus performed only by the central computer, ensuring excellent data security at the sites).

The controller gathers the data for several hours before initiating a transmission. If any of the counters has advanced by more than a preset value, or any alarm (tamper or low voltage) has been received, the controller generates a single message immediately. Any further message will include alarm information along with counter data, if alarm condition still exists. Note: The duration interval between two transmissions is always greater than 1 Hr.

- a. The messages generated by the controller are 16 bytes each, and are outputed from the digital section to the RF section as serial data (RS-232 standard protocol) via the DATA OUT output of the controller.
- b. The Tx control output of the controller is used for activating the TX switch for the duration of the message, to enable power supply to the RF section thus enabling the transmission of the message (transmit mode).

#### 2.2.3 RF Section

The RF section consists of a phased-locked loop (PLL) and a low-power amplifier connected to an integral antenna.

The PLL reference is driven by a 13.56 MHz. crystal oscillator. This reference is phase-compared by the Phase Detector with the divided output frequency.

The phase detection signal from the detector is filtered by the PLL Loop Filter and then summed with the shaped signal received from the digital section by the Sum Network block. The output of the Sum Network is the control signal that modulates and locks the Voltage Control Oscillator (VCO).

# **Chapter 3**

# **Technical Characteristics**

## 3.1 Technical Specification

#### 3.1.1 Electrical

Max Effective Radiated Power (ERP) 1.4 µW Peak (Complies with FCC 15.231(e))

Output frequency 433.92 MHz

Carrier wave modulation 2 Level FSK

Power supply Lithium battery, 3.6 Volt

Input Channels 1-8 Water Meters

Compatibility Any type of meter which has a reed relay switch

(pulsed output)

Transmission Duration 0.8 Sec. Max.

Duration between 1 Hr. Min.

Transmissions

#### 3.1.2 Physical

Operating temperature  $-10 \div +60^{\circ}\text{C}$ 

Water Resistance Splash resistance (IP-64)

Length 11 cm.

Width 8 cm.

Depth 3 cm.

Weight (excluding clamp) 200 gr.

Weight (including clamp) 500 gr.

Clamp material stainless steel

Clamp screws protected from dismantling

# 3.2 Label Contents (see file: Speed\_Tx ID Label)

FCC ID: MLLSPEEDTx433L1



Model: Speed Tx\_433\_L1

S/N: YY-nnnnn

Miltel Communications Ltd. Made in Israel

This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may cause undesired operation.

Figure 3-1: Label Design

# **Installation Instructions**

#### 4.1 General

The *Speed Tx* is installed by a professional technician. Several possibilities for installation have been programmed into the system in order to provide solutions for installation of various types of water meters. The *Speed Tx* installation is performed using a stainless steel clamp that enables connection to pipelines of different diameters (0.75", 1.00", 1.50" or 2.00").

The Speed Tx unit is protected so that it is impossible to open or dismantle the box without breaking the four one-time screw locks.

#### 4.2 Installation

For on-site installation of the **Speed Tx** device, proceed as follows:

- 1) Loosen the four screws fastening the unit's box and open the box cover.
- 2) Install the unit's box base as required:
  - a. For pipeline installations (as in Figure 2-1), first attach the stainless steel clamp (see Figure 4-1) to the pipeline, close it around the pipeline and fasten the screw in the middle of the device. Place the unit's box base on top of the screw and install it using two steel screws.

b. For wall mounting of the unit, install the base directly onto the wall or surface using the two steel screws.

3) Connect the wire pairs from the water meters to the terminal blocks on the PCB. Up to four such pairs can be connected, with unused connections left open (i.e., no termination is required).

#### **Note**

Connect each pair of wires to the respective terminals; note the connections for future reference.

- 4) Close the unit's box cover.
- 5) Perform functional radio test by touching box corner with strong magnet (trigger transmission). Verify correct reception of data at base station (concentrator). Update water actual readings for the respective meter.
- 6) Close the four screws fastening the cover.
- 7) Insert plastic protection plugs.



Figure 4-1: Speed Tx - Pipeline Installation