

**FCC Statement**

## Radio and Television Interference

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules and applicable Industry Canada specifications. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning this equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**WARNING:** Changes or modifications not expressly approved by Dorel Juvenile Group can void your authority to operate this equipment under the Federal Communications Commission rules..

**One (1) Year Limited Warranty**

Dorel Juvenile Group, Inc. warrants to the original purchaser that this Monitor is free from material and workmanship defects when used under normal conditions for a period of one (1) year from the date of purchase. Should the product contain defects in material or workmanship Dorel Juvenile Group, Inc., will repair or replace the product, at our option, free of charge. Purchaser will be responsible for all costs associated with packaging and shipping the product to Dorel Juvenile Group Consumer Relations Department at the address noted below and all other freight or insurance costs associated with the return. Dorel Juvenile Group will bear the cost of shipping the repaired or replaced product to the purchaser. Product should be returned in its original package accompanied by a proof of purchase, either a sales receipt or other proof that the products within the warranty period. This warranty is void if the owner repairs or modifies the product or the product has been damaged as a result of misuse.

This warranty excludes any liability other than that express stated previously, including but not limited to, and incidental or consequential damages.

**SOME STATES OR PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.**

**THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT MAY VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.**

©2013 Cosco Management, Inc. All Rights Reserved. Todos derechos reservados.

www.djgusa.com (800) 544-1108 www.safety1st.com Made in CHINA.

Hecho en CHINA. Styles and colors may vary. Los estilos y los colores pueden variar.

Distributed by (distribuido por) Dorel Juvenile Group, Inc., 2525 State St., Columbus,

IN 47201-7494 Dorel Distribution

Canada, 873 Hodge, St. Laurent,

QC H4N 2B1



Register for our eNewsletter and  
watch our experts on Safety 1st TV

8/16/13

4358-XXXX

# View 'n Motion WiFi Remote Video Monitor

## For use with smart devices\*

\* SmartPhone, Tablet, Computer  
and other devices not included.



FREE iOS or  
Android app

Thank you for purchasing a Safety 1st product. We are not only about safety, we're also about your satisfaction. If you have any questions or comments, please call our Consumer Relations department at 1-800-544-1108 or e-mail us at consumer@safety1st.com

Please read the following instructions and warnings carefully.

Keep these instructions for future reference.

Tool needed: Flathead Screwdriver (not included)

### ⚠ WARNING!

Strangulation Hazard - Children have STRANGLED in cords. Keep cords out of reach of children more than 3 feet (0.9 m) away. Do not use with an extension cord. Only use the AC adapters provided.



**⚠ WARNING!**

For indoor use only. To reduce the risk of fire or electrical shock, do not expose this product to water or moisture. NEVER attempt to disassemble the product. This is dangerous and will void the warranty.

**⚠ CAUTION!**

This monitor is not intended to be used as a medical monitor and its use should not replace proper adult supervision. You should check your child's activity at regular intervals as this monitor will not alert parents to the silent activities of a child.

**⚠ CAUTION!**

To protect your privacy, always turn the monitor off when not in use. Although encryption makes it less likely that sound and video can be decoded by other devices outside your home, it is not a guarantee.

**Important!**

- Please read all warnings and assembly instructions carefully before using the video monitor. Parent Unit is a Receiver. Baby Unit is a Transmitter.
- Check your child's activity at regular intervals, as this monitor will not alert parents to the silent activities of a child.
- To prevent entanglement with the adapter cord, NEVER PLACE THE CORD IN OR NEAR A CRIB OR PLAYPEN. DO NOT place the Receiver anywhere its AC adapter cord is near children.
- ALWAYS KEEP TRANSMITTER, RECEIVER AND AC ADAPTERS OUT OF REACH OF CHILDREN
- This product is not a medical monitor and its use should not replace adult supervision.
- Check the reception regularly.
- NEVER use the Transmitter or Receiver near water. For example, do not use near a bath tub, bathroom sink, laundry tub, kitchen sink, in a wet basement, etc.
- Always unplug the AC adapters from wall outlets during long periods of non-use.
- Check to make sure outlet plates are not unusually hot to the touch. If they are, immediately unplug cords from these outlets. Check that all outlet connections are in good condition so that adapter is not loose or that no wiring is exposed. Have a qualified, licensed electrician check the wiring as soon as possible.
- Position the Transmitter, Receiver and AC adapters to allow adequate ventilation and prevent these components from overheating.
- To prevent overheating, keep the Transmitter, Receiver and AC adapters away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat. Also keep these components out of direct sunlight.
- Certain electronic devices are sensitive to magnetic fields and may be damaged permanently or temporarily disabled if exposed to a magnetic field that is too strong. Video screen will become distorted and/or discolored if exposed to a strong magnetic field.
- Use only the AC adapters provided. Use of any other adapter may damage the Transmitter and/or Receiver. Plug AC adapters into standard household current only! (120V AC) To prevent entanglement and overheating, DO NOT use extension cords.
- The AC adapter may become slightly warm to the touch during operation. This is normal.
- Position the AC adapter cords so that they are not walked on or pinched by items placed upon or against them, paying particular attention to cords at AC adapter plugs, wall plugs and the point where the cords attach to the Transmitter and Receiver.
- To remove AC adapter from the outlet, firmly grasp the adapter "brick." DO NOT pull on the cord, as this could damage it.
- The LEDs emit IR (infra red) light that is not harmful.
- This product should be serviced only by qualified service personnel at Dorel Juvenile Group when:
  - An AC Adapter or its plug is damaged
  - The Transmitter or Receiver has fallen
  - Liquid has spilled into the Transmitter or Receiver, or
  - The Transmitter or Receiver do not appear to operate normally or exhibit a marked change in performance.
- DO NOT attempt to service this product beyond that described in the Troubleshooting section. All other servicing should be referred to qualified personnel at Dorel Juvenile Group.

Important Warnings . . . . .	2
System Requirements . . . . .	4
Features & Components . . . . .	5

**Getting Started:**

• Camera Set-up . . . . .	6
• Quick App Guide 	7
• Resetting the Camera . . . . .	8
• Getting Started Online with Wi-Fi devices (Android or iOS smart devices) . . . . .	9
• Getting Started Online with Cable/Ethernet devices (PC/Notebook & MAC laptops) . . . . .	10

**Camera & App Functions:**

• Home/Exit App . . . . .	11
• Temperature . . . . .	11
• Humidity . . . . .	11
• Talk Status . . . . .	11
• Settings . . . . .	11
• Volume . . . . .	11
• Alerts . . . . .	11
• Pan/Tilt . . . . .	12
• Zoom . . . . .	12
• Brightness . . . . .	12
• Talk . . . . .	12
• Share . . . . .	12
• My Cams . . . . .	13
• Shared Cams . . . . .	13
• More Options . . . . .	13
• Help . . . . .	13

**Add Additional Cameras**

(Scan QR Code or Enter Camera ID Number): . . . . .	14
• My Cams/Camera List . . . . .	14
• My Cams/Delete Camera . . . . .	14

**Add Friends to Share**

• Shared Cams/Add a Friend: . . . . .	15
• Shared Cams/Friends List . . . . .	15
• Shared Cams/Delete a Friend . . . . .	15

Use & Care . . . . .	16
----------------------	----

Safety Instructions . . . . .	17
-------------------------------	----

Troubleshooting . . . . .	18 & 19
---------------------------	---------

FCC Statement . . . . .	20
-------------------------	----

Warranty . . . . .	20
--------------------	----

## System Requirements

### Mobile Device:

- Android 2.2+ HVGA+ resolution device
- iOS 4.0+ iPhone, iPad, iPod touch.

### Web Browser:

- FireFox 5.0+
- IE7+
- Chrome 13.0+
- Safari 3.2+.
- Computer operating system should be Win XP+, Linux 2.6+, MAC OSX 10.5+. Should contain Flash player and Java JRE 1.6+.

### Network:

- Requires DHCP service from router.
- Bandwidth: Upload >512K, download >2M.
- WiFi access point (optional, required for camera to connect to internet using WiFi.)
- Wireless bandwidth >54M.

## Features & Components

WiFi Remote Video Monitor  
(front & back views)



AC Adapter &  
Adapter Cord  
(USB Connector)

### WiFi Remote Video Monitor

- A** Motorized Camera (Pan/Tilt)
- B** Photo Sensor (for night mode detection)
- C** Camera Lens
- D** Power On/Off Button
- E** Microphone

- F** Speaker
- G** Connection Status (Red LED)
- H** AC Adapter Jack
- I** Temperature & Humidity Sensor
- J** Cable Connection Jack
- K** Power On Indicator (Green LED)
- L** Reset Button



## Camera Set-up:

- Choose a Camera location that will provide the best view of your baby in the crib. Camera should be placed on a flat surface, such as a dresser, bureau or shelf. **NEVER** place Camera on cords within **3 feet** of the crib.

### ⚠ WARNING!

Strangulation Hazard - Children have STRANGLED in cords. Keep cords out of reach of children more than 3 feet (0.9 m) away. Do not use with an extension cord. Only use the AC adapters provided.



- Insert large end of AC Adapter Connector cord into USB port on AC Adapter.
- Insert the small end of the AC Adapter cord into the AC Adapter Jack on the back of the Camera and plug the AC Adapter into wall outlet.
- Press the Power On/Off Button on the front of the Camera. The green Power LED, on the back of the Camera, will light up. **Note:** Press the Power On/Off Button again to turn device off. The green Power LED will turn off.



### IMPORTANT NOTES:

- The Camera must be in range of the Wi-Fi router with which you want to link.
- If you move your Camera from one router to another (i.e. from home to office), then the Camera must be reset. Reset again, if you change for other smart devices (Android or iOS).

Please refer to "Resetting the Camera" section (page 8).

App Icons	Icon Description/Features
	Home - Exit out of app.
	Temperature - Displays room temperature from current linked camera.
	Humidity - Displays humidity level from current linked camera.
	Settings - Change app account password settings and camera settings.
	Volume - Slide the volume from - to + to increase volume level and vice versa.
	Alert - Tap to view email notifications for sound and temperature alerts
	Pan/Tilt - Press the up and down arrows to tilt and the left and right arrows to pan.
	Zoom - Slide the zoom from - to + to enlarge the view and vice versa.
	Brightness - Slide the brightness from - to + to brighten the view and vice versa.
	Nightlight - Turn the Nightlight On/Off.
	Talk - Turn the Talk feature On/Off. When the Talk feature is activated, the Talk Icon appears in the top status bar.
	Share - Tap to invite, add and change status of friends sharing camera views.
	My Cams - Tap to add and change cameras on/off.
	Shared Cams - Tap to add and change status of additional cameras
	More Options - Tap to manage Account Settings and App updates from Safety1st.
	Help - Tap for help with connection problems. See Troubleshooting Section (pages 18 & 19).



### Resetting the Camera:

- If your Camera is moved from one router to another (home to office), then the Camera must be reset again. And reset again for Wi-Fi devices (Android or iOS smart devices).
- 1. Power Off the Camera.
- 2. Press and hold the Reset Button (underside of Camera).
- 3. Power On the Camera.
- 4. Keep pressing the Reset Button until you hear a beep sound.
- 5. Release the Reset Button and wait for the Camera to complete the internal reset procedure.
- 6. After about 1 minute, two short beeps will be heard and the red LED starts blinking.
- It may take a few minutes until your Camera appears in your Wi-Fi devices list, or is added to your account. Please be patient.
- The Camera view will be displayed automatically once the Camera has been added.

### Status of LED Indication (Red LED):

Reset / Setup status	fast blinking
Unconnect status	slow blinking
Connect status	solid red / no blinking

### Getting Started Online with Wi-Fi devices (Android or iOS smart devices):


- Using your device browser, go to [www.safety1st.com](http://www.safety1st.com) to download and install the Safety1st App.
- Turn on the Wi-Fi of your device and select your wireless network.
- Power on the Camera (see Camera Set-up and Resetting the Camera sections (pages 6 & 8).
- After downloading the Safety1st App, the Account Setup screen appears. Create an account: Enter a Username, a Password and e-mail address. Agree with the Terms of Use and tap "Submit". **NOTE:** All fields are required to be filled in and Terms of Use must be accepted to proceed.
- Login into account. Follow the on-screen instructions, select the Wi-Fi connection, and select the Camera from the list.
- Successful connection goes to Live Feed of activated Camera on screen.
- Wait up to 5 minutes for a successful connection. Should the connection process take longer, logout and try again.
- Ensure that you have a good Wi-Fi network connection on your device.





## Getting Started Online with Cable/Ethernet devices (PC/Notebook & MAC laptops):

- Connect Ethernet Cable or Mini USB Cable to the back of the Camera and the other end into your router. NOTE: Please have your router password available.
- Please make certain that the Camera is connected to a power outlet. Power on the Camera (see Camera Set-up and Resetting the Camera sections (pages 6 & 8).
- Using your device browser, go to [www.safety1st.com](http://www.safety1st.com) to download and install the Safety1st App.
- After downloading the Safety1st App, the Account Setup screen appears. Create an account: Enter a Username, a Password and e-mail address. Agree with the Terms of Use and tap "Submit". NOTE: All fields are required to be filled in and Terms of Use must be accepted to proceed.
- Login into account. Follow the on-screen instructions, select the Cable connection, and select the Camera from the list.
- Successful connection goes to Live Feed of activated Camera on screen.



## Camera and App Functions:



### Home/Exit App

- Tap to exit out of app.

70°F

### Temperature

- Displays room temperature from current linked camera. Tap to adjust temperature format settings.

68%

### Humidity

- Displays room humidity level from current linked camera. Tap to adjust humidity settings.



### Talk Status


- When the Talk feature is activated, the Talk Icon appears in the top status bar. (See page 12 for use).



### Settings

- Tap to adjust settings. Change Camera settings, Wi-Fi settings, Alert settings, & Audio Sensitivity settings.

Temperature  
Humidity



### Volume

- Tap to adjust Volume. Move the slider from left (-) to right (+) to adjust volume level.



### Alerts

- Tap to turn On/Off notification for sound and temperature alerts.



## Camera and App Functions:



### Pan/Tilt

- Tap to adjust view from motorized Camera. Press the up and down arrows to tilt and the left and right arrows to pan.



### Zoom

- Tap to adjust view from motorized Camera. Slide the zoom from - to + to enlarge the view and vice versa.



### Brightness

- Tap to adjust Brightness. Slide the brightness from - to + to brighten the view and vice versa.

### Pan/Tilt Arrows Control



### Nightlight

- Tap to turn the Nightlight On/Off.



### Talk

- Tap to turn the Talk Back function On/Off. When the Talk feature is activated, the Talk Icon appears in the top status bar.



### Share

- Tap to invite, add and change status of friends sharing Camera views. (See "Add Friends to Share Camera Views" section on page 15).

## Camera and App Functions:



### My Cams

- Tap to add and change Cameras On/Off (See "Add Additional Cameras" section on page 14).



### Shared Cams

- Tap to add and change status of additional Cameras sharing Camera views. (See "Add Friends to Share Camera Views" section on page 15).



### More Options

- Tap to manage Account Settings and App updates from Safety1st.



### Help

- Tap for help with connection problems. See Troubleshooting Section (pages 18 & 19).



My Cams      Shared Cams      More Options



### Add Additional Cameras (Scan QR Code or Enter Camera ID Number):



#### My Cams/Add Camera

1. Locate the Camera ID # and QR Code on the back of the Camera. You can then enter the Camera ID # or by scanning the QR Code.
2. Enter a Camera Name. Once Camera has been successfully added, you can change the Camera Name on the Camera Settings page.



#### My Cams/Camera List

Tap to view list of Cameras connected, and tap to turn individual Cameras On/Off.



#### My Cams/Delete Camera


Tap to delete a connected Camera from the Camera List. Press the delete button to confirm Camera is deleted.

### Add Friends to Share Camera View:



#### Shared Cams/Add a Friend

- Tap to send an email invite to add a friend. This function will send email with username, prompting friend to create a password.
- Once friend has been successfully added, you can change the sharing status of your friend..



#### Shared Cams/Friends List

Tap to view list of friends connected, and tap to turn individual sharing of friends On/Off.



#### Shared Cams/Delete Friend

Tap to delete a connected friend from the Friends List. Press the delete button to confirm friend is deleted.



## Care and Cleaning

Use a soft, dry cloth to keep your monitor free from dust.  
DO NOT immerse product in water.

### Cleaning Camera Lens:

1. With a soft brush, such as a clean makeup brush, carefully brush away any dust and dirt particles that may be on your Camera lens. Do not skip this step as a small bit of sand or dirt left behind could scratch your lens in the next steps.
2. Take a cotton swab and lightly moisten it with clean water. Carefully swab around the inside edges of your lens.
3. With a dry portion of a lens cloth or soft non-abrasive tissue, buff the lens in a circular motion to dry.

## Helpful Hints

Use household electricity. Range and sound quality also depends on the construction of your house. Steel reinforced wall, for example, reduces the effective range of the monitor.

When not using the Unit, remove AC Adapter and be sure the power button is "OFF". When you are not using the AC Adapter, remove it from the Unit and store it in a safe, dry place until you need it again.

When using the AC Adapter with household electricity, make sure the outlet is "ON". Some electrical outlets are powered through a switch in the room. If the Camera is plugged in and turned "ON", the power indicator light should be lit. If it is not, try turning the light switch in the room "ON".

## Safety Instructions

**VENTILATION:** The Monitor should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings, or placed in an enclosed installation, such as a book case or cabinet that may impede the flow of air through the ventilation openings.

- Position the Transmitter, Receiver and AC adapters to allow adequate ventilation and prevent these components from overheating.

**HEAT:** The Monitor should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat. Also keep these components out of direct sunlight.

**POWER SOURCE:** The Monitor should be connected to a power supply only of the type described in these operating instructions.

**POWER CORD PROTECTION:** The power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against it. Pay particular attention to the cord at the plug, convenience receptacle, and at the point it exits from the Monitor. **NOTE: Do not place adapter under a window where a child might use it to step on and reach something that might be dangerous.**

- Check to make sure outlet plates are not unusually hot to the touch. If they are, immediately unplug cords from these outlets. Check that all outlet connections are in good condition so that adapter is not loose or that no wiring is exposed. Have a qualified, licensed electrician check the wiring as soon as possible.

**OBJECT AND LIQUID ENTRY:** Care should be taken so that objects do not fall onto, and liquids are not spilled into the enclosure through the openings.

**DAMAGE REQUIRING SERVICE:** The Monitor should be serviced by qualified service personnel when:

- A. The power supply cord has been damaged; or
- B. Objects have fallen or liquid has been spilled into the product; or
- C. The Monitor has been exposed to rain; or
- D. The Monitor does not appear to operate normally or exhibits a marked change in its performance; or
- E. The Monitor has been dropped or the enclosure damaged.

**THE USER SHOULD NOT ATTEMPT TO SERVICE OR REPAIR THE MONITOR. ALL SERVICING SHOULD BE REFERRED TO SAFETY 1<sup>ST</sup> CUSTOMER SERVICE DEPARTMENT: (800) 544-1108.**



#### FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- \*Reorient or relocate the receiving antenna.
- \*Increase the separation between the equipment and receiver.
- \*Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \*Consult the dealer or an experienced radio/TV technician for help.

#### INDUSTRY CANADA NOTICES (IC):

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device

#### Avis d'Industrie Canada (IC):

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil

RF Exposure warning: The distance between user and product include its antenna must be no less than 20cm during the normal operation.  
La distance entre l'utilisateur et de produits ne devrait pas être inférieure à 20cm