

1. OPEN THE BATTERY COVER AND SNAP IN A 9V BATTERY.
2. TURN THE "ON/OFF" SWITCH TO "ON" POSITION.
3. PRESS THE "PUSH TO TALK" BUTTON TO TRANSMIT YOUR VOICE.
PRESS THE "MORSE CODE BUTTON" AT THE SAME TIME TO TRANSMIT MORSE CODES.
4. RELEASE "PUSH TO TALK" BUTTON FOR RECEIVING VOICE OR MORSE CODES.
5. TURN THE "ON/OFF" SWITCH TO "OFF" POSITION AFTER USING.

MODE D'EMPLOI:

1. OUVRE LE COUVERCLE DES PILES ET INSTALLER UNE PILE 9 VOLTS.
2. METS L'INTERRUPTEUR "MARCHE/ARRET" SUR LA POSITION "MARCHE".
3. APPUIE SUR LE BOUTON "POUSSE POUR PARLER" POUR TRANSMETTRE TA VOIX.
APPUIE SUR LE "BOUTON CODE MORSE" EN MEME TEMPS POUR TRANSMETTRE EN MORSE.
4. LACHE LE BOUTON "POUSSE POUR PARLER" POUR RECEVOIR LA VOIX OU LE CODE MORSE.
5. METS L'INTERRUPTEUR "MARCHE/ARRET" SUR LA POSITION "ARRET" APRES UTILISATION.


WARNING:

DO NOT TOUCH OR MODIFY THE INTERNAL COMPONENTS OTHER THAN REPLACING THE BATTERY.

ATTENTION:

NE PAS TOUCHER OU MODIFIER LES COMPOSANTS INTERNES EN DEHORS DU CHANGEMENT DES PILES.

REQUIRES 2-9 VOLT ALKALINE BATTERIES (NOT INCLUDED)
FONCTIONNE AVEC 2 PILES ALCALINES DE 9 VOLTS (NON FOURNIES)



MADE IN CHINA
FABRIQUE EN CHINE

"Modifications not authorized by the manufacturer may void users authority to operate this device."

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.