

User Manual

The wireless remote control is a small and portable 2-Key transmitter. It is very convenient for a user to put it in a pocket. The transmitter used to control equipment LOCK or UNLOCK.

The wireless remote control encode IC is LX2240B1, data format is composed of 20 bits address code and 4 bits data.

One bit data width of 1.3MS.

The data of the LOCK key is 0001

The data of the UNLOCK key is 0010



1. Basic Specification:

- 1). Power supply: DC6V (2*CR2016)
- 2). Modulation mode: AM
- 3). Frequency: 433.92MHz
- 4). Outline dimensions: 61mm(length), 29 mm(width), 13 mm(height)
- 5). Product weight: 25 ± 3g

6). Operating temperature range: 0 ~50

7). Storage temperature range:-10 ~60

2. Applications:

Car Security System

Garage Door Controller

Home/Office Security System

Personal Alarm System

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.