



Wireless Door Chime Accessory Transmitter

This Package includes:

- Door chime button
- Battery

You will need a screwdriver and other tools depending on how the button is mounted.

Product Features include:

- Battery powered transmitter - No wires to run.
- Channels are selectable to allow more than one door chime to ring at the same time.

To get the most out of this product, please read these instructions carefully.

INSTALLATION

1. Install battery.

Remove the cover from the side of the chime button case. Lift the case up and away from the back. Install battery (supplied).

2. Set the frequency code to match your door chime.

Make sure that the frequency set matched on both the button and chime. Replace cover removed in Step 1.

3. Before mounting, test the range.

Put the chime and the button where you want to mount them and then press the button.

4. Mount chime button.

Drill 3/4" diameter x 3-1/2" deep hole at chime button location. Insert button into escutcheon and use provided hardware to install.

OPERATION

Press the door chime button to verify that the button and chime work properly. When the button is pressed, the chime should sound. If it doesn't, check that the frequency codes are set the same and that the alkaline batteries are fresh.

BATTERY REPLACEMENT

Chime

Replace batteries following door chime instructions.

Button

Open button case (see Step 1). Replace battery with one N Cell, 1.5V alkaline battery. Close button case.

ADDITIONAL DOOR CHIMES

When installing other Wireless Door Chime sets, remember to set switches to different settings to avoid interference. If you want them to all ring at the same time, set them to the same frequency code.

TROUBLESHOOTING

The range of the door chime depends on location, temperature and battery condition. If you are having problems with this product, please try the solutions listed below.

Chime rings on its own:

- A neighbor may have a wireless chime set with the same frequency jumper settings. Change the chime and button frequency jumpers.

Chime doesn't sound:

- Make sure the button and the chime jumpers are set the same.
- Replace the button battery. Also check chime batteries.

Batteries are OK, but chime does not work when installed:

- Mounting the chime or button directly on metal, concrete or near metal studs reduces the range.
- Do not mount the chime too close to ground level concrete slabs which may also reduce the range. Mount the chime away from the floor.
- Try different locations for the chime closer to the button. Also, try to orient the chime at a different angle to increase the range. Range is most effective to the sides of the button.

Questions on this product?

Call 1-800-637-1453

7:30 AM to 6:00 PM Central Time, Weekdays

Regulatory Information

The user is cautioned that changes or modifications not expressly approved by the party responsible for regulatory compliance could void the user's authority to operate this equipment.

FCC NOTE

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

WARRANTY

BROAN-NUTONE ONE YEAR LIMITED WARRANTY

Broan-NuTone warrants to the original consumer purchaser of its products that such products will be free from defects in materials or workmanship for a period of one year from the date of original purchase. THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

During this one-year period, Broan-NuTone will, at its option, repair or replace, without charge, any product or part which is found to be defective under normal use and service.

THIS WARRANTY DOES NOT EXTEND TO FLUORESCENT LAMP STARTERS, TUBES, HALOGEN AND INCANDESCENT BULBS, FUSES, FILTERS, DUCTS, ROOF CAPS, WALL CAPS AND OTHER ACCESSORIES FOR DUCTING. This warranty does not cover (a) normal maintenance and service or (b) any products or parts which have been subject to misuse, negligence, accident, improper maintenance or repair (other than by Broan-NuTone), faulty installation or installation contrary to recommended installation instructions.

The duration of any implied warranty is limited to the one-year period as specified for the express warranty. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

BROAN-NUTONE'S OBLIGATION TO REPAIR OR REPLACE, AT BROAN-NUTONE'S OPTION, SHALL BE THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY. BROAN-NUTONE SHALL NOT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH PRODUCT USE OR PERFORMANCE. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. This warranty supersedes all prior warranties.

To qualify for warranty service, you must (a) notify Broan-NuTone at the address or telephone number below, (b) give the model number and part identification and (c) describe the nature of any defect in the product or part. At the time of requesting warranty service, you must present evidence of the original purchase date.

Broan-NuTone LLC, 926 W. State Street, Hartford, Wisconsin 53027 www.nutone.com 800-558-1711