

# ALIGNMENT INSTRUCTIONS

## WARNING

Any repairs or adjustments should be made under the supervision of a qualified radio-telephone technician.

## TRANSMITTER

### 1. Power Supply Voltage

The power supply voltage should be set for 4.5 VDC measured at the radio during transmit. Periodically check the power supply voltage during the alignment procedure.

### 2. Frequency Setting

- A. Connect a frequency counter or Communications Service Monitor to the antenna connector through an RF power attenuator (5 watt minimum rating, 20 dB minimum attenuation).
- B. Depress the PTT switch.
- C. Adjust the C26 trimmer capacitor such that the output frequency is equal to the channel frequency with a maximum error of +/- 200 Hz.
- D. Release the PTT switch.

### 3. Output Power Alignment.

- A. Set the power supply voltage for 4.5 VDC.
- B. Connect a Communications Service Monitor or watt meter and dummy load to the antenna connector.
- C. Depress the PTT switch.
- D. To be convinced for 0.45 Watt (50 ohm load) output power with a maximum error of -0.15 Watts.
- E. Release the PTT switch.

### 4. Modulation Adjustment.

- A. Connect an audio generator.

The audio frequency should be set at 1 KHz at 400mVrms.

- B. Connect an FM deviation meter or Communications Service Monitor to the antenna connector through an RF power attenuator ( 5 watt minimum rating, 20dB minimum attenuation). Set the monitor to read peak deviation.
- B. Depress the PTT switch.
- D. Adjust RV 1 for +/- 2.5 KHz maximum deviation.

SB TECHNOLGOY CO., LTD.  
FCC ID: OTVSBTFR458WB  
JOB #: 665BK0  
EXHIBIT #: 8A

E. Release the PTT switch.

## RECEIVER

NOTE: Insure that the proper channel has been selected before proceeding with the alignment procedure.

### 1. Power Supply Voltage.

The proper voltage for testing is 4.5 VDC.

### 2. Receiver Alignment

A. Connect an RF signal generator or Communications Service Monitor to the antenna connector.

C. Connect a SINAD meter and oscilloscope across the speaker terminals.

Note : Don't share speaker & antenna ground

C. Set the output level of the RF signal generator for -47dBm, the generator should be set for +/- 1.5KHz deviation of a 1KHz tone.

D. Monitor the audio output level for 0.5Vrms.

E. Adjust L1 for maximum audio output.

### 3. Weather Receiver Alignment

A. Connect an RF signal generator or Communications Service Monitor to the antenna connector.

B. Connect a SINAD meter and oscilloscope across the speaker terminals.

Note : Don't share speaker & antenna ground

C. Set the output level of the RF signal generator for -47dBm, the generator should be set for +/- 1.5KHz deviation of a 1KHz tone.

D. Set Weather Receiver mode at Function operation.

E. Monitor the audio output level for 0.5Vrms.

F. Adjust L33 for maximum audio output