



TXU TM702V00 USER GUIDE

Use the following procedure to install and operate the TXU Outage Notification Device TM701V00 Outage Notification device

Installation

- Step 1.** There are three components to your *Outage Notification installation package*: the device, a phone cord, and a small AC adapter (which is located in the small box)
- Step 2.** Remove the AC adapter from the box
- Step 3.** Visually inspect all pieces for damage. (Note: You may notice the status indicator light on the device blinking approximately every 15 seconds – this is normal.)
- Step 4.** Insert one end of the phone cord into the "Phone Line IN" port of the device.
- Step 5.** Insert the round plug end of the AC adapter cord into the "POWER" port of the device.
- Step 6.** Locate a power outlet near an analog telephone jack (Typically a fax line, not a digital or ISDN phone line). You should select a 110 Volt power outlet that is not controlled by a wall switch and is on the electrical circuit you wish to monitor. The telephone jack and wall outlet should be within approximately seven feet of each other.
- Step 7.** Insert the free end of the phone cord into the telephone jack.
- Step 8.** Plug the AC adapter into the wall outlet.

Note: *The status indicator light will turn ON continuously for a few seconds, then start blinking to indicate that it is contacting TXU Energy. After sending a short message, the status indicator light will be continuously ON – Your AC power is ON and the service is activated.) If you wish to connect a fax machine or an answering machine, simply use the jack marked "Phone Line OUT" on the device.*

- Step 9.** Within fifteen minutes you should receive the following message from the service, "Welcome to TXU Outage Notification! Your service has been successfully activated." This message will be sent to the contacts setup during the enrollment process. If you do not receive a Welcome message within fifteen minutes, please call TXU Outage Notification Customer Service at 1-888-398-8711 or check the contact information setup on the Outage Notification web site at:

<http://www.txuenergy.com/energyserv/outagenotification>

For your convenience there is a "Velcro" strip included in the kit. If you wish to attach the device to the wall or under a table, simply remove the protective film from one side of the Velcro strip and apply it to the back of the device (do not cover the battery cover door). Remove the second protective film from the Velcro strip and press the device in place.

Device Relocation

Use the following procedure to move the device to another location within the same building or structure.

- Step 1.** First select the new location.
- Step 2.** Remove the phone cord from the "Phone Line IN" port of the device.
- Step 3.** Remove the round plug end of the AC adapter cord from the power port of the device.



- Step 4.** Move all components to the new location.
- Step 5.** Plug to the phone cord into the (analog) telephone wall outlet.
- Step 6.** Plug the AC adapter into the 110 Volt outlet at the new location (again, be sure that the outlet is not controlled by a wall switch.)
- Step 7.** Insert the free end of the phone cord into the "Phone Line IN" port of the device.
- Step 8.** Insert the round plug end of the AC adapter cord into the "POWER" port of the device.
- Step 9.** After a moment, the status indicator light should turn ON continuously. You should not receive any notifications from TXU Energy.

Note: *To avoid possible regulated utility charges for reporting a false outage be sure to FIRST disconnect the round plug end of the AC adapter cord from the device before unplugging the AC adapter from the wall outlet.*

Initial Online Access Instruction

Please note that your initial user ID for online account access is your business phone number that you provided when you register for the service. Your initial password is changeme. For security purpose, please reset your user ID and password after you log in the first time.

Status Indicator Light Conditions

The following conditions are indicated by the light status indicator on the device:

- ON Continuously -- AC power is ON.
- Fast blinking (continuous blinking at a 2 second interval) – AC power is OFF, device is running on battery.
- Fast blinking (2 second interval, short duration) – device is attempting to contact TXU Energy.
- Slow blinking (continuous blinking at a 15 second interval) – device is awaiting activation (or being relocated).
- OFF continuously – AC is OFF, battery is dead.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.