

front 445mm x 210mm

LIMITED WARRANTY

ENTERMEDIA 1 YEAR LIMITED WARRANTY

Thank you for purchasing a highly qualified Entermedia's (ET) product.
ET warrants its products against defects in materials and workmanship under generally accepted industry standards for a period of one (1) year for labor and parts from the date of retail purchase. ET's warranty obligations are limited to the terms and conditions set forth below:

TERMS AND CONDITIONS

- If a defect or defects exist, at its option, ET will repair the product at no charge, using new or refurbished replacement parts provided the product does not fall into one of the categories of Section Number 9. "The warranty does not cover as below:" Replacement parts are warranted for the balance of the original applicable warranty period.
- To obtain warranty protection, notice of the alleged defects must be given promptly upon discovery and this warranty card bearing the date of purchase, the product's model number with its serial number and other fill-ins must be presented with dated proof of purchase (Tax Invoice / receipt) to one of our authorized service centers.
- Our decision on all questions with respect to complaints as a result of defects, either materials or workmanship, shall be conclusive.
- In order to ensure that you are covered by the warranty, you should use only genuine ET's parts and components such as adaptors, cables provided during installation.
- Entermedia or Authorized Service Centers will repair products under warranty at no charge, given all guidelines and restrictions are followed. Shipping expenses may or may not apply to customer depending on the region. Please contact local service center before sending any units in for repair.
- After warranty period, to have normal service, customers shall bear all costs in shipping the product(s) for both ways (Customers to service centers and Service centers to customers).
- All of returned products must be packaged appropriately, and it is recommended that they be insured or sent by a method that provides for tracking of the package. The recipient (service center(s) or even ET) is not responsible for any product that is lost or damaged in transit.
- Please be noticed that the warranty will not be effective and all the costs of both after service and shipping in and out shall be born by customers if they purchase the products flawed in or purchased from other countries.
(Our authorized service centers can be founded in the last page of the manual provided.)
- The warranty does not cover as below :
 - Defects, damage and breakage resulting from accidents, misuse (breakage, spillage of food / liquid substances that defect the product and parts such as P.C.B, battery leakage and etc.), wrong usage of electrical supply and voltage, abuse, alternation, modification, improper testing/operation, installation, tampering or failure of the purchaser to follow normal operating procedures described in the user's manual.
 - Product subjected to unauthorized disassembles and/or repairs which adversely affect the performance of the product.
 - In case of non-authorized third party engagement.
 - Normal and customer wear and tear, corrosion, rusting or stains.
 - Scratches and damages to the outer surface areas and externally exposed parts that are due to normal customer use.
 - Claims for damaged/missing parts or accessory after 3 days from the original date of goods received.
 - Product which has its serial number removed or altered or made illegible / tampered.
 - If the warranty card is being altered, defaced or erased in any manner whatsoever.
 - Accessories in the product package provided by ET such as adaptors, cables which are considered as consumable articles.
 - The warranty period for a voice coil inside the mic ball of a mic is 6 months from the date of a retail purchase.
- Any service charge due to the clauses of "The warranty does not cover" will be billed to customers and the service charge will vary depending on each service center in each country. Please consult the service charge with your nearest service center.

If you want to contact our technical "Service Center" close to your area, please refer to our website at "www.entermedia.xyz".

LIMITED WARRANTY

PRODUCT		CITY / STATE / ZIP	
MODEL NUMBER		TELEPHONE	
WARRANTY PERIOD	1 YEAR FROM PURCHASE DATE	PURCHASE DATE DAY / MONTH / YEAR	
PURCHASER'S NAME		PURCHASED FROM	
ADDRESS		REASON FOR SERVICE	

Designed & Supplied by ENTERMEDIA CO., LTD.

*Commercial usage of this device is not allowed.

Address : Enter B/D, 157-1, Seongo-ro, Bucheon-si, Gyeonggi-do, Korea 14429

VER.100

Tel : +82-32-880-9000 | Fax : +82-32-673-0868 | Website : www.entermedia.xyz

fold



What should you do if you encounter the following problems?

Q I cannot turn my MAGICSING on.

- Make sure the AC adaptor is plugged correctly into the power outlet.
- Make sure the HDTV cable is properly connected between your MAGICSING and TV.

A

Q I cannot see anything or hear any sound on my TV.

Check your TV's input select if it is correctly connected to your MAGICSING and HDMI port.

A

Q There is no sound coming from the MIC.

Press the volume button of the Karaoke. You can adjust that by using [▲][▼] buttons.

A

Q The MAGICSING display screen has frozen or has disappeared from the TV screen.

Press the power button off, and then turn it back on.

A

Q I cannot see anything or hear any sound on my TV.

- Check your TV's input select if it is correctly connected to your MAGICSING and HDTV port.
- If this connection doesn't work properly, you may try by changing the screen resolution setting.

A


- Press and hold button [1] on the microphone, and then press the [◊] button using another finger until the word "1080p 60Hz" appears on your TV.
Do not release button [1] and [◊] button until the word "1080p 60Hz" appears on the TV.
- Press and hold button [2] on the microphone, and then press the [◊] button using another finger until the word "1080p 50Hz" appears on your TV.
Do not release button [2] and [◊] button until the word "1080p 50Hz" appears on the TV.
- Press and hold button [3] on the microphone, and then press the [◊] button using another finger until the word "720p 60Hz" appears on your TV.
Do not release button [3] and [◊] button until the word "720p 60Hz" appears on the TV.
- Press and hold button [4] on the microphone, and then press the [◊] button using another finger until the word "720p 50Hz" appears on your TV.
Do not release button [4] and [◊] button until the word "720p 50Hz" appears on the TV.

A

MAGICSING

A QUICK GUIDE ON HOW TO USE YOUR MAGICSING


ET30KH



back 445mm x 210mm

STEP 1 What are the items inside your MAGICSING?


1 MAGICSING should contain the following items.




If you find any of the items above missing and/or damaged, please contact the store where you purchased the product from immediately.

STEP 2 How do you set up your MAGICSING?


1 Please connect one end of the HDTV cable to the HDTV port on the beside of the MAGICSING and the other end of the HDTV cable to the HDMI port on your TV.



2 Please connect the AC adaptor as shown in the picture below.




3 Please turn your TV on and select the connected HDMI port.




Tip If the connection of external speakers.

- For audio output, connect red end "Right" and white end "Left" of the RCA stereo cable to audio input on your amplifier or other audio devices.



STEP 3 How do you start using your MAGICSING?

1 Turn on the power switch beside the MAGICSING and press the [◊] button on the MAGICSING microphone. The MAGICSING Display Screen appears on your TV.




2 Update MAGICSING program to the latest version

- By default, MAGICSING program is set to automatically update itself when Wi-Fi is connected.
- When MAGICSING program releases the update, an update message will be shown on the screen.
- If updates are available, click the Update buttons to download and install them.
- Update will provide the latest version for new song's line up, MAGICSING system and MAGICSING Karaoke program and so on. You can always do a manual update in configuration settings of MAGICSING menu as well.

Settings of Wi-Fi connection

- Open your MAGICSING device's Settings.
- Tap Wi-Fi.
- At the top, tap the ON/OFF switch.
- On the list of available Wi-Fi networks, tap a network name.
If the network is secured and you need a password, you'll see the Wi-Fi lock.
- Once you're connected:
 - "Connected" shows under the network name.
 - The Wi-Fi network is a "Saved network." When in range, your device automatically connects to it.



Tip You can connect and use a mouse, keyboard and gamepads to MAGICSING's USB port.




3 After finishing the booting process, you can select Home screen. This home screen has "Karaoke", "Media", "Game", "Setting", "Manual". You can select and run these functions.

- Karaoke : Singing and enjoying MAGICSING Karaoke.
- Media : Playing video clip, mp3 and photo.
- Game : Playing embedded games.
- Setting : Settings for MAGICSING system.
- Manual : How to use MAGICSING.



4 To select a song using your MAGICSING arrow keys when the song list appears. And press ▶/■ to play a song.



* Play and sing all songs from the streaming service but the default limit is 30 seconds.
When you register the MAGICSING Streaming Service Coupon, you can enjoy all songs without time limit. (Refer to STEP4 on How to register the MAGICSING Streaming Service Coupon.)

5 You can adjust karaoke settings by using CONFIGURATION screen in the MENU.



STEP 4 MAGICSING streaming service coupon



- Download MAGICSING Karaoke app from the Google Play Store or APP Store on your Smartphone.
- To register the coupon code, sign up as member thru MAGICSING karaoke app using your registered e-mail.
- MAGICSING karaoke app is able to connect with MAGICSING Karaoke device to Smart phone thru the QR Code.

FCC compliance Information

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation ET30KH-BT

This device is intended only for OEM integrators under the following conditions:

- 1) The transmitter module may not be co-located with any other transmitter or antenna,
- 2) OEM shall not supply any tool or info to the end-user regarding to Regulatory Domain change.

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.).

IMPORTANT NOTE: In the event that these conditions can not be met (for example certain

laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

Maximum antenna gain allowed for use with this device is 4.75 dBi

End Product Labeling

To satisfy FCC exterior labeling requirements, the following text must be placed on the exterior of the end product : **Contains Transmitter Module FCC ID : PBNET30KH -BT**

Manual Information To the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required regulatory information/warning as show in this manual.

<Antenna Notice>

This Module should be used only supplied antenna. ENTERMEDIA CO., LTD. will not be held responsible for the problem caused when using a different antenna.

<RF Exposure>

This module is used in a fixed location. Therefore, It isn't necessary for the SAR testing.

<MPE Evaluation>

※ This device operates at separate distance above 20cm.