

MaiSto - Radio Control Vehicles

Please keep this owner's instruction manual for future reference.
It contains important information.
We reserve the right to improve/revise the product specifications without notice.

Class 1 LED Product

Contents:

- RC Vehicle With Built-in Rechargeable Battery (non replaceable) x 1
- Controller x 1
- 1.5V "AAA" LR03/R03 non-rechargeable Battery (For Controller Use) x 2
- USB Cable x 1
- Tracks x 24
- Cones x 6
- Owner's Instruction Manual x 1

Charging the built-in rechargeable battery for the RC vehicle: (Refer to Diagram 1)



1. Open the charging port cover on the vehicle.
2. Make sure the switch is on the OFF/CHARGE position before charging.
3. Locate a USB certified port from any of the devices shown below.
4. Connect the USB charging plug with the USB certified port.
5. The LED indicator will start lighting in red to show it is charging.
6. Once the LED indicator turns off, the vehicle is fully charged.
7. Detach the USB plug from the USB certified port, then install the charging port cover on the vehicle.

Battery installation for the controller: (Refer to Diagram 2)




1. Switch the power OFF.
2. Use screwdriver to loosen the screw on the battery cover and to open the battery cover. (Screwdriver is not included)
3. Install 2 new 1.5V "AAA" LR03/R03 batteries with correct polarity (+/-) as shown inside the battery compartment.
4. Install the battery cover and then tighten the screw on the battery cover.

How to play: (Refer to Diagram 3, 4, 5 & 6)

1. Follow the picture on the box to build you own track.
2. Set the "Power Switch" on the controller and vehicle to ON position, the "Power LED" on both the controller and vehicle will flash less than 3 seconds then stay on, meaning the automatic frequency matching between the controller and the vehicle is completed.




3. If the "Power LED" of the controller or the "Power LED" of the vehicle flash more than 3 seconds, switch off both the vehicle and controller, then turn them on again.
4. Pull the trigger on the transmitter to drive the vehicle forward. Push the trigger on the transmitter to drive the vehicle backward.
5. Press the top button on the transmitter to change the speed.
6. Turn the transmitter steering wheel to move the vehicle left or right.
7. If the vehicle does not run in a straight line, adjust the wheel alignment under the chassis.
8. The "Power LED" on the vehicle will not flash nor stay on if the rechargeable battery has run out power.
9. Turn the switch of the controller and vehicle to OFF position when not in play.



Performance Tips:

1. Do not drive the vehicle on grass, sand or go through water.
2. Do not drive the vehicle in windy or rainy weather.
3. Do not drive the vehicle into any hard object.
4. Keep fingers, hair and loose clothing away from the vehicle.
5. The operating range can be affected by a variety of factors:
 - a) Weak controller or vehicle batteries.
 - b) Interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transmitter, etc.
6. Outdoor usage is recommended in order to get optimal control range.
7. Remove the package, take out all accessories and assemble the product before giving it to children to play.



Cautions:

1. The Built-in rechargeable battery must be charged before use.
2. Do not overcharge the Battery.
3. Do not charge the Battery if it shows leakage, corrosion, or has loose or exposed wires or other damage.
4. Do not cover the vehicle with any sort of material while charging.

MaiSto - Véhicules radio-commandés

Veuillez conserver ce mode d'emploi pour vous-y reporter dans le futur.
Il contient des informations importantes.
Nous nous réservons le droit de modifier/améliorer les caractéristiques du produit sans avis préalable.

Produit de classe 1 LED

Contenu :



- Véhicule Radiocommandé Avec Batterie Incorporée (non remplaçable) x 1
- Contrôleur x 1
- 2 Piles 1.5V "AAA" LR03/R03 non-rechargeables (Pour l'émetteur)
- Câble USB x 1
- Pistes x 24
- Cônes x 6
- Mode d'emploi x 1

Recharge du pack batterie du véhicule RC: (Voir Diagramme 1)

1. Ouvrez le couvercle du port de charge du véhicule.
2. S'assurer que l'interrupteur est en position OFF/CHARGE (arrêt/charge) avant de charger la batterie.
3. Situez le port USB d'un appareil quelconque listé ci-dessous.
4. Branchez le câble de charge USB dans un port USB conforme.
5. Le voyant LED s'allumera en rouge pour indiquer le début de la charge.
6. Une fois le voyant LED éteint, le véhicule est complètement chargé.
7. Détachez la fiche USB du port certifié USB, puis installez le couvercle du port de charge sur le véhicule.

Mise en place de la pile de la télécommande: (Voir Diagramme 2)



1. Coupez l'alimentation (OFF).
2. Desserrez la vis du couvercle des piles à l'aide d'un tournevis et ouvrez le couvercle.(Tournevis non fourni)
3. Mettez en place 2 piles alcalines 1.5V "AAA" LR03/R03 neuves en respectant les polarités (+/-) indiquées dans le compartiment des piles.
4. Refermez le couvercle en place et serrez la vis.



Comment jouer: (Voir Diagramme 3, 4, 5 & 6)

1. Suivez l'image sur la boîte pour construire votre propre piste.
2. Mettez les "Interrupteurs d'alimentation" de la radiocommande et du véhicule en position ON (marche), les LEDs témoins d'alimentation du véhicule et de la radiocommande clignoteront pendant moins de 3 secondes puis resteront fixes, témoignant de la bonne synchronisation automatique des fréquences entre la radiocommande et le véhicule.

3. Si la "LED d'alimentation" de la radiocommande ou du véhicule clignote pendant plus de 3 secondes, arrêtez le véhicule ainsi que la radiocommande, puis rallumez-les.
4. Tirez sur le manche de la télécommande pour faire avancer le véhicule. Poussez sur le manche de la radiocommande pour faire reculer le véhicule.
5. Appuyez sur le bouton supérieur de l'émetteur pour modifier la vitesse.
6. Tournez le volant de la radiocommande pour faire aller le véhicule vers la gauche ou vers la droite.
7. Si le véhicule ne roule pas en ligne droite, réglez le levier d'alignement des roues situé sous le châssis.
8. La "LED d'alimentation" du véhicule ne sera ni allumée ni clignotante si la batterie est déchargée.
9. Mettez l'interrupteur d'alimentation du véhicule sur OFF lorsque vous ne l'utilisez pas.




Conseils pour de meilleures performances:

1. Ne roulez pas sur l'herbe, le sable, ou dans l'eau.
2. Ne roulez pas par temps pluvieux ou venteux.
3. Ne faites pas rentrer le véhicule dans un objet dur.
4. Gardez vos doigts, vos cheveux et les vêtements amples éloignés du véhicule.
5. La portée utile peut être affectée par différents facteurs:
 - a) Piles faibles dans l'émetteur ou dans le véhicule.
 - b) Interférences en provenance d'appareils émettant des ondes radio tels qu'une autre radiocommande émettant sur la même fréquence, un poste CB, un téléphone sans fil, un transformateur haute tension, etc.
6. Il est recommandé de jouer à l'extérieur pour maximiser la portée utile.
7. Retirez l'emballage, sortez tous les accessoires et assemblez le produit avant de le donner à l'enfant pour qu'il joue avec.

Mises en garde:

1. La batterie incorporée doit être chargée avant utilisation.
2. Ne surchargez pas la Batterie.
3. Ne chargez pas la batterie si elle présente des signes de fuite, de corrosion, si ses fils électriques sont lâchez ou apparents, ou si elle a subi d'autres dommages.
4. Ne recouvrez le véhicule avec aucun matériau souple en cours de charge.
5. Ne touchez pas le véhicule lorsqu'il est chaud. Attendez que le véhicule refroidisse avant de le recharger.
6. Ne jetez pas la batterie au feu.



5. Do not touch the vehicle when it is hot. Wait until the vehicle cools before recharging.
6. Do not dispose of the Battery in fire.
7. Do not dismantle the Battery or USB, and do not cut the Battery or USB cables.
8. The USB Cable used with the toy shall be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.
9. Rechargeable batteries are to be removed from the toy before being charged (for transmitter).
- 10.The Battery will be warm after charging, and hot after use in a Vehicle.
- 11.The supply terminals are not to be short-circuited.
- 12.Rechargeable batteries are only to be charged by adults or by children at least 8 years old.
- 13.Battery change must only be made by adults!
- 14.Note that the 1.5V "AAA" Battery is non-rechargeable and is not to be recharged. Only Batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor. Alkaline AAA batteries are recommended to be used for the transmitter. Do not mix alkaline, standard or rechargeable batteries. Do not mix old and new batteries or different type of batteries. Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions.
- 15.Exhausted batteries must be removed from the product.
- 16.Remove all batteries from the product when not in use for long periods of time.

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.
Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries.
You can hand in your old batteries at public collection points in your area or wherever batteries are sold.



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

Pb = Battery contains lead
Cd = Battery contains cadmium
Hg = Battery contains mercury

RSS-210 Compliance Statementent:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

1. This device may not cause interference;
2. This device must accept any interference, including interference that may cause undesired operation of the device.



MaiSto International, Inc.
Fontana, CA 92336, U.S.A.



Vous trouverez ces abréviations chimiques ainsi que le symbole d'une poubelle barrée sur les piles contenant des substances dangereuses:

Pb = Pile contenant du plomb
Cd = Pile contenant du cadmium
Hg = Pile contenant du mercure



MaiSto International, Inc.
Fontana, CA 92336, U.S.A.