

InsideTNC

IV011A

USER'S GUIDE

Copyright© 2000 Inside Telecom Co.,Ltd.

This installation guide is copyrighted. All rights reserved. This document may not, in whole or part, be copied, reproduced, reduced or translated by any means, either mechanical or electronic, without prior consent in writing from Inside Telnetcom Co., Ltd. The information in this manual has been carefully checked and is believed to be accurate. However, Inside Telnetcom Co., Ltd assumes no responsibility for any inaccuracies that may be contained in this manual.

In the interest of continuous product development product development, Inside Telnetcom Co., Ltd. reserves the right to make improvements in this manual and the products describes it at any time, without notice obligation.

LOCATION OF INSIDE TELNETCOM CO., LTD

ADD. : #1138, Sanbon-Dong, Kunpo-City, Kyounggi-Do, Korea., 435-040

TEL. : 82-31-396-1500

FAX. : 82-31-396-1112

URL. : www.insidetnc.co.kr

IDREAM.GeForce2 MX/GTS is registered trademark of Inside Telnetcom Co., Ltd

Intel Pentium®III is registered trademark of Intel Inc.

Microsoft Windows® is registered trademark of Microsoft Corporation.

nVIDIA GeForce2 MX/GTS® is registered trademark of NVIDIA Corporation.

All other trademarks belong to their respective owners.

Copyright© 1999 Inside Telnetcom Co., Ltd,

This product is for home use registered suitable EMI, you can use in the all kinds of area including a residential district.

FCC RF INTERFERENCE STATEMENT

NOTE :

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio, TV technical for help.
- Only shielded interface cable should be used.

Finally, any changes or modifications to the equipment by the user not expressly approved by the grantee or manufacturer could void the users authority to operate such equipment,

- CONTENTS -

1. Features of InsideTNC's IV011A
- The Feature of GeForce2 MX/GTS
- System Requirement
- Driver and Software Support
2. Installation (Hardware)
3. Installation (Software)
Method I. Plug& Play
Method II. Do it your self
4. Troubleshooting

APPENDIX

* Table 1-1. Windows 95/98ME Resolution rate & Refresh rate- 32MB

* Table 1-2. Windows 95/98 ME 3D Display Mode - 32MB

1. The Feature of InsideTNC's IV011A

Used nVIDIA's GeForce2 MX/GTS GPU, Inside Telnetcom's IV011A supports the advanced features, TwinView, a innovative dual display architecture, which doubles your desktop workspace using two space saving display and. DVC(Digital Vibrance Control) which provides crisp, bright visuals.

IV011A(DREAM.GeForce2 GTS) supports second Transform and Lighting Engines, NSR to be able to bring natural material properties to life via seven simultaneous pixel operations that deliver advanced per -pixel shading capabilities in a single pass and HDVP(High -Definition Video Processor) to enable you to turn their PCs into full quality DVD players and HDTV receivers/players.

The Feature of GeForce2 MX / GTS

- ▶ nVIDIA Corporation's GeForce2 MX/GTS GPU

	Core Clock	Memory Clock
GeForce2 MX	200 MHz	166 MHz
GeForce2 GTS	200 MHz	333 MHz

- ▶ SDRAM 32MB / 64MB
- ▶ NVIDIA Shading Rasterizer(NSR)
- ▶ High-Definition Video Processor (HDVP)
- ▶ Per-Pixel Shading and Advanced Video Processing
- ▶ Microsoft® Direct® and OpenGL® Optimization and Support
- ▶ TV-Out Support: Composite, S-VHS – option

TwinView : TwinView is NVIDIA's innovative dual display architecture. Through TwinView, IV011A supports the widest range of dual display configurations on the planet. You can connect virtually any combination of TVs, flat panels, and monitors. IV011A with TwinView is the first device to support two digital flat panel displays through dual integrated TMDS transmitters. (www.nvidia.com)

DVC(Digital Vibrance Control) : It's rare to find ideal lighting conditions for crisp, bright, clean onscreen visuals at home or in the office. Digital Vibrance Control is a patent pending innovation that allows the user to digitally control the intensity of all images through a simple control panel. The result is richer color, and brighter, cleaner, more ergonomically pleasing images. (www.nvidia.com)

NVIDIA Shading Rasterizer(NSR) : With the NVIDIA Shading Rasterizer (NSR) in GeForce2 GTS, wood looks grainy, lit objects gleam in the hotspots yet also cast realistic shadows, and water ripples and rolls into waves. (www.nvidia.com)

System Requirements

- Intel Pentium II 233MHz (Minimum) or compatible CPU
- Windows 95(OSR 2.1 Minimum) / Windows98 / Windows 98SE / Windows ME
- Windows NT 4.0 with Service pack 3 minimum)/ Windows2000
- Motherboard compatible with AGP 1.0/2.0
- CD-ROM Drive and Mouse

Driver and Software Supports


- Display Driver for Windows 95/98/ME
- Display Driver for Windows 2000, WindowsNT 4.0/3.5
- OpenGL ICD for Windows 2000, Windows NT 4.0, Windows 95/98/ME
- Display Driver for Linux, OS/2

Before Installation


To avoid accidental electric chock, shut your computer down and unplug the power cord before staring the following procedures. Remember which cable go to which connectors. You may want to label your computer's cable before disconnection them. To protect your board form damage due to static electrical discharge, ground yourself be touching the power supply box inside you computer before starting the procedures below.

2. Installation (Hardware)

1. With the power off, remove your computer cover and locate on AGP slot.




2. Insert your card firmly into the slot. Card should be taken to press it evenly and snugly into its slot. **Do not force!**



NOTICE.

AGP slot is designed as a double structure in a different way from PCI slot. When DREAM.GRAPHICS is not inserted into its AGP slot snugly, your computer system can not work at all; therefore, you must set your board firmly into the slot.

3. Once you are certain that the card is installed properly in its slot, secure it to the PC frame with the screw you removed in step. Make sure the card does not lift out of the slot while tightening the bracket screw. Connect your monitor cable to the 15 pin-connectors on your computer.



4. Secure the cover and reboot your computer. Continue with the software installation for operating system in the following section.

REBOOT!

3. Installation (Software)

This section describes the software installation process for supported Windows.

To install the GeForce2 MX driver

1. Start up Windows and log onto and account with administrator privileges.
2. Place the GeForce2 MX/GTS CDROM disk into your CD-ROM drive. When the installation window opens, choose the installation.
3. Follow the instructions that appear on your screen.
4. Restart your system at the prompt. You have installed your driver software successfully!

Inside TNC's GeForce2 MX/GTS Driver

The DREAM.GRAPHICS driver software lets you optimize the working relationship between your card, your system and your applications. Use the Inside TNC Display Control Panel screens to customized the driver settings.

I. Play & Plug

1. When Windows 95/98ME starts working, *Add New Software Wizard* appears by the function of Play& Plug box with the message of '*Windows has found the following new hardware*'. Select *Specify a location of the driver(Advanced)*, then click *Next* from the following dialogue box.

