

# Hand-Held Transmitter

## Instruction Manual

### Technical Specification:

Maximum Loading: 15A 125V/AC 60Hz

Batteries: 12V(GP23A)

Remote Frequency: 315MHz±0.05%


Remote Distance:  $D \geq 35$ feet(The distance which without any disturber)

Coding: Preset before delivery

Ambient Temperature: -30°C(-22°F)~60°C(140°F)

### Installation:

1. Open the manual cover for batteries, install a pair of batteries 12V 23A  
See Figure 1.
2. Plug indoor & outdoor receiver in sockets on inside & outside walls as  
Figure 2,3
3. Press RF manual overriding button "ON" & "OFF" respectively, and the  
receiver will turn on & off.



**Note:**

1. 60-120cm away from the ground.
2. On inside/outside wall.
3. Not exposed to direct sunlight.
4. Not installed on inside metal walls, far away from metal objects.
5. Please use the device within the allowed distance.
6. Please recharge the batteries when the controlling distance is shortened.
7. Wait for 0.5 sec. once press button.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.