

Nokia 6750 User Guide



9208298
Issue 1

CE 0434

DECLARATION OF CONFORMITY

Hereby, NOKIA CORPORATION declares that this RM-381 product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/.

© 2008 Nokia. All rights reserved.

Nokia, Nokia Connecting People, and Navi are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

US Patent No 5818437 and other pending patents. T9 text input software Copyright (C) 1997-2008. Tegic Communications, Inc. All rights reserved.



Includes RSA BSAFE cryptographic or security protocol software from RSA Security.



Java is a trademark of Sun Microsystems, Inc.

This product is licensed under the MPEG-4 visual Patent Portfolio License (i) for personal and noncommercial use in connection with information which has been encoded in compliance with the MPEG-4 Visual Standard by a consumer engaged in a personal and noncommercial activity and (ii) for use in connection with MPEG-4 video provided by a licensed video provider. No license is granted or shall be implied for any other use. Additional information, including that related to promotional, internal, and commercial uses, may be obtained from MPEG LA, LLC. See <http://www.mpegl4.com>.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility for end-user support, functionality of the applications, or the information in the applications or these materials. Nokia does not provide any warranty for the third-party applications.

BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

Export controls

This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

FCC/INDUSTRY CANADA NOTICE

Your device may cause TV or radio interference (for example, when using a telephone in close proximity to receiving equipment). The FCC or Industry Canada can require you to stop using your telephone if such interference cannot be eliminated. If you require assistance, contact your local service facility. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by Nokia could void the user's authority to operate this equipment.

9208298/Issue 1

Contents

SAFETY	4
1. Get started	8
2. Your phone.....	13
3. Call functions.....	17
4. Navigate the menus	20
5. AT&T Music.....	20
6. Write text.....	21
7. Messaging	22
8. YELLOWPAGES	34
9. MEdia Net	34
10. MEdia Mall	41
11. My Stuff	41
12. Address Book.....	56
13. Settings.....	60
14. PC connectivity	71
15. Battery and charger information	72
Index	80

S A F E T Y

SAFETY

Read these simple guidelines. Not following them may be dangerous or illegal.
Read the complete user guide for further information.



SWITCH ON SAFELY

Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.



ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.



SWITCH OFF IN RESTRICTED AREAS

Follow any restrictions. Switch the device off in aircraft, near medical equipment, fuel, chemicals, or blasting areas.



QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



ENHANCEMENTS AND BATTERIES

Use only approved enhancements and batteries. Do not connect incompatible products.



WATER-RESISTANCE

Your device is not water-resistant. Keep it dry.

General information

■ About your device

The wireless device described in this guide is approved for use on the UMTS 850 and 1900, and GSM 1800 and 1900 MHz networks. Contact your service provider for more information about networks.

When using the features in this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights.

Copyright protection may prevent some images, music, and other content from being copied, modified, or transferred.

Your device may have preinstalled bookmarks and links for third-party internet sites. You may also access other third-party sites through your device. Third-party sites are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you choose to access such sites, you should take precautions for security of content.



Warning: To use any features in this device, other than the alarm clock, the device must be switched on. Do not switch the device on when wireless device use may cause interference or danger.

Remember to make back-up copies or keep a written record of all important information stored in your device.

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.

The images in this guide may differ from your device display.

■ Network services

To use the device you must have service from a wireless service provider. Many of the features require special network features. These features are not available on all networks; other networks may require that you make specific arrangements with your service provider before you can use the network services. Using network services involves transmission

General information

of data. Check with your service provider for details about fees in your home network and when roaming on other networks. Your service provider can give you instructions and explain what charges will apply. Some networks may have limitations that affect how you can use network services. For instance, some networks may not support all language-dependent characters and services.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, these features will not appear on your device menu. Your device may also have a special configuration such as changes in menu names, menu order, and icons. Contact your service provider for more information.

■ Access codes

To set how your phone uses the access codes and security settings, select **Menu > Settings > Security > Access codes**.

- The PIN (UPIN) code, supplied with the SIM (USIM) card, helps to protect the card against unauthorized use.
- The PIN2 (UPIN2) code, supplied with some SIM (USIM) cards, is required to access certain services.
- PUK (UPUK) and PUK2 (UPUK2) codes may be supplied with the SIM (USIM) card. If you enter the PIN code incorrectly three times in succession, you are asked for the PUK code. If the codes are not supplied, contact your service provider.
- The security code helps to protect your phone against unauthorized use. You can create and change the code, and set the phone to request the code. Keep the code secret and in a safe place separate from your phone. If you forget the code and your phone is locked, your phone will require service and additional charges may apply. For more information, contact a Nokia Care point or your phone dealer.
- The call restriction password is required when using the call barring service to restrict calls to and from your phone (network service).
- To view or change the security module settings for the web browser, select **Menu > Settings > Security > Security module sett.**

■ Configuration settings service

To use some of the network services, such as mobile internet services, MMS, Nokia Xpress audio messaging, or remote internet server synchronization, your phone needs the correct configuration settings. For more information on availability, contact your network operator, service provider, nearest authorized Nokia dealer, or visit the support area on the Nokia website, www.nokia.com/support.

When you have received the settings as a configuration message, and the settings are not automatically saved and activated, *Configuration settings received* is displayed.

■ Download content

You may be able to download new content (for example, themes) to the phone (network service).

For the availability of different services and pricing, contact your service provider.

 **Important:** Use only services that you trust and that offer adequate security and protection against harmful software.

■ Assisted Global Positioning System

Your phone may have Assisted Global Positioning System (A-GPS), a positioning system that uses an assistance server and reference network to make measurements and determine location. A-GPS is dependent on your network service. Contact your provider for additional information.

A-GPS may also utilize cellular radio networks for aiding in positioning in some circumstances where standalone GPS positioning is unavailable. This feature requires network support and coverage.

A-GPS should not be used for precise location measurement, and you should never rely solely on location data from the A-GPS module.

■ Nokia support

Check www.nokia.com/support or your local Nokia website for the latest version of this guide, additional information, downloads, and services related to your Nokia product.

Get started

On the website, you can get information on the use of Nokia products and services. If you need to contact customer service, check the list of local Nokia Care contact centers at www.nokia.com/customerservice.

For maintenance services, check your nearest Nokia service center at www.nokia.com/repair.

1. Get started


■ Install SmartChip card and battery

Always switch the device off and disconnect the charger before removing the battery.

This device is intended for use with BP-6MT battery. Always use original Nokia batteries. See "Nokia battery authentication" on page 75.

The SmartChip card and its contacts can easily be damaged by scratches or bending, so be careful when handling, inserting, or removing the card.

To remove the back cover of the phone, slide the release button back (1) pull the back cover up (2) and push the cover forward (3).




Remove the battery as shown.



Get started

Insert the SmartChip card properly into the holder.



Replace the battery. To replace the back cover, align the tabs on the cover to the slots on the back of the phone (1). Push the cover into place as shown (2).


■ Insert a microSD card

Use only compatible microSD cards with this device. Other memory cards, such as reduced size MultiMedia cards, do not fit in the microSD card slot and are not compatible with this device. Using an incompatible memory card may damage the memory card as well as the device, and data stored on the incompatible card may be corrupted.

Use only microSD cards approved by Nokia for use with this device. Nokia utilizes the approved industry standards for memory cards but not all other brands may function correctly or be fully compatible with this device.

Get started

1. Remove the back cover and the battery. Push the memory card holder forward (1) and swing card holder up (2).
2. Insert the card into the memory card holder with the gold-colored contact area facing down (3).
3. Close the card holder (3 and 4) and slide the card holder back in place (5). Replace the battery and back cover.



Memory card

Keep all memory cards out of the reach of small children.


You can use the microSD memory card to store your multimedia files such as video clips, music tracks, and sound files, images, and messaging data, and to back up information from phone memory.

Some of the folders in *Tones & Graphics* with content that the phone use, for example, Themes, may be stored on a memory card.

■ Charge the battery

Your battery has been precharged, but the charging levels may vary.

1. Connect the charger to a wall socket.
2. Connect the charger to your phone.
3. When the battery is fully charged, disconnect the charger from the device, then from the wall outlet.



Get started

You may also charge the battery with a USB cable with power from a computer.

1. Connect the USB cable to the USB port of a computer and to your device.
2. When the battery is full, disconnect the USB cable.

If the battery is completely discharged, it may take a few minutes before the charging indicator appears on the display or before any calls can be made.

The charging time depends on the charger used. Charging the BP-6MT battery with the AC-6 charger takes approximately XXX while the phone is in standby mode.

 **Note:** The phone shall only be connected to products that bear the USB-IF logo or have completed the USB-IF compliance program.

■ Connect a headset

You can connect a universal 2.5 mm headset to your device. Connect the headset to the device as shown.

■ Antenna

Your device has an internal antenna located at the bottom of the phone.

Get started



Note: As with any other radio transmitting device, do not touch the antenna unnecessarily when the device is switched on. Contact with the antenna affects call quality and may cause the device to operate at a higher power level than otherwise needed. Avoiding contact with the antenna area when operating the device optimizes the antenna performance and the battery life.

■ Phone strap

Remove the back cover of the phone. Insert a thread through the eyelet. Place the thread around the post of the phone as shown in the picture. Tighten the thread. Put the back cover back in place.

2. Your phone

■ Keys and parts

FCC Draft

1 Earpiece	10
2 Display	11
3 Navi™ (scroll key)	12
4	13
5	14
6	15
7	16
8	17
9	18

Switch the phone on and off

 **Warning:** Do not switch the phone on when wireless phone use is prohibited or when it may cause interference or danger.

To switch the phone on or off, press and hold the power key. See "Keys and parts" on page 14.

If the phone asks for a PIN or a UPIN code, enter the code (displayed as ****), and select OK.

Set the time, time zone, and date

Enter the local time, select the time zone of your location in terms of the time difference with respect to Greenwich Mean Time (GMT), and enter the date. See "Set time and date" on page 62.

■ Key functions

The Navi™ key and selections keys have the following functions:

1. Navi™ key – scroll up, down, left, right, and select with the center key
2. Right selection key – connect to *Music*
3. Cellular Video – connect to Cellular Video. For more information visit wireless.att.com/3g
4. Camera and video key – connect to the camera or video
5. Left selection key – Options connects to shortcuts.
6. MEdia Net key – connect to MEdia Net's wireless internet

■ Standby mode

When the phone is ready for use, and you have not entered any characters, the phone is in the standby mode.

Y o u r p h o n e

Main display

- 1 Network mode indicator
- 2 Signal strength of the cellular network
- 3 Battery charge status
- 4 Indicators
- 5 Network name or the operator logo
- 6 Clock
- 7 Main display
- 8 The left selection key
- 9 The middle selection key
- 10 The right selection key

Indicators

-  You have unread messages.
-  You have new voice mail..
-  You have unsent, canceled or failed messages.
-  The phone registered a missed call.
-  Your phone is connected to the instant messaging service, and the availability status is online or offline.
-  You received one or several instant messages.
-  The keypad is locked.
-  The phone does not ring for an incoming call or text message.
-  The alarm clock is activated.
-  The countdown timer is running.
-  The stopwatch is running.
-  The phone is registered to the GPRS or EGPRS network.
-  A GPRS or EGPRS connection is established.

Y o u r p h o n e

- ❑ The GPRS or EGPRS connection is suspended (on hold).
- ❑ A Bluetooth connection is active.
- ❑, ● Push-to-talk connection is active or suspended.
- ❑ If you have two phone lines, the second phone line is selected.
- ❑ All incoming calls are forwarded to another number.
- ❑ The loudspeaker is activated, or the music stand is connected to the phone.
- ❑ Calls are limited to a closed user group.
- ❑ The timed profile is selected.
- ❑, ☎, ☎, or ☎ A headset, handsfree, loopset, or music stand enhancement is connected to the phone.

■ Keypad lock (keyguard)

Select Menu or Unlock, and press * within 1.5 seconds to lock or unlock the keypad.

To set the automatic keyguard on with a time delay, select *Menu > Settings > Phone settings > Automatic keyguard*.

To answer a call when the keyguard is on, press the call key or open the phone. When you end or reject the call, the keypad automatically locks.

Security keyguard

The security keyguard requires a 5 to 10 digit code to protect against unauthorized use. To change the code and activate the security keyguard, select *Menu > Settings > Phone settings > Security keyguard*.

When the security keyguard is activated, enter the security code if requested.

For more information, see *Security keyguard*, in "Phone settings" on page 69.

Call functions

When the automatic or security keyguard is on, calls still may be possible to the official emergency number programmed into your device.

Offline profile



Important: In the offline profile you cannot make or receive any calls, or use other features that require cellular network coverage. Calls may still be possible to the official emergency number programmed into your device. To make calls, you must first activate the phone function by changing profiles. If the device has been locked, enter the lock code.

To activate the Offline profile, press the power key, and select *Offline*. When the Offline profile is active, the connection to the cellular network is turned off. You can listen to music using the music player when the Offline profile is active. Remember to switch off your device when wireless phone use is prohibited.

To leave the Offline profile, press the power key, and select another profile.

■ Functions without a SmartChip card

Several functions of your phone may be used without installing a SmartChip card (for example, the data transfer with a compatible PC or another compatible device). Without a SmartChip card, some functions appear dimmed in the menus and cannot be used.

For an emergency call, some networks may require that a valid SmartChip card is properly inserted in the device.

3. Call functions

■ Make a voice call

1. Enter the phone number, including the area code.

For international calls, press * twice for the international prefix (the + character replaces the international access code), enter the country code, the area code without the leading 0, if necessary, and the phone number.

2. To call the number, press the call key.

Call functions

To increase the volume in a call, press the volume up key and to decrease press the volume down key.

3. To end the call or to cancel the call attempt, press the end key.

To search for a name or phone number that you have saved in *Address book*, see "Find a contact" on page 57. Press the call key to call the number.

To access the list of dialed numbers, press the call key once in the standby mode. To call the number, select a number or name, and press the call key.

Speed dialing

Assign a phone number to one of the speed-dialing keys, 2 to 9. See "Speed dial list" on page 60. Call the number in either of the following ways:

- Press a speed-dialing key, then the call key.
- If *Speed dialing* is set to *On*, press and hold a speed-dialing key until the call begins. See *Speed dialing* in "Call settings" on page 68.

Enhanced voice dialing

You can say the name saved in the contact list of the phone to make a phone call. Voice commands are not language-dependent. To set the language, see *Voice playback lang.* in "Phone settings" on page 69.



Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely solely upon voice dialing in all circumstances.

1. In the standby mode, press and hold the right selection key or press and hold the volume down key. A short tone is played, and *Speak now* is displayed.
2. Say the voice command clearly. If the voice recognition was successful, a list with matches is shown. The phone plays the voice command of the match on the top of the list. If the result is not the correct one, scroll to another entry.

Call functions

Using voice commands to carry out a selected phone function is similar to voice dialing. See *Voice commands* in "My shortcuts" on page 63.

■ Answer or end a call

To answer an incoming call, press the call key, or open the phone. To end the call, press the end key or close the phone.

To reject an incoming call, press the end key or close the phone. To reject an incoming call when the phone is closed, press and hold a volume key.

To mute the ringing tone, press a volume key when the phone is closed, or select *Silence* when the phone is open.

Call waiting

To answer the waiting call during an active call, select *Answer*. The first call is put on hold. To end the active call, press the end key. To switch back to the first call without ending the second call, select *Options > Swap*.

To activate the call waiting function, see "Call settings" on page 68.

■ Options during a voice call

Many of the options that you can use during a call are network services. For availability, contact your service provider.

During a call, select *Options* and from the following:

Call options are *Mute* or *Unmute*, *Address book*, *Menu*, *Lock keypad*, *Record*, *Loudspeaker* or *Handset*.

Network services options are *Answer* or *Reject*, *Hold* or *Unhold*, *PTT*, *Contacts*, *New call*, *Add to conference*, *End call*, *End all calls*, and the following:

Touch tones – to send tone strings

Swap – to switch between the active call and the call on hold

Transfer – to connect a call on hold to an active call and disconnect yourself

Conference – to make a conference call of up to five persons

Private call – to discuss privately in a conference call

N a v i g a t e t h e m e n u s



Warning: Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

4. Navigate the menus

The phone offers you an extensive range of functions, which are grouped into menus.

1. To access the menu, select **Menu**.

To change the menu view, select **Options > Main menu view > Grid, Grid with labels, or Tab**.

To rearrange the menu, scroll to the menu you want to move, and select **Options > Organize > Move**. Scroll to where you want to move the menu, and select **OK**. To save the change, select **Done > Yes**.

2. Scroll through the menu, and select an option (for example, *Settings*).
3. If the selected menu contains further submenus, select the one you want (for example, *Call*).
4. If the selected menu contains further submenus, repeat step 3.
5. Select the setting of your choice.
6. To return to the previous menu level, select **Back**. To exit the menu, select **Exit**.

5. AT&T Music

This menu provides access to the music player, various music-related tools, applications, and services.

To open the music player from the standby mode, select **Menu > AT&T Music > Music player**, or press the right selection key.

See "Music player" on page 46 for more information on using the music player.

6. Write text

You can enter text (for example, when writing messages) using traditional or predictive text input. When you write text, text input indicators appear at the top of the display.  indicates traditional text input.  indicates predictive text input. Predictive text input allows you to write text quickly using the phone keypad and a built-in dictionary. You can enter a letter with a single keypress.  indicates predictive text input with *Word suggestions*. The phone predicts and completes the word before you enter all the characters.

 **Abc**, **abc**, or **ABC** appears next to the text input indicator, indicating the character case. To change the character case, press #.

 **123** indicates number mode. To change from the letter to number mode, press and hold #, and select *Number mode*.

To set the writing language while writing text, select **Options > Writing language**.

■ Predictive text input

To set predictive text input on while writing a message, select **Options > Prediction options > Prediction on**.

 **Tip:** To quickly set predictive text input on or off or switch to number mode when writing text, press # twice, or select and hold **Options**.

To select the prediction input type, select **Options > Prediction options > Prediction type > Normal** or *Word suggestions*.

1. Start writing a word using the 2 to 9 keys. Press each key only once for one letter. The entered letters are displayed underlined.

If you selected *Word suggestions* as prediction type, the phone starts to predict the word you are writing. After you enter a few letters, and if these entered letters are not a word, the phone tries to predict longer words. Only the entered letters are displayed underlined.

To insert a special character, press and hold *, or select **Options > Insert symbol**. Scroll to a character, and select **Use**.

Messaging

To write compound words, enter the first part of the word; to confirm it, press the scroll key right. Write the next part of the word and confirm the word.

To enter a full stop, press 1.

2. When you finish writing the word and it is correct, to confirm it, press 0 to add space.

If the word is not correct, press * repeatedly, or select Options > *Matches*. When the word that you want appears, select the word.

If the ? character is displayed after the word, the word you intended to write is not in the dictionary. To add the word to the dictionary, select Spell. Complete the word (traditional text input is used), and select Save.

■ Traditional text input

To set traditional text input on, select Options > *Prediction options* > *Prediction > Off*.

Press a number key, 1 to 9, repeatedly until the desired character appears. Not all characters available under a number key are printed on the key. The characters available depend on the selected writing language.

If the next letter you want is located on the same key as the present one, wait until the cursor appears.

The most common punctuation marks and special characters are available under the 1 key. For more characters, press *.

7. Messaging

You can read, write, send and save text and multimedia messages, e-mail, audio and flash messages. The messaging services can only be used if they are supported by your network or service provider.

When sending messages, your phone may display the words *Message sent*. This is an indication that the message has been sent by your device to the message center number programmed into your device. This is not an indication that the message has been received at the intended

Messaging

destination. For more details about messaging services, check with your service provider.

■ Text and multimedia messages

You can create a message and optionally attach, for example, a picture. Your phone automatically changes a text message to a multimedia message when a file is attached.

■ Text messages

Your device supports the sending of text messages beyond the character limit for a single message. Longer messages are sent as a series of two or more messages. Your service provider may charge accordingly. Characters that use accents or other marks and characters from some language options, such as Spanish, take up more space, which limits the number of characters that can be sent in a single message.

An indicator at the top of the display shows the total number of characters left and the number of messages needed for sending.

Before you can send any text or e-mail messages, you need to save your message center number. Select *Menu > Messaging > Messaging settings > Text > Message centers > Add center*, enter a name, and the number from the service provider.

■ Multimedia messages

A multimedia message can contain text, pictures, and sound or video clips.

Only devices that have compatible features can receive and display multimedia messages. The appearance of a message may vary depending on the receiving device.

The wireless network may limit the size of MMS messages. If the inserted picture exceeds this limit the device may make it smaller so that it can be sent by MMS.

 **Important:** Exercise caution when opening messages. E-mail messages may contain malicious software or otherwise be harmful to your device or PC.

For availability and subscription to the multimedia service (MMS), contact your service provider.

Messaging

Create a text or multimedia message

1. Select Menu > Messaging > New message > Message.
2. To add recipients, scroll to the *To:* field, and enter the recipient's number or e-mail address, or select **Add** to select recipients from the available options. Select **Options** to add recipients and subjects and to set sending options.
3. Scroll to the *Text:* field, and enter the message text.
4. To attach content to the message, scroll to the attachment bar at the bottom of the display and select the desired type of content.
5. To send the message, press **Send**.

The message type is indicated at the top of the display and changes automatically depending on the content of the message.

Service providers may charge differently depending on the message type. Check with your service provider for details.

Read a message and reply

 **Important:** Exercise caution when opening messages. Messages may contain malicious software or otherwise be harmful to your device or PC.

Your phone issues a notification when you receive a message. Select **View** to display the message. If more than one message was received, to display a message, select the message from the **Inbox** and **Open**.

To create an answer message, select **Reply**.

Send messages

To send the message, select **Send**. The phone saves the message in the **Outbox** folder and sending starts.

 **Note:** The message sent icon or text on your device screen does not indicate that the message is received at the intended destination.

If the message sending is interrupted, the phone tries to resend the message a few times. If these attempts fail the message remains in the **Outbox** folder. To cancel the sending of the messages in the **Outbox** folder, select **Options > Cancel sending**.

Messaging

To save the sent messages in the *Sent items* folder, select **Menu > Messaging > Message settings > General settings > Save sent messages**.

Organize your messages

The phone saves received messages in the **Inbox** folder. Organize your messages in the **saved items** folder.

To add, rename, or delete a folder select **Menu > Messaging > Saved items > Options**.

■ SmartChip messages

SmartChip messages are text messages that are saved to your SmartChip card. You can copy or move those messages to the phone memory, but not vice versa. Received messages are saved to the phone memory.

To read SmartChip messages, select **Menu > Messaging > Options > SmartChip messages**.

■ Instant messaging

Instant messaging (IM) is a way to send short, simple text messages to friends and family, regardless of the mobile system or platform they use (like the internet), as long as they all use the same IM service. Check with your service provider for availability.

Before you can use IM, you must subscribe to the service. To check the availability and costs and to subscribe to the service, contact your wireless service provider and the IM service provider from whom you receive your unique ID, password, and settings.



Note: Depending on both your IM service provider and your wireless service provider, you may not have access to all of the features described in this guide.

Depending on the network, the active IM conversation may consume the phone battery faster, and you may need to connect the phone to a charger.

Register with an IM service

Before you can use IM, you must register with an IM service to obtain a user name and password. You can obtain a user name and password by

Messaging

registering over the internet (using your computer) with the IM service provider you have selected. During the registration process, you will have the opportunity to create the user name and password of your choice. For more information about signing up for IM services, contact your wireless service provider.

Log in

1. Select **Menu > Messaging > IM >** and the service you want to log into.

You must select the IM service every time you log in.

2. Enter your screen name and password if they are not already displayed.
3. Select **Options > Sign In.**

Depending on your IM service, you may not need to enter your user name and password manually every time you log in.

You can choose to save your password so you do not have to enter it each time you sign in, or you can choose to log in automatically and skip the log in window when you select the IM application. Scroll to **Save password** or **Automatic sign-in** and select **Mark**.

Icons and menu items

Each IM service provider has its own unique interface, so the IM menu items, display text, and icons on your phone may appear differently for each IM service. If you have questions about the differences in the various IM service providers' text and icons, contact your wireless service provider for more information.

IM menus

When you select IM from your phone menu, a list of available IM services is displayed. Select the desired IM service to access the offline menu options: Sign On, Saved Conversations, and Network settings.

Depending on the IM service provider you are using, these may not be the exact menu items displayed.

After you log into IM, the following IM online options appear: Conversations, Online contacts, and Offline contacts. Depending on the

Messaging

IM service provider you are using, these may not be the exact menu items displayed.

Begin an IM session

You can send instant messages to anyone if you have the person's user name and you use the same IM service. As the conversation progresses, the most recent message appears at the bottom of the window, causing the previous messages to move up one level (some IM services may do this in the opposite direction).

If you want to chat with a person, you must first add that person to online contacts. See "Contacts" on page 30.

To begin an IM session, do the following:

1. From the IM online menu, select a contact who is online.
2. A conversation window is opened, and the contact's name is displayed at the top.
3. Enter a message. When you finish the message, select OK.

Receive and reply to messages

If you have an active chat open and receive an instant message from the contact or group member with whom you are chatting, the new message is displayed on the conversation window in the sequence in which they are received. Select *Write to reply*.

If you receive an instant message when you have the IM application open, but do not have an active chat open, a message appears showing you have a new instant message with the name of the sender. Select *Open* to open the conversation window with that contact's new message displayed. To reply, select *Write*, enter a message, and select *OK*.

If you receive an instant message when you are logged in to the IM service, but do not have the IM application open on your phone, a message is displayed telling you that a new IM message has been received. Select *Start* to open the IM application, and view the new message.

Messaging

Return to chat session

From the IM online menu, select *Conversations*. This list displays all IM conversations and group chats in which you are currently participating. To view a conversation or continue chatting, select a group name or contact name.

Use detail from a chat

If a contact sends you a phone number or URL in a chat session, you can call that phone number or connect to the URL.

From the chat session, select **Menu > Use Detail**. A list of phone numbers or URLs from the chat session is displayed. Select the desired item.

If you select a URL, the IM application closes and the web browser starts. To log back into the IM application, select **Menu > Messaging > IM**. The IM application opens, and you can see your conversations and contacts.

Chat session options

You can save, view, rename, or delete a chat session.

To save a chat session, while you have the conversation open, select **Menu > Save**, edit the name if desired, and select **OK**.

To view a saved chat session, from the IM online menu, select **Menu > Saved conversations**. Scroll to the desired conversation name, and select **Open**.

To rename a saved chat session, from the IM online menu, select **Menu > Saved conversations**. Scroll to the desired conversation name, and select **Menu > Rename**. Rename the conversation, and select **OK**.

To delete a saved chat session, from the IM online menu, select **Menu > Saved conversations**. Scroll to the desired conversation name, and select **Menu > Delete > OK**.

Set your availability

You can determine if other users can tell whether you are available or not. From the IM online menu, highlight your name at the top of the window, and select **Menu > My Status > Available, Invisible, or Busy**.

Messaging

Contacts

You can add the names of contacts with whom you interact frequently by IM to the contacts list.

To add a new contact during an IM session, select **Menu > Add Contact > OK**. Enter a nickname and select **OK**.

To add a new contact from the IM online menu, select **Menu > Add Contact**. Enter the contact's user name for the IM service, and select **OK**. Enter a nickname for the contact, and select **OK**.

To remove a contact from the IM online menu, select **Online contacts** or **Offline contacts**. Scroll to the contact you wish to remove, and select **Menu > Delete contact > OK**.

Log off service

From the IM online window, you can exit the IM application, but still be connected to the IM service. Select **Back** until the IM online window appears; then select **Exit**. If you open IM again, you do not need to log in again.

You can receive instant messages and chat invitations from your contacts when using your phone for other purposes, such as playing a game. If you are connected to your IM service, but you have not used your IM application for some time, you may be automatically disconnected from the IM service. The next time you open the IM application, you must log in again.

To disconnect from the IM service, you must log out from the online window.

You are taken to the IM service provider list, where you can exit the IM application or select an IM service and log in again.

From the IM online screen, select **Sign Out > OK**.

■ E-mail

The actual terms and words seen when sending, replying, forwarding, or saving e-mail may be dependent on your e-mail service provider.

Messaging



Important: Exercise caution when opening messages. E-mail messages may contain malicious software or otherwise be harmful to your device or PC.

E-mail provides access to certain common e-mail services. If you have an e-mail account with one of the supported e-mail services, you can use this application to access your e-mail account. With this application you can view your inbox, compose and send e-mail, receive e-mail, receive notification of new e-mail, and delete e-mail. This e-mail application is different from the SMS and MMS e-mail function.

If you do not have an e-mail account already, visit the website of one of the e-mail service providers and register for an e-mail account. If you have questions regarding the cost of e-mail service, contact your wireless service provider.

Start e-mail

1. Select *Menu > Messaging > E-mail*.
2. Highlight and select the provider with which you have an e-mail account. Alternatively, you can select *Options > Add account* and the appropriate provider from the list.
3. Read and accept the terms of use, if you are presented with any.
4. Enter your user ID and password. Note that the password is case sensitive.
5. If you wish to have your login information remembered, highlight the checkbox option, and select *Mark*.
6. Select *Options > Save*.

After the account is successfully validated, it appears on the list.

If you select to have your login information remembered, when you next select that account, the first page of your e-mail inbox view is automatically loaded. If the login information has not been remembered, you must login to start using your e-mail account.

View the inbox and other folders

The inbox view loads the first page of the inbox by default. Scroll up or down in the inbox.

Messaging

To navigate from the inbox to another folder, scroll right or left. This switches the tab view from the current folder to the next folder. Scroll to the desired folder. Stop at the desired folder and the first page of that folder loads automatically. When folder content is loaded, it is not updated again until you select *Options > Refresh folder*.

To view an e-mail, select the e-mail. When you highlight a particular e-mail, you see an expanded view with more details about the e-mail.

Write and send

1. To start writing an e-mail from the inbox view, select *Options > Compose New*.
2. Enter the recipient's e-mail address, a subject, and the e-mail message.
3. Select *Send* to send the e-mail.

Reply and forward

1. When viewing an e-mail, select *Options > Reply, Reply to all, or Forward*. The e-mail view loads with the appropriate fields completed.
2. Enter the remaining information.
3. Select *Send* to send the e-mail.

Delete

To delete an e-mail from the inbox view, select *Options > Delete*. To mark multiple e-mail to be deleted, select *Options > Mark for deletion*. To delete marked e-mail, select *Options > Delete marked*.

To delete an e-mail you are viewing, select *Delete*.

Preferences

From the inbox view, select *Options > Preferences* to set the following preferences:

Folder display – to view e-mails in the inbox view by their address or subject.

Delete Confirmation – to be prompted with a delete confirmation or not

Messaging

Message AutoExpand – to automatically expand the e-mail message in the inbox view when it is highlighted

Highlight and select your desired preferences. To apply your preference changes, select **Options > Save**. These preferences are applied to all of your e-mail accounts.


E-mail alerts

To set e-mail alerts on or off from the inbox view, select **Options > E-mail Alerts**. If e-mail alerts are enabled, you get notifications of new e-mails. This setting only applies to the current e-mail account, and does not affect the notification settings of other e-mail accounts.

■ Voice mail

If you subscribe to voice mail (network service), your service provider furnishes you with a voice mailbox number. The number may be populated in your phone during the activation process. If not, you need to save this number to your phone to use voice mail. When you receive a voice message, your phone lets you know by beeping, displaying a message, or both. If you receive more than one message, your phone shows the number of messages received.

To call your voice mailbox, in the standby mode, press and hold 1, or select **Menu > Messaging > Voice mail > Listen to voice mails**. To enter, find, or edit your voice mailbox number, select *Voice mailbox number*.

If supported by the network,  indicates new voice messages. Select *Listen* to call your voice mailbox number.

■ Service commands

Use the service commands editor to enter and send service requests (also known as USSD commands) to your service provider. Contact your service provider for information about specific service commands.

Select **Menu > Messaging > Serv. commands**.

■ Delete messages

To delete messages one by one, select **Menu > Messaging > Delete messages > By message** and the folder from which you want to delete messages. Scroll to the message you want to delete, and select **Delete**.

Messaging

To delete more than one message at the same time, scroll to one of the messages you want to delete, and select **Options > Mark**. Scroll to each additional message you want to delete, and select **Mark**; or to delete all the messages, select **Options > Mark all**. When you have finished marking the messages you want to delete, select **Options > Delete marked**.

To delete all messages from a folder, select **Menu > Messaging > Delete messages > By folder** and the folder from which you want to delete the messages. Depending on the folder, the phone asks if you want to delete the messages. To delete, select **Yes**. Otherwise, if the folder contains unread messages or messages that are waiting to be sent, the phone asks whether you want to keep them. To keep these messages, select **Yes**.

To delete all messages from all folders, select **Menu > Messaging > Delete messages > All messages > Yes**.

■ Message settings

Select **Select Menu > Messaging > Message settings** and from the following:

General settings – to save copies of sent messages in your phone, to overwrite old messages if the message memory becomes full and to set up other preferences related to messages.

Text messages – to allow delivery reports, to set up message centers for SMS and SMS e-mail, to select the type of character support, and to set up other preferences related to text messages.

Multimedia messages – to allow delivery reports, to set up the appearance of multimedia messages, to allow the reception of multimedia messages and advertisements, and to set up other preferences related to multimedia.

Service messages – to activate service messages and to set up preferences related to service messages,

Y E L L O W P A G E S

8. Y E L L O W P A G E S

In the standby mode, to access to the AT&T Y E L L O W P A G E S website, select **Menu > Y E L L O W P A G E S**. Y E L L O W P A G E S provides a directory of local and national businesses, search options, maps, and directions.

If you have questions about billing or accessing this website, contact your service provider.

9. M E d i a N e t

You can access various mobile internet services with your phone browser.



Important: Use only services that you trust and that offer adequate security and protection against harmful software.

Check the availability of these services, pricing, and instructions with your service provider.

With the phone browser you can view the services that use wireless markup language (WML) or extensible hypertext markup language (XHTML) on their pages. Appearance may vary due to screen size. You may not be able to view all details of the internet pages.

■ Set up browsing

You may receive the configuration settings required for browsing as a configuration message from the service provider that offers the service you want to use. See "Configuration settings service" on page 8. You can also enter all the configuration settings manually. See "Configuration" on page 70.

■ Connect to a service

Ensure that the correct configuration settings of the service are activated.

1. To select the settings for connecting to the service, select **Menu > M E d i a N e t > Settings > Configuration sett.**

Media Net

2. Select *Configuration*. Only the configurations that support browsing service are shown. Select a service provider or *Default* for browsing. See "Set up browsing" on page 35.
3. Select *Account* and a browsing service account contained in the active configuration settings.
4. Select *Displ. term. window* > *Yes* to perform manual user authentication for intranet connections.

Make a connection to the service in one of the following ways:

- Select **Menu** > *Media Net*. In the standby mode, press and hold 0, or press the **Media Net** key under the left selection key. See "Key functions" on page 15.
- To select a bookmark of the service, select **Menu** > *Media Net* > *Bookmarks*.
- To select the last URL, select **Menu** > *Media Net* > *Last MNet addr*.
- To enter the address of the service, select **Menu** > *Media Net* > *Go to*. Enter the address of the service, and select **OK**.

■ Browse pages

After you make a connection to the service, you can start browsing its pages. The function of the phone keys may vary in different services. Follow the text guides on the phone display. For more information, contact your service provider.

Browse with phone keys

To browse through the page, scroll in any direction.

To select an item, press the call key, or select **Select**.

To enter letters and numbers, press the 0 to 9 keys. To enter special characters, press *.

Direct calling

While browsing, you can make a phone call, and save a name and a phone number from a page.

■ Bookmarks

You can save page addresses as bookmarks in the phone memory.

1. In the standby mode, select **Menu** > *MEdia Net*, or select the **MEdia Net** key to connect to the web. While browsing, select **Options** > *Add bookmark*.
2. Select **Menu** > *MEdia Net* > *Bookmarks* to view a list of saved bookmarks.
3. Scroll to a bookmark, and select it, or press the call key to make a connection to the page associated with the bookmark.
4. Select **Options** to view, edit, delete, or send the bookmark; to create a new bookmark; or to save the bookmark to a folder.

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with, or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility for end-user support, functionality of the application, or the information in the applications or these materials. Nokia does not provide any warranty for the third-party applications.

BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

Receive a bookmark

When you have received a bookmark that is sent as a bookmark, *1 bookmark received* is displayed. To view the bookmark, select **Show**.

■ Appearance settings

While browsing, select **Options** > *Other options* > *Appearance settings* and from the following options:

Text wrapping – Some websites may not automatically wrap text. Select *On* to allow text to wrap to the next line for viewing entire headings.

Font size – to set the font size

Show images > No – to hide images on the page

Alerts > Alert for unsec. conn. > Yes – to set the phone to alert when a secure connection changes to an unsecure one during browsing

Alerts > Alert for unsec. items > Yes – to set the phone to alert when a secure page contains an unsecure item. These alerts do not guarantee a secure connection. For more information, see "Browser security" on page 40.

Character encoding > Content encoding – to select the encoding for the browser page content

Character encoding > Unicode (UTF-8) addr. > On – to set the phone to send a URL as a UTF-8 encoding

Screen size > Full or Small – to set the screen layout

Show page title – to show the page title of a web address

JavaScript > Enable – to enable the JavaScripts

■ Security settings

Cookies

A cookie is data that a site saves in the cache memory of your phone. Cookies are saved until you clear the cache memory. See "Cache memory" on page 40.

While browsing, select **Options > Other options > Security > Cookie settings**; or in the standby mode, select **Menu > MEdia Net > Settings > Security settings > Cookies**. To allow or prevent the phone from receiving cookies, select **Allow** or **Reject**.

Scripts over secure connection

You can select whether to allow the running of scripts from a secure page. The phone supports WML scripts.

While browsing, to allow the scripts, select **Options > Other options > Security > WMLScript settings**; or in the standby mode, select **Menu > MEdia Net > Settings > Security settings > WMLScripts in conn. > Allow**.

■ Download settings

To automatically save all downloaded files in *Tones & Graphics*, select Menu > *MEdia Net* > *Settings* > *Downloading sett.* > *Automatic saving* > *On*

■ Service inbox

The phone is able to receive service messages sent by your service provider (network service). Service messages are notifications (for example, news headlines), and they may contain a text message or an address of a service.

To access the service inbox in the standby mode, when you have received a service message, select *Show*. If you select *Exit*, the message is moved to the service inbox. To access the service inbox later, select Menu > *MEdia Net* > *Service inbox*.

To access the service inbox while browsing, select *Options* > *Other options* > *Service inbox*. Scroll to the message you want, and to activate the browser and download the marked content, select *Retrieve*. To display detailed information on the service notification or to delete the message, select *Options* > *Details* or *Delete*.

Service inbox settings

Select Menu > *MEdia Net* > *Settings* > *Service inbox sett.*

To set whether you want to receive service messages, select *Service messages* > *On* or *Off*.

To set the phone to receive service messages only from content authors approved by the service provider, select *Message filter* > *On*. To view the list of the approved content authors, select *Trusted channels*.

To set the phone to automatically activate the browser from the standby mode when the phone has received a service message, select *Autom. connection* > *On*. If you select *Off*, the phone activates the browser only after you select *Retrieve* when the phone has received a service message.

■ Cache memory

A cache is a memory location that is used to store data temporarily. If you have tried to access or have accessed confidential information requiring passwords, empty the cache after each use. The information or services you have accessed is stored in the cache.

To empty the cache while browsing, select **Options > Other options > Clear the cache**; in the standby mode, select **Menu > MEdia Net > Clear the cache**.

■ Browser security

Security features may be required for some services, such as online banking or shopping. For such connections you need security certificates and possibly a security module, which may be available on your SmartChip card. For more information, contact your service provider.

Security module

The security module improves security services for applications requiring a browser connection, and allows you to use a digital signature. The security module may contain certificates as well as private and public keys. The certificates are saved in the security module by the service provider.

To view or change the security module settings, select **Menu > Settings > Security > Security module sett.**

Certificates



Important: Even if the use of certificates makes the risks involved in remote connections and software installation considerably smaller, they must be used correctly in order to benefit from increased security. The existence of a certificate does not offer any protection by itself; the certificate manager must contain correct, authentic, or trusted certificates for increased security to be available. Certificates have a restricted lifetime. If Expired certificate or Certificate not valid yet is shown even if the certificate should be valid, check that the current date and time in your device are correct. Before changing any certificate settings, you must make sure that you really trust the owner of the certificate and that the certificate really belongs to the listed owner.

There are three kinds of certificates: server certificates, authority certificates, and user certificates. You may receive these certificates from your service provider. Authority certificates and user certificates may also be saved in the security module by the service provider.

To view the list of the authority or user certificates downloaded into your phone, select **Menu > Settings > Security > Authority certificates** or **User certificates**.

 is displayed during a connection, if the data transmission between the phone and the content server is encrypted.

The security icon does not indicate that the data transmission between the gateway and the content server (or place where the requested resource is stored) is secure. The service provider secures the data transmission between the gateway and the content server.

Digital signature

You can make digital signatures with your phone, if your SmartChip card has a security module. Using the digital signature can be the same as signing your name to a paper bill, contract, or other document.

To make a digital signature, select a link on a page, for example, the title of the book you want to buy and its price. The text to sign, which may include the amount and date, is shown.

Check that the header text is *Read* and that the digital signature icon  is shown.

If the digital signature icon does not appear, there is a security breach, and you should not enter any personal data such as your signing PIN.

To sign the text, read all of the text first, and select **Sign**.

The text may not fit within a single screen. Therefore, make sure to scroll through and read all of the text before signing.

Select the user certificate you want to use. Enter the signing PIN. The digital signature icon disappears, and the service may display a confirmation of your purchase.

10. MEdia Mall

From the standby mode, select **Menu > MEdia Mall** to access to the AT&T Mall website. The MEdia Mall provides links to a variety of content such as tones, games, graphics, multimedia, and applications that may be purchased and downloaded to your phone.

If you have questions about billing or about accessing this website, please contact your service provider.

11. My Stuff

In this menu, you can manage graphics, images, recordings, and tones, which are files arranged in folders. This menu also includes multimedia and entertainment features available in the phone, and features that assist you in organizing daily tasks.

Your phone supports an activation key system to protect acquired content. Always check the delivery terms of any content and activation key before acquiring them, as they may be subject to a fee.

■ Tones & Graphics

In the standby mode, select **Menu > My Stuff > Tones & Graphics** to manage images, video clips, music files, themes, graphics, tones, audio, and received files. These files are stored in the phone memory or an attached microSD memory card and may be arranged in folders.

The files stored in tones and graphics use the memory capacity of the phone. You can use a compatible memory card to extend the memory capacity to store images, themes, graphics, ringing tones, video clips, and audio clips in tones and graphics.

To manage the files and folders, do the following:

1. Select **Menu > My Stuff > Tones & Graphics**. A list of folders is shown. If a memory card is inserted in the phone, *Memory card (unformat.)* or the name of the memory card is shown.
2. Scroll to the folder you want. To view a list of files in the folder, select **Open**. For the available options, select **Options**.

My Stuff

3. Scroll to the file you want to view, and select **Open**. For the available options, select **Options**.

Format memory card

To format a new memory card, select **Menu > My Stuff > Tones & Graphics**. Scroll to the memory card folder and select **Options > Format mem. card**. See "Memory card" on page 11.

■ Games & Apps.

In the standby mode, select **Menu > My Stuff > Games and Apps** to manage applications and games. These files are stored in the phone memory or an attached microSD memory card and may be arranged in folders.

For options to format or lock and unlock the memory card, see "Memory card" on page 11.

Launch a game

Your phone software includes some games.

Select **Menu > My Stuff > Games & Apps > Games**. Scroll to the desired game, and select **Open**.

To set sounds, lights, and shakes for the game, select **Menu > My Stuff > Games and Apps**. Scroll to **Games** and select **Options > Application settings**. For more options, see "Application options" on page 43.

Launch an application

Your phone software includes some Java applications.

Select **Menu > My Stuff > Games and Apps > Application**. Scroll to an application, and select **Open**.

Application options

Update version – to check if a new version of the application is available for download from web (network service)

Media net page – to provide further information or additional data for the application from an internet page (network service), if available

App. access – to restrict the application from accessing the network

Download an application

Your phone supports J2ME Java applications. Make sure that the application is compatible with your phone before downloading it.



Important: Only install and use applications and other software from sources that offer adequate security and protection against harmful software.

You can download new Java applications and games in different ways.

Use the Nokia Application Installer from PC Suite to download the applications to your phone, or select **Menu > My Stuff > Games & apps > Options > Downloads > App. downloads**; the list of available bookmarks is shown. See "Bookmarks" on page 37.

For the availability of different services and pricing, contact your service provider.

Your device may have preinstalled bookmarks and links for third-party internet sites. You may also access other third-party sites through your device. Third-party sites are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you choose to access such sites, you should take precautions for security or content.

■ Multimedia

From the standby mode, select **Menu > My Stuff > Multimedia** to access multimedia and entertainment features available in the phone.

Camera

When taking and using images or video clips, obey all laws and respect local customs as well as privacy and legitimate rights of others, including copyrights.

You can take photos or record live video clips with the built-in 1.3 megapixel camera.

The camera produces pictures in jpeg format and video clips in 3gpp format. The camera lens is on the front of the phone. The color display works as a viewfinder.

Take a photo

1. Select **Menu > My Stuff > Multimedia > Camera > Capture**; or press the camera key, and select **Capture**.

My Stuff

The phone saves the photo in **Menu > My Stuff > Tones & Graphics > Images** unless you set the phone to use the memory card to save photos.

2. To take another photo, select **Back**.
3. To zoom in or out, scroll up or down.
4. To take several photos in quick succession, select **Options > Image sequence on > Sequence**. To take another photo, select **Options > New image**. To take a single image, select **Options > Image sequence off**.

The higher the resolution, the fewer photos you can take sequentially.

5. To send the photo as a multimedia message, select **Send**.
6. To set a timer to delay capturing a photo for 10 seconds, select **Options > Self-timer on > Start**.

A beep sounds while the self-timer is running. It beeps faster when the camera is about to capture the photo. After the time-out, the camera takes the photo and saves the photo in **Menu > My Stuff > Tones & Graphics > Images**.

To take a photo when the lighting is dim, the camera automatically adjusts a longer exposure time so the photo quality is better.

This Nokia device supports an image capture resolution up to 1024 x 1280 pixels. The image resolution in these materials may appear different.

Self-portrait

To take a self-portrait photo, select **Menu > My Stuff > Multimedia > Camera** and close the fold. To take a picture, press the PTT key. To view the photo, open the fold.

Record a video clip

Select **Menu > My Stuff > Multimedia > Video > Record**. To pause recording, select **Pause**; to resume recording, select **Continue**. To stop recording, select **Stop**. The phone saves the recording in **Menu > My Stuff > Open Tones & Graphics > Video clips** or a folder in the memory card. To view the options, select **Options**.

My Stuff

Camera and video settings

Select Menu > My Stuff > Multimedia > Camera or Video > Options > Settings and edit the available settings.

Camera and video effects

Select Menu > My Stuff > Multimedia > Camera or Video > Options > Effects and one of the available options.

Music player

Your phone includes a music player for listening to music tracks, recordings, or MP3, MP4, WMA (Windows Media Audio), aac, aac+, or eaac+ sound files that you have transferred to the phone with the Nokia Music Manager application. Music files are automatically detected and added to the default track list.

Play music tracks

1. Select Menu > My Stuff > Multimedia > Music player > Go to Music player. The details of the first track on the default track list are shown.
2. To play a track, scroll to the track, and select .
3. To skip to the beginning of the next track, select . To skip to the beginning of the previous track, select  once.
4. To rewind the current track, select and hold . To fast forward the current track, select  and hold it. Release the key at the position you want.
5. To pause the playing, select .



Warning: Listen to music at a moderate level. Continuous exposure to high volume may damage your hearing. Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

Options in Music player

In the music player menu, music tracks can be saved in the following categories:

All songs – to view all music tracks

My Stuff

Playlists – to create new playlists, check the currently playing music, view recently added playlists or tracks, find the tracks played most often, and view all playlists

Artists – to view all music tracks by the artist's name

Albums – to view music tracks by albums

Genres – to view music tracks by genres

Videos – to view a list of music videos

Settings

To change settings, select **Menu > My Stuff > Multimedia > Music player > Go to Media player > Options > Settings** and choose from the following:

Shuffle – to play music tracks in random order

Repeat – to repeat the current song, all songs, or to turn off repeat

Equalizer – to open the list of media equalizer sets. See "Equalizer" on page 48.

Stereo widening – to enhance the audio output of the phone by enabling a wider stereo sound effect

Music player theme – to select the theme or skin of the music player

Other options

Go to Music menu – to go to the main music menu

Now playing – to view the track currently playing

Add to playlist – to add the current song to the favorites track list.

Downloads – to download music through web.

MEdia Net page – to go to MEdia Net

Mute audio – to mute the audio

Play via Bluetooth – to connect and play music through a Bluetooth enabled audio accessory using Bluetooth connection

Voice recorder

You can record pieces of speech, sound, or an active call. This is useful when recording a name and phone number for writing them down later.

My Stuff

Record sound

1. Select **Menu > My Stuff > Multimedia > Voice recorder**.
2. To start recording, select . To start recording during a call, select **Options > Record**. While recording a call, all parties to the call hear a faint beeping sound. When recording a call, hold the phone in the normal position near to your ear.
3. To stop recording, select .

The recording is saved in **Menu > My Stuff > Tones & Graphics > Audio**.

4. To listen to the latest recording, select **Options > Play last recorded**.
5. To send a recording using Bluetooth or as a multimedia message, scroll to the recording and select **Options > Send**.

List of recordings

1. Select **Menu > My Stuff > Multimedia > Voice recorder > Options > Audio list**.

The list of folders in tones and graphics is shown.

2. Open **Audio** to see the list with recordings.
3. Select **Options** to view a list of options for files.

Define a storage folder

To use a folder (other than audio) as the default folder in tones and graphics, select **Menu > My Stuff > Multimedia > Voice recorder > Options > Select memory** and a folder from the list.

Equalizer

To control the sound quality when using the music player by amplify or diminish frequency bands.

Select **Menu > My Stuff > Multimedia > Equalizer**.

To activate a set, scroll to one of the equalizer sets, and select **Activate**.

To view, edit, rename, and select your own settings, select **Set 1 or Set 2 > Options > Edit, or Rename**. Only Set 1 and Set 2 can be edited or renamed.

My Stuff

Stereo widening

Stereo widening enhances the audio output of the phone by enabling a wider stereo sound effect. To change the setting, select **Menu > My Stuff > Multimedia > Stereo**.

■ Tools

Your Nokia mobile phone has many useful features for organizing your everyday life. The following features are found in tools: alarm clock, calendar, to-do list, notes, calculator, countdown timer, and stopwatch.

Push to Talk

Select  > *Games&Apps* > *PTT*.

Push to Talk (PTT) is a two-way radio service available over a GSM cellular network (network service).

You can use PTT to have a conversation with one person or with a group of people having compatible devices and service. While you are connected to the PTT service, you can use the other functions on the phone.

To check availability and costs, and to subscribe to the service, contact your network operator. Service availability may differ from that for normal calls. Visit wireless.att.com/ptt for additional information.

Before you can use the PTT service, you must define the required PTT service settings. Select  > *Games&Apps* > *PTT* and from the following:

Set your name – to see how your PTT name appears to your contacts and groups

Auto accept – to set the phone to automatically accept invitations from other PTT users

PTT Is: On – to switch the PTT service on

Always switch PTT off before switching the phone off or removing the battery.

PTT options

Select  > *PTT* > *Games&Apps* > *PTT Contacts* > *Options* and from the following:

My availability – to set your PTT status to Available or Do Not Disturb

Voice message – to send a voice message to a contact

Call me alert – to send a notification to a contact

My Stuff

Quick group – to mark contacts to create a quick group

New message – to send a text message to a contact

Switch PTT on and off

To disconnect from the PTT service, select  > Games&Apps > PTT > PTT *Is: On* and select *Offline*

To connect to the PTT service, select  > Games&Apps > PTT. If you have added groups to the phone, you are automatically joined to the active groups. There may be a brief delay while PTT connects.

Connection indicators

These indicators appear on the standby screen below the battery indicator if active idle is turned off. When active idle is turned on, the PTT indicator is below or to the right of the active idle navigation bar.

-  PTT is connected: your status is Available
-  Service is disconnected
-  Information is waiting
-  Your status is Do Not Disturb

Add contacts

You can add individual contacts or create contact groups to call several people at once.

Add a one-to-one contact

To add a contact to the PTT contacts list, select  > Games&Apps > PTT > Add contact. Enter the name and telephone number of the new contact. An invitation is sent to the person.

Add a contact group

You can save a group of contacts so you can call them collectively.

To add a PTT contact group, select  > Games&Apps > PTT > Add group and name the group.

To add an existing contact to the group, select *From PTT contacts* and mark the contacts you want added to the new group.

To add a new contact to the group manually, enter the name and telephone number of the new contact. An invitation is sent to the person.

My Stuff

Make and receive a PTT call

 **Warning:** Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

To make a group call, a one-to-one call, or a call to multiple recipients, you must hold the PTT key as long as you talk. To listen to the response, release the PTT key. You can check the login status of your contacts in  > Games&Apps > PTT > PTT Contacts. To add a contact, select  > PTT > Add contact. See "Add a one-to-one contact" on page 50 for more information.

Contact status indicators

These indicators appear next to your contacts and provide information about their connection status.

-  Contact is available
-  Contact is available with phone set to vibrate or silent
-  Do not disturb; you cannot contact this person
-  Invitation is in progress; you cannot contact this person
-  Contact has PTT switched off; you cannot contact this person

Make a one-to-one call

To start a one-to-one call from the list of contacts to which you have added the PTT telephone number, select  > PTT > Games&Apps > PTT Contacts. Scroll to a contact, and press and hold the PTT key while talking. Remember that you must release the PTT key to receive their reply.

To start a one-to-one call from the list of PTT groups, select PTT Contacts, scroll to the desired group, and select View. Scroll to the desired contact, and press and hold the PTT key while talking.

Make a group call

To make a call to a group, select PTT Contacts in the PTT menu, scroll to the desired group, and press and hold the PTT key while talking.

My Stuff

Make a PTT call to multiple recipients

To select multiple PTT contacts from the contact list, create a Quick Group. The recipients receive an incoming call. If a recipient's phone is set to silent or vibrate, they must accept the call in order to participate.

1. Select  > *Games & Apps* > *PTT* > *PTT Contacts* and mark the desired contacts. The Quick Group is automatically created.
2. Press and hold the PTT key to start the call. The group name is shown on the display, as soon as members join the call.
3. Press and hold the PTT key to talk to them. Release the PTT key to hear the response.
4. Press the end key to terminate the call.

Receive a PTT call

A short tone notifies you of an incoming PTT call. Information, such as the group, the phone number, or the nickname of the caller are displayed.

You can either accept or reject an incoming one-to-one call if you have set the phone to silent or vibrate.

When you press and hold the PTT key while the caller is talking, you hear a queuing tone. Release the PTT key, and wait for the other person to finish; then you can press and hold the PTT key and begin talking.

Change from PTT to mobile call

You can convert a one-to-one or group PTT call to a standard mobile call if you initiated the PTT call. Anytime during the PTT call select **Options** > *Convert to Cellular*. The call recipient(s) can then join your mobile call by pressing the PTT key.

Call Me Alerts

If you make a one-to-one call and do not get a response, you can send a request for the person to call you back.

Send a Call Me Alert

You can send a Call Me Alert in the following ways:

To send a Call Me Alert from the contacts list in the *PTT* menu, select *PTT Contacts*. Scroll to a contact, and select **Options** > *Call me alert*.

My Stuff

To send a Call Me Alert from the group list in the PTT menu, select *PTT Contacts*, and scroll to the desired group. Select *Options > Call me alert*. The alert is sent only to members logged in to PTT.

Respond to a Call Me Alert

When someone sends you a Call Me Alert, *Please call* is displayed with the caller's name in the standby mode.

To call the sender, press and hold the PTT key.

To send a Call Me Alert to the sender, select *Options > Call me alert*.

Voice messages

You can send a voice message to one of your PTT contacts or groups. From the *PTT Contacts* menu, select the individual or group to receive the voice message. Select *Options > Voice message*. Push and hold the PTT key while speaking. Release the PTT key to deliver the message.

Log

Access the PTT log from the PTT Main Menu or by pressing and holding the PTT key while in idle view. The log displays records of your PTT calls. While in this view, you can filter and delete log information or make PTT calls.

Alarm clock

The alarm clock uses the time format set for the clock. The alarm clock works even when the phone is turned off if there is enough power in the battery.

To set the alarm, select *Menu > My Stuff > Tools > Alarm clock > Alarm time* and enter the alarm time. To change the alarm time when the alarm time is set, select *On*. To set the phone to alert you on selected days of the week, select *Repeat alarm*.

To set a snooze time-out, select *Snooze time-out* and the time you want.

After making changes to the alarm settings, scroll to the bottom of the menu and select *Save*.

My Stuff

Alert tone and message

The phone sounds an alert tone and flashes *Alarm!* and the current time on the display, even if the phone is switched off. To stop the alarm, select **Stop**. If you let the phone continue to sound the alarm for a minute or select **Snooze**, the alarm stops for the selected snooze time-out and then resumes.

If the alarm time is reached while the device is switched off, the device switches itself on and starts sounding the alarm tone. If you select **Snooze**, the device switches off, then switches on again after the snooze time is reached. If you select **Stop**, the device asks whether you want to activate the device for calls. Select **No** to switch off the device or **Yes** to make and receive calls. Do not select **Yes** when wireless phone use may cause interference or danger.

Recent Calls

The phone logs the phone numbers of identified missed, received, and dialed calls, and the approximate length of your calls. The phone registers missed and received calls only if the network supports these functions and the phone is turned on and within the network's service area.

To view the information on your calls, select **Menu > Recent Calls > All calls > Missed calls**, **Calls received**, or **Calls made**. To view your recent missed and received calls and the calls made chronologically, select **All calls**. To view the contacts to whom you most recently sent messages, select **Msg. recipients**.

To view the approximate information on your recent communications, select **Menu > Recent Calls > Call time**, **Data counter**, **Pack. data timer**, or **Data transfer**.

To view how many text and multimedia messages you have sent and received, select **Menu > Recent Calls > Message log**.



Note: The actual invoice for calls and services from your service provider may vary, depending on network features, rounding off for billing, taxes, and so on.



Note: Some timers may be reset during service or software upgrades.

My Stuff

Calendar

The calendar helps you keep track of reminders, calls that you need to make, meetings, and birthdays.

Select **Menu > My Stuff > Tools > Calendar**.

The current day is indicated by a frame in the month view. If there are any notes set for the day, the day is in bold type. To view the day notes, select **View**. To view a week, select **Options > Week view**. To delete all notes in the calendar, select the month or week view and **Options > Delete all notes**.

Other options for the calendar day view are make a note; delete, edit, or move a note; copy a note to another day; send a note with Bluetooth wireless technology; or send a note as a text message or multimedia message to the calendar of another compatible phone. Select **Settings**, to set the date and time. Select **Auto-delete notes**, to set the phone to delete old notes automatically after a specified time.

Make a note

Select **Menu > My Stuff > Tools > Calendar**, the date you want, and **Options > Make a note**, and one of the following note types:

 **Meeting**,  **Call**,  **Birthday**,  **Memo** or  **Reminder**.

Note alarm

The phone beeps and displays the note. If a call note appears, to call the displayed number, press the call key. To stop the alarm and to view the note, select **View**. To stop the alarm for 10 minutes, select **Snooze**. To stop the alarm without viewing the note, select **Exit**.

To-do list

To save a note for a task that you have to do, select a priority level for the note, and mark it as done when you have completed it. Notes can be sorted by priority or by date.

To-do notes

1. Select **Menu > My Stuff > Tools > To-do list**.
2. If no note is added, select **Add note**; otherwise, select **Options > Add**.

My Stuff

3. Write the note, select the priority, set the deadline and the alarm type for the note, and select **Save**.
4. To view a note, scroll to it, and select **View**.

Notes

Select *Notes* to write and send notes to compatible devices by using text messaging or MMS.

1. Select **Menu > My Stuff > Tools > Notes**.
2. To make a note if one is not added, select **Add note**; otherwise, select **Options > Make a note**.
3. Write the note, and select **Save**.
4. To view a note, scroll to it, and select **View**.

Calculator

The calculator in your phone provides basic arithmetic and trigonometric functions; calculates the square, the square root, and the inverse of a number; and converts currency values.

 Note: This calculator has limited accuracy and is designed for simple calculations.

Select **Menu > My Stuff > Tools > Calculator**. Press **#** for a decimal point. Scroll to the desired operation or function, or select it from **Options**.

To save the exchange rate, select **Options > Exchange rate**. To perform the currency conversion, enter the amount to be converted and select **Options > Foreign unit in domestic units or Domestic unit in foreign units**.

Timer

1. Select **Menu > My Stuff > Tools > Timer > Normal timer**; enter the alarm time in hours, minutes, and seconds; and select **OK**.
You can write your own note text, which is displayed when the time expires.
2. To start the timer, select **Start**.
3. To change the countdown time, select **Change time**.

A d d r e s s B o o k

4. To stop the timer, select *Stop timer*.

If the alarm time is reached when the phone is in the standby mode, the phone sounds a tone and flashes the note text (if it is set) or *Countdown completed*. To stop the alarm press any key. If no key is pressed, the alarm automatically stops within 60 seconds. To stop the alarm and to delete the note text, select *Exit*. To restart the countdown timer, select *Restart*.

Stopwatch

Select *Menu > My Stuff > Tools > Stopwatch* to measure time, take intermediate times, or take lap times using the stopwatch. During timing, the other functions of the phone can be used. To set the stopwatch timing in the background, press the end key.

Using the stopwatch or allowing it to run in the background when using other features increases the demand on battery power and reduces the battery life.

12. Address Book

In the address book, you can store and manage contact information, such as names, phone numbers, and addresses. You can save names and numbers in the internal memory of the phone, the SmartChip card memory, or in a combination of the two. Names and numbers saved in the SmartChip card memory, are indicated by .

■ Find a contact

Select *Menu > Address Book > Names*, and scroll through the list of contacts, or enter the first letter of the name you are trying to find.

■ Save names and phone numbers

Names and numbers are saved in the used memory. Select *Menu > Address Book > Names > Options > Add new contact*. Enter the last name, first name, and phone number, and select *Save*.

■ Save numbers, items, or an image

In the phone memory for contacts, you can save different types of phone numbers and short text items per name. You can also assign a ringing tone to a contact.

The first number you save is automatically set as the default number and it is indicated with a frame around the number type indicator (for example, ). When you select a name, the default number is used unless you select another number.

1. Make sure that the memory in use is either *Phone* or *Phone and SmartChip*. See "Settings" on page 59.
2. Scroll to the name to which you want to add a new number or text item and select *Details* > *Options* > *Add detail*.
3. To add a number, select *Number* and one of the number types.
4. To add another detail, select a text type, an image from tones and graphics, or a new image.
5. To change the number type, scroll to the number you want, and select *Options* > *Change type*. To set the selected number as the default number, select *Select as default*.
6. Enter the number or text item. To save it, select *Save*.
7. To return to standby mode, select *Back* > *Exit*.

■ Copy contacts

To copy a name and phone number from the phone memory to the SmartChip card memory, or vice versa, select *Menu* > *Address book* > *Names* > *Options* > *Copy contact*. To move all contacts from the SmartChip card to phone memory, or vice versa, select *Menu* > *Address book* > *Move contacts* or *Copy contacts* > *From phone to SmartChip* or *From SmartChip to phone*. To copy more than one contact, but not all contacts, select *Menu* > *Address book* > *Names* > *Options* > *Mark*. Scroll and mark the contacts you want to move, and select *Move marked* or *Copy marked*.

■ Edit contact details

1. Find the contact you want to edit, select *Details*; and scroll to the name, number, text item, or image you want.
2. To edit a name, number, or text item, or to change image, select *Options > Edit*.

You cannot edit an ID when it is on the IM contacts or subscribed names list.

■ Delete contacts or details

To delete all the contacts and the details attached to them from the phone or SmartChip card memory, select *Menu > Address Book > Delete all contacts > From phone memory or From SmartChip*. Confirm with the security code.

To delete a contact, find the contact you want, and select *Options > Delete contact*.

To delete a number, text item, or an image attached to the contact, find the contact, and select *Details*. Scroll to the desired detail, and select *Options > Delete > Delete number, Delete detail, or Delete image*.

Deleting an image from contacts does not delete it from *My Stuff*.

■ Business cards

You can send and receive a person's contact information from a compatible device that supports the vCard standard as a business card.

To send a business card, find the contact whose information you want to send and, select *Details > Options > Send business card > Via multimedia, Via text message, or Via Bluetooth*.

When you have received a business card, select *Show > Save* to save the business card in the phone memory. To discard the business card, select *Exit > Yes*.

■ Settings

Select *Menu > Address Book > Settings* and one of the following options:

Address Book

Memory in use – to select the SmartChip card or phone memory for your contacts. Select *Phone and SmartChip* to recall names and number from both memories. In that case, when you save names and numbers, they are saved in the phone memory.

Address book view – to select how the names and numbers in *Address Book* are displayed

Name display – to select whether the contact's first or last name is displayed first

Font size – to set the font size for the list of contacts

Check memory – to view the free and used memory capacity

■ Groups

To arrange the names and phone numbers saved in the memory into caller groups with a different ringing tone and a group image, select *Menu > Address Book > Groups > Add*. Choose a name, image, ringing tone, and select *Save*. To add contacts to the group, select *View > Add*. Scroll to the first contact you want to add and press *Select*. Select *Add* and scroll to the next contact and press *Select* until all members are selected. To delete a member select *Options > Remove member*.

■ Speed dial list

To assign a number to a speed dialing key, select *Menu > Address Book > Speed dial list*, and scroll to the speed-dialing number that you want.

Select *Assign* or, if a number has already been assigned to the key, select *Options > Change*. Select *Find* and the contact you want to assign. If the speed dialing function is off, the phone asks whether you want to activate it.

To make a call using speed dialing, see "Speed dialing" on page 19.

■ Service and my numbers

Select *Menu > Address Book* and one of the following options:

Service numbers – to call the service numbers of your service provider, if the numbers are included on your SmartChip card (network service)

Settings

My numbers – to view the phone numbers assigned to your SmartChip card. This is only shown if the numbers are included on your SmartChip card.

13. Settings

■ Set profiles

Your phone has various settings groups called profiles, for which you can customize the phone tones for different events and environments.

Select *Menu > Settings > Set profile*, and the desired profile and from the following options:

Activate – to activate the selected profile

Customize – to customize the profile. Select the setting you want to change, and make the changes.

Timed – to set the profile to be active until a certain time up to 24 hours, and set the end time. When the time set for the profile expires, the previous profile that was not timed becomes active.

■ Set theme

A theme contains elements for personalizing your phone.

Select *Menu > Settings > Set theme* and from the following options:

Select theme – to set a theme. A list of folders in tones and graphics opens. Open the *Themes* folder, and select a theme.

Themes – to open a list of links to download more themes

■ Tones

You can change the tone settings of the selected active profile.

Select *Menu > Settings > Tones*, or select *Set profile* to find the same settings.

To set the phone to ring only for calls from phone numbers that belong to a selected caller group, select *Alert for*. Scroll to the caller group you want or *All calls*, and select *Mark*.

Settings

Select Options > *Save* to save the settings or *Cancel* to leave the settings unchanged.

If you select the highest ringing tone level, the ringing tone reaches its highest level after a few seconds.

■ Lights

To activate or deactivate light effects associated with different phone settings, select **Menu** > *Settings* > *Lights*.

■ Display

Select **Menu** > *Settings* > *Display* and from the available options:

Wallpaper – to add the background image in the standby mode

Home screen – to switch the active home screen mode on or off and to organize and personalize the active home screen mode.

Home screen font col. – to select the color for the texts in the home screen mode

Navigation key icons – to display the icons of the current navigation key shortcuts in the home screen mode when active home screen is off

Notification details – to display contact information in missed calls and messages received.

Fold animation – to set your phone to display an animation when you open and close the phone

Screen saver – to select a screen saver or turn off the screen saver

Font size – to set the font size for messaging, contacts and web pages

Operator logo – to set your phone to display or hide the operator logo

■ Set time and date

To change the time, time zone, and date settings, select **Menu** > *Settings* > *Set time/date* > *Date & time settings*, *Date and time format*, or *Auto-update of time* (network service).

When traveling to a different time zone, select **Menu** > *Settings* > *Date & time settings* > *Time zone* and the time zone of your location in terms of the time difference with respect to Greenwich Mean Time (GMT) or Universal Time Coordinated (UTC). The time and date are set according

Settings

to the time zone and enable your phone to display the correct sending time of received text or multimedia messages. For example, GMT -5 denotes the time zone for New York (USA), 5 hours west of Greenwich/London (UK).

■ My shortcuts

With personal shortcuts you get quick access to often used functions of the phone.

Left selection key

To select a function from the list, select **Menu > Settings > My shortcuts > Left selection key**.

In the home screen mode, select **Options > Options** and from the following options:

Select options – to add a function to the shortcut list or to remove one
Organize – to rearrange the functions on your personal shortcut list

Right selection key

To select a function from the list, select **Menu > Settings > My shortcuts > Right selection key**.

Navigation key

To assign other phone functions from a predefined list to the navigation key (scroll key), select **Menu > Settings > My shortcuts > Navigation key**.

Home screen key

To select a navigation key to activate the active home screen mode, select **Menu > Settings > My shortcuts > Home screen key**.

■ Sync and backup

Select **Menu > Settings > Sync and backup** and from the following:

Settings

■ Connectivity

You can connect the phone to a compatible device using a Bluetooth wireless technology or a USB data cable connection. You can also define the settings for EGPRS or 3G dial-up connections.

Bluetooth wireless technology

This device is compliant with Bluetooth Specification 2.1 + EDR supporting the following profiles: Advanced Audio Distribution Profile (A2DP), Audio/Visual Remote Control Profile (AVRCP), Dial-Up Network Profile (DUN), File Transfer Profile (FTP), Generic Audio/Video Distribution Profile (GAVDP), Hands-free Profile (HFP), Headset Profile (HSP), Object Push Profile (OPP), Personal Area Networking Profile (PAN), Phone Book Access Profile (PBAP), SIM Access Profile (SAP) and Service Discovery Application Profile (SDAP). To ensure interoperability between other devices supporting Bluetooth technology, use Nokia approved enhancements for this model. Check with the manufacturer of other devices to determine their compatibility with this device.

There may be restrictions on using Bluetooth technology in some locations. Check with your local authorities or service provider.

Features using Bluetooth technology or allowing such features to run in the background while using other features, increase the demand on battery power and reduce the battery life.

Bluetooth technology allows you to connect the phone to a compatible Bluetooth device within 10 meters (32 feet). Since devices using Bluetooth technology communicate using radio waves, your phone and the other devices do not need to be in direct line-of-sight, although the connection can be subject to interference from obstructions such as walls or from other electronic devices.

Set up a Bluetooth connection

Select *Menu > Settings > Connectivity > Bluetooth* and from the following options:

Bluetooth > On or Off – to activate or deactivate the Bluetooth function.  indicates that Bluetooth is activated. When activating Bluetooth technology for the first time, you are asked to give a name for the phone. Use a unique name that is easy for others to identify.

Settings

My phone's visibility – to select how your phone's visibility to other devices.

Search audio enhanc. – to search for compatible Bluetooth audio devices. Select the device that you want to connect to the phone.

Active devices – to view a list of active devices to which you have an active connection

Paired devices – to search for any Bluetooth device in range. Select *New* to list any Bluetooth device in range. Select a device, and *Pair*. Enter an agreed Bluetooth passcode of the device (up to 16 characters) to associate (pair) the device to your phone. You must only give this passcode when you connect to the device for the first time. Your phone connects to the device, and you can start data transfer.

My phone's name – to change the name of your phone, which is visible to other bluetooth devices.

Bluetooth wireless connection

Select *Menu > Settings > Connectivity > Bluetooth*. To check which Bluetooth connection is currently active, select *Active devices*. To view a list of Bluetooth devices that are currently paired with the phone, select *Paired devices*.

Bluetooth settings

To define how your phone is shown to other Bluetooth devices, select *Menu > Settings > Connectivity > Bluetooth > My phone's visibility* or *My phone's name*.

If you are concerned about security, turn off the Bluetooth function, or select *My phone's visibility > Hidden*. Always accept only Bluetooth communication from others with whom you agree.

Packet data

General packet radio service (GPRS) or 3G are network services that allow mobile phones to send and receive data over an internet protocol (IP)-based network.

Settings

To define how to use the service, select **Menu > Settings > Connectivity > Packet data > Packet data conn.** and from the following options:

When needed – to set the packet data connection to established when an application needs it. The connection is closed when the application is terminated.

Always online – to set the phone to automatically connect to a packet data network when you switch the phone on

Modem settings

You can connect the phone using Bluetooth wireless technology or USB data cable connection to a compatible PC and use the phone as a modem to enable GPRS Or 3G connectivity from the PC.

To define the settings for connections from your PC, select **Menu > Settings > Connectivity > Packet data > Packet data settings > Active access point**, and activate the access point you want to use. Select **Edit active access pt. > Packet data acc. pt.**, enter a name to change the access point settings, and select **OK**. Select **Packet data acc. pt.**, enter the access point name (APN) to establish a connection to an network, and select **OK**.

You can also set the GPRS dial-up service settings (access point name) on your PC using the Nokia Modem Options software. See "Nokia PC Suite" on page 73. If you have set the settings both on your PC and on your phone, the PC settings are used.

Data transfer

Synchronize your calendar, contacts data, and notes with another compatible device (for example, a mobile phone), a compatible PC, or a remote Internet server (network service).

Your phone allows data transfer with a compatible PC or another compatible device when using the phone without a SmartChip card.

Transfer contact list

To copy or synchronize data from your phone, the name of the device and the settings must be in the list of transfer contacts. If you receive data from another device (for example, a compatible mobile phone), the

Settings

corresponding transfer contact is automatically added to the list, using the contact data from the other device. *Server sync* and *PC synchronization* are the original items in the list.

To add a new transfer contact to the list (for example a mobile phone), select **Menu > Settings > Connectivity > Data transfer > Options > Add transfer contact > Phone synchronization or Phone copy**, and enter the settings according to the transfer type.

To edit the copy and synchronize settings, select a contact from the transfer contact list and **Options > Edit**.

To delete a transfer contact, select it from the transfer contact list, select **Options > Delete**.

Data transfer with a compatible device

For synchronization use Bluetooth wireless technology or a cable connection. The other device must be activated for receiving data.

To start data transfer, select **Menu > Settings > Connectivity > Data transfer** and the transfer contact from the list, other than *Server sync* or *PC synchronization*. According to the settings, the selected data is copied or synchronized.

Synchronize from a compatible PC

To synchronize data from calendar, notes, and contacts, install the Nokia PC Suite software for your phone on the PC. Use Bluetooth wireless technology or a USB data cable for the synchronization, and start the synchronization from the PC.

Synchronize from a server

To use a remote internet server, subscribe to a synchronization service. For more information and the settings required for this service, contact your service provider. You may receive the settings as a configuration message. See "Configuration settings service" on page 8 and "Configuration" on page 70.

To start the synchronization from your phone, select **Menu > Settings > Connectivity > Data transfer > Server sync**. Depending on the settings, select *Initialising synchronization* or *Initialising copy*.

Settings

Synchronizing for the first time or after an interrupted synchronization may take up to 30 minutes to complete.

USB data cable

You can use the CA-101 USB data cable to transfer data between the phone and a compatible PC. You can also use the USB data cable with Nokia PC Suite.

To activate the phone for data transfer or image printing, connect the data cable. Confirm *USB data cable connected*. *Select mode*, and select from the following options:

Nokia mode – to use the phone to interact with applications on a PC that has Nokia PC Suite

Music sync – to connect the phone to a PC to synchronize it with Windows Media Player (music, video)

Data storage – to connect to a PC that does not have Nokia software and use the phone as a data storage

To change the USB mode, select *Menu > Settings > Connectivity > USB data cable > Nokia mode, Music sync, or Data storage*.

■ Call settings

Select *Menu > Settings > Call settings* and from the following options:

Call forwarding – to forward your incoming calls (network service). You may not be able to forward your calls if some call restriction functions are active. See *Call restrictions* in "Security" on page 71.

Anykey answer > On – to answer an incoming call by briefly pressing any key, except the power key, the camera key, the left and right selection keys, or the end key

Automatic redial > On – to make a maximum of 10 attempts to connect the call after an unsuccessful call attempt

Speed dialing > On – to dial the names and phone numbers assigned to the speed-dialing keys 2 to 9 by pressing and holding the corresponding number key

Settings

Call waiting > Activate – to have the network notify you of an incoming call while you have a call in progress (network service). See "Call waiting" on page 20.

Summary after call > On – to briefly display the approximate duration and cost (network service) of the call after each call

Send my caller ID > Yes – to show your phone number to the person you are calling (network service). To use the setting agreed upon with your service provider, select *Set by network*.

Answ. iff fold opened > On – to answer an incoming call by opening the fold

■ Phone settings

Select *Menu > Settings > Phone settings* and from the following options:

Language settings – to set the display language of your phone, select *Phone language*. *Automatic* selects the language according to the information on the SmartChip card. To set a language for the voice playback, select *Recognition lang*. See "Enhanced voice dialing" on page 19 and *Voice commands* in "My shortcuts" on page 63.

Check memory – to view the amount of used and available phone memory

Automatic keyguard – to set the keypad of your phone to lock automatically after a preset time delay when the phone is in the standby mode and no function of the phone has been used. Select *On*, and set the time.

Security keyguard – to set the phone to ask for the security code when you unlock the keyguard. Enter the security code, and select *On*.

Welcome note – to write the note that is shown when the phone is switched on

Software updates – to update phone software or check the current software

Network mode – to select dual mode (UMTS and GSM), UMTS, or GSM. You cannot access this option during an active call.

Settings

Help text activation – to select whether the phone shows help texts

Start-up tone > On – the phone plays a tone when switched on

Switch off tone > On – the phone plays a tone when switched off

Fold close handling – to select whether to return to standby mode or keep all applications open when the fold is closed

Flight query > On – the phone asks whether to use the flight profile every time when switched on. With flight profile all radio connections are switched off. The flight profile should be used in areas sensitive to radio emissions.

■ Accessories

This menu or the following options are shown only if the phone is or has been connected to a compatible mobile enhancement.

Select **Menu > Settings > Enhancements**. Select an enhancement, and depending on the enhancement, from the following options:

TTY/TDD – to set the phone on or off for TTY/TDD communication

Charger > Default profile – to select the profile that you want to be automatically activated when you connect to the selected enhancement

Charger > Lights – to set the lights permanently on. Select *Automatic* to set the lights on for 15 seconds after a keypress.

Hearing aid > T-coil hrgng. aid mode > On to optimize the sound quality when using a t-coil hearing aid.  is shown when the T-coil hearing aid mode is active.

Headphones – to select the activated profile when a headset is connected.

■ Configuration

You can configure your phone with settings required for certain services to function correctly. Your service provider may also send you these settings. See "Configuration settings service" on page 8.

Select **Menu > Settings > Configuration** and from the following options:

Settings

Default config. sett. – to view the service providers saved in the phone. To set the configuration settings of the service provider as default settings, select **Options > Set as default**.

Activ. def. in all apps. – to activate the default configuration settings for supported applications

Preferred access pt. – to view the saved access points. Scroll to an access point, and select **Options > Details** to view the name of the service provider, data bearer, and packet data access point or GSM dial-up number.

Connect to support – to download the configuration settings from your service provider

Device manager sett. – to select when to allow service software updates

Personal config. sett. – to add new personal accounts for various services manually, and to activate or delete them. To add a new personal account if you have not added any, select **Add**, otherwise, select **Options > Add new**. Select the service type, and select and enter each of the required parameters. The parameters differ according to the selected service type. To delete or activate a personal account, scroll to it, and select **Options > Delete** or **Activate**.

■ Security

When security features that restrict calls are in use (such as call restriction and fixed dialing) calls still may be possible to the official emergency number programmed into your device.

Select **Menu > Settings > Security** and from the following options:

PIN code request – to set the phone to ask for your PIN code every time the phone is switched on. Some SmartChip cards do not allow the code request to be turned off.

Call restrictions – to restrict incoming calls to and outgoing calls from your phone (network service). A restriction password is required.

Fixed dialing – to restrict your outgoing calls to selected phone numbers if this function is supported by your SmartChip card. When the fixed dialing is on, GPRS connections are not possible except while sending text messages over a GPRS connection. In this case, the

PC connectivity

recipient's phone number and the message center number must be included in the fixed dialing list.

Security level > Phone – to set the phone to ask for the security code whenever a new SmartChip card is inserted into the phone. If you select *Memory*, the phone asks for the security code when the SmartChip card memory is selected, and you want to change the memory in use.

Access codes – to change the security code, PIN code, UPIN code, PIN2 code, or restriction password

Code in use – to select whether the PIN code or UPIN code should be active

PIN2 code request – to select whether the PIN2 code is required when using a specific phone feature which is protected by the PIN2 code. Some SmartChip cards do not allow the code request to be turned off.

Authority certificates – to view the list of the authority certificates downloaded into your phone. See "Certificates" on page 40.

User certificates – to view the list of the user certificates downloaded into your phone. See "Certificates" on page 40.

Security module sett. – to view *Secur. module details*, select *Module PIN request*, or change the module PIN and signing PIN. See also "Access codes" on page 7.

■ Reset device

To reset some of the menu settings to their original values, select *Menu > Settings > Reset device*. Enter 1234, 12345, or create a security code if the phone prompts you to create one. The names and phone numbers saved in the address book, are not deleted.

14. PC connectivity

You can send and receive e-mail, and access the Internet when your phone is connected to a compatible PC through a Bluetooth or a data cable connection. You can use your phone with a variety of PC connectivity and data communications applications.

Battery and charger information

■ Nokia PC Suite

With Nokia PC Suite you can synchronize contacts, calendar, notes, and to-do notes between your phone and the compatible PC or a remote internet server (network service). You may find more information and PC Suite on the Nokia website at www.nokia.com/support or your local Nokia website.

■ Packet data

With your phone you can use packet data services. For availability and subscription to data services, contact your network operator or service provider. See "Modem settings" on page 66.

■ Data communication applications

For information on using a data communication application, refer to the documentation provided with it.

Making or answering phone calls during a computer connection is not recommended, as it might disrupt the operation.

For better performance during data calls, place the phone on a stationary surface with the keypad facing downward. Do not move the phone by holding it in your hand during a data call.

15. Battery and charger information

■ Charging and discharging

Your device is powered by a rechargeable battery. The battery intended for use with this device is the BP-6MT. Nokia may make additional battery models available for this device. This device is intended for use when supplied with power from the following chargers: AC-6. The exact charger model number may vary depending on the type of plug. The plug variant is identified by one of the following: E, EB, X, AR, U, A, C, or UB.

The battery can be charged and discharged hundreds of times, but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, replace the battery. Use only Nokia approved batteries, and recharge your battery only with Nokia approved chargers designated for this device. Use only replacement batteries qualified with the device per the IEEE-

Battery and charger information

1725-2006 standard. Use of other batteries or chargers may present a risk of fire, explosion, leakage, or other hazard.

If a battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger, then disconnect and reconnect it to begin charging the battery. If the battery is completely discharged, it may take several minutes before the charging indicator appears on the display or before any calls can be made.

Always switch the device off and disconnect the charger before removing the battery.

Unplug the charger from the electrical plug and the device when not in use. Do not leave fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Always try to keep the battery between 15°C and 25°C (59°F and 77°F). Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Battery performance is particularly limited in temperatures well below freezing.

Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen cause a direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Do not dismantle, cut, open, crush, bend, deform, puncture, or shred cells or batteries. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. In the event of such a leak, flush your skin or eyes immediately with water, or seek medical help.

Do not modify or remanufacture, attempt to insert foreign objects into the battery or immerse or expose it to water or other liquids.

Improper battery use may result in a fire, explosion, or other hazard. If the device or battery is dropped, especially on a hard surface, and you believe the battery has been damaged, take it to a service center for inspection before continuing to use it.

Battery and charger information

Use the battery only for its intended purpose. Never use any charger or battery that is damaged. Keep your battery out of the reach of small children.


■ Nokia battery authentication

Always use original Nokia batteries for your safety. To check that you are getting an original Nokia battery, purchase it from an authorized Nokia dealer, and inspect the hologram label using the following steps:

Successful completion of the steps is not a total assurance of the authenticity of the battery. If you have any reason to believe that your battery is not an authentic, original Nokia battery, you should refrain from using it, and take it to the nearest authorized Nokia service point or dealer for assistance. Your authorized Nokia service point or dealer will inspect the battery for authenticity. If authenticity cannot be verified, return the battery to the place of purchase.

Authenticate hologram

1. When looking at the hologram on the label, you should see the Nokia connecting hands symbol from one angle and the Nokia Original Enhancements logo when looking from another angle.



2. When you angle the hologram left, right, down, and up, you should see 1, 2, 3, and 4 dots on each side respectively.



What if your battery is not authentic?

If you cannot confirm that your Nokia battery with the hologram on the label is an authentic Nokia battery, please do not use the battery. Take it to the nearest authorized Nokia service point or dealer for assistance. The use of a battery that is not approved by the manufacturer may be dangerous and may result in poor performance and damage to your device and its enhancements. It may also invalidate any approval or warranty applying to the device.

To find out more about original Nokia batteries, visit www.nokia.com/battery.

Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Do not touch the main display with hard or angular materials. Objects like earrings or jewelry may scratch the display.
- Use a soft, clean, dry cloth to clean any lenses (such as camera, proximity sensor, and light sensor lenses).
- Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.
- Use chargers indoors.
- Always create a backup of data you want to keep (such as contacts and calendar notes) before sending your device to a service facility.
- To reset the device from time to time for optimum performance, power off the device and remove the battery.

Additional safety information

All of the above suggestions apply equally to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorized service facility for service.

Additional safety information

Your device and its enhancements may contain small parts. Keep them out of the reach of small children.

■ Operating environment

Remember to follow any special regulations in force in any area, and always switch off your device when its use is prohibited or when it may cause interference or danger. Use the device only in its normal operating positions. This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 2.2 centimeters (7/8 inch) away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the device the above-stated distance from your body.

To transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure that the above separation distance instructions are followed until the transmission is completed.

Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because information stored on them may be erased.

■ Medical devices

Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine if they are adequately shielded from external RF energy or if you have any questions. Switch off your device in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Implanted medical devices

Manufacturers of medical devices recommend that a minimum separation of 15.3 centimeters (6 inches) should be maintained between a wireless device and an implanted medical device, such as a pacemaker or implanted cardioverter

Additional safety information

defibrillator to avoid potential interference with the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimeters (6 inches) from the medical device when the wireless device is turned on
- Do not carry the wireless device in a breast pocket
- Hold the wireless device to the ear opposite the medical device to minimize the potential for interference.
- Turn the wireless device off immediately if there is any reason to suspect that interference is taking place.
- Read and follow the directions from the manufacturer of their implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Hearing aids

Some digital wireless devices may interfere with some hearing aids. If interference occurs, consult your service provider.

■ Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic antiskid (antilock) braking systems, electronic speed control systems, and air bag systems. For more information, check with the manufacturer or its representative of your vehicle or any equipment that has been added.

Only qualified personnel should service the device, or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Using your device while flying in aircraft is prohibited. Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal.

■ Potentially explosive environments

Switch off your device when in any area with a potentially explosive atmosphere and obey all signs and instructions. Potentially explosive atmospheres include areas where you would normally be advised to turn off your vehicle engine. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Switch off the device at refueling points such as near gas pumps at service stations. Observe restrictions on the use of radio equipment in fuel depots, storage, and distribution areas; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), and areas where the air contains chemicals or particles such as grain, dust, or metal powders.

■ Emergency calls



Important: Wireless phones, including this device, operate using radio signals, wireless networks, landline networks, and user-programmed functions. Because of this, connection in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

To make an emergency call:

1. If the device is not on, switch it on. Check for adequate signal strength. Some networks may require that a valid SmartChip card is properly inserted in the device.
2. Press the end key as many times as needed to clear the display and ready the device for calls.
3. Enter the official emergency number for your present location. Emergency numbers vary by location.
4. Press the call key.

If certain features are in use, you may first need to turn those features off before you can make an emergency call. If the device is in the offline or flight mode, you must change the profile to activate the phone function before you can make an emergency call. Consult this guide or your service provider for more information.

When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

Additional safety information

■ Hearing aid compatibility (HAC)



Warning: For hearing aid compatibility, you must turn off the Bluetooth connectivity.

Your mobile device model complies with FCC rules governing hearing aid compatibility. These rules require an M3 microphone or higher value. The M-value, shown on the device box, refers to lower radio frequency (RF) emissions. A higher M-value generally indicates that a device model has a lower RF emissions level, which may improve the likelihood that the device will operate with certain hearing aids. Some hearing aids are more immune than others are to interference. Please consult your hearing health professional to determine the M-rating of your hearing aid and whether your hearing aid will work with this device. More information on accessibility can be found at www.nokiaaccessibility.com.

■ Certification information (SAR)

This mobile device meets guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network. That amount changes depending on a number of factors such as how close you are to a network base station. The highest SAR value under the ICNIRP guidelines for use of the device at the ear is 0.84W/kg.

Use of device accessories and enhancements may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band. Additional SAR information may be provided under product information at www.nokia.com.

Your mobile device is also designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA) and Industry Canada. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during

product certification for use at the ear is 1.00W/kg and when properly worn on the body is 0.85W/kg.

Index

A

Address Book 56
alarm clock 52
alert tone and message 53
alerts 32
antenna 11
applications 42
AT&T Mall 41
AT&T Music 20

B

battery
authentication 74
charging 10
charging, discharging 72
installation 8
battery charge status 15
Bluetooth connectivity 63
bookmarks 36
browser 34, 36, 37
business cards 58

C

cache memory 39
calculator 55
calendar 54
call
counters 53
functions 17
options 19
settings 67
timers 53
voice mail 32
waiting 19
caller groups 59
calls 17, 18, 19
calls made 53
calls received 53
camera 43
effects 45
record a video clip 44
settings 45
take a photo 43

certificates 39

character case 21
charge the battery 10
charger lights 69
clock 15
clock settings 61
configuration 69
 setting service 7
contact information 7
contacts 56
cookies 37
countdown timer 55
customer service 7

D

data
 communication 72
 transfer 65
data cable 67
date settings 61
define a storage folder 47
delete
 contact details 58
 contacts 58
 messages 32
dialing 59
digital signature 40
downloads 7, 38

E

edit contact details 58
EGPRS 64
e-mail 29-32
emergency calls 78
end call 17
enhancements 69
equalizer 47
explosive environments 77

F

factory settings 71
fold animation 61
folders

define for storage 47
outbox 24
font size 61

G
games 42
Games & Applications 42
GPRS 64
groups 59

H
handsfree. See loudspeaker.
hearing aid 77
hearing aid compatibility 78
help 5

I
IM 25
indicators 15
installation
 battery 8
 SmartChip card 8
instant messaging 25
internet 34

K
key functions 14
keyguard 16
keypad lock 16
keys 16

L
language options 23
language settings 68
list of recordings 47
loudspeaker 19

M
main display 15, 61
maintenance 74
MEdia Net 34, 36
memory
 capacity 41
 SmartChip 56
 status 59
memory card 10, 42
memory in use 59

menu 20
message center number 22
message length indicator 23
message settings 33

messages
 multimedia 23
 read and reply 24
 sending 24
 SmartChip 25
 text 23

missed calls 53
multimedia messages 23
music player 45, 46
Music sync 67
my numbers 60
My Stuff 41

N
names 56
navigation 20
navigation key 62
network
 name or display 15
network mode 15
NOKIA contact information 7
note alarm 54
note creation 54
notes 55

O
offline mode 17

P
pacemakers 76
packet data 64, 72
parts 13
PC connectivity 71
PC Suite 71
phone
 configuration 69
 keys 13
 parts 13
 settings 68

phone lock. See keypad lock.
phonebook 56
PIN codes 14
play music 45
predictive text input 21
pushed messages 38

R
received calls 53
record a call 47
recordings list 47
ringing tones 41, 60

S
safety information 76
save names 56
save numbers 57
scrolling 20
security
 module 39
 settings 70
send multimedia message 24
service
 commands 32
 inbox 38
 messages 38
 numbers 59
service numbers 59
services 34
set profiles 60
settings
 active standby 61
 call 67
 camera 45
 clock 61
 configuration 69
 connectivity 63
 contacts 58
 data transfer 65
 date 61
 downloads 38
 enhancements 69
 fold animation 61
 GPRS, EGPRS 64
 main display 61
 messages 33
 my shortcuts 62
 phone 68
 profiles 60
 restore factory settings 71
 security 70
 service inbox 38
 themes 60
 time 61
 tones 60
 USB data cable 67
 wallpaper 61
shortcuts 62
signal strength 15

SmartChip
 card 17
 card installation 8
speed dial list 59
speed dialing 18
standby mode 14, 62
status indicators 15
stereo widening 48
stopwatch 56
strap 12
subscribed names list 58
switch on and off 14
synchronization 65

T
take a photo 43
text 21, 22
themes 60
time settings 61
timer 55
to-do list 54
tones 60
Tones & graphics 41
tools 18
traditional text input 22

U
unlock keypad 16
UPIN 14

V
vehicles 77
video clip 44
voice
 dialing 18
voice mail 32
voice recorder 46

W
wallpaper 61
wireless markup language 34
wrist strap 12
write multimedia message 24
write text 21

X
XHTML 34