


Thank you for purchasing this remote control toy car. In order to gain a thorough understanding of the product and safe, trouble-free operation, please read the following instructions carefully before use.

SPECIFICATIONS AND FEATURES


This toy car has forward, reverse, right & left steering and stop functions. It requires 2XAA batteries and 5xAA batteries for the remote control and R/C car respectively.

HOW TO INSTALL THE BATTERY, ANTENNA AND CHARGING THE BATTERY


1. Install the batteries into remote control: Open the battery compartment cover, insert 2XAA batteries into the battery compartment. Ensure that the battery is inserted properly by matching the “+” and “-” symbols indicating inside the battery compartment. Close the compartment cover. Turn the power switch to “ON”. The red power light will turn on, indicating that power is now supplied to the remote control.



2. Insert the antenna into the small hole located at the top of the remote control unit; screw it until it is well tightened by turning it in the clockwise direction. You can unscrew and remove it by turning it in counter-clockwise direction.




3. Remote control car: Open the battery compartment cover located at the bottom of the car. Insert 5x “AA” batteries into the battery compartment. Ensure that the battery is inserted properly by matching the “+” and “-” symbols which are indicated inside of the battery compartment. Close the compartment cover and screw the cover. Turn the power switch to “ON” to power the car on.




OPERATION INSTRUCTIONS


1. Turn the power switch of the remote control car and the remote control unit to the “ON” position; Switch the channel control on both the remote control and the model car to the same channel.



2. Operate the gun style remote control unit: When the trigger is pulled back half way, the remote control car will move forward at a low speed; When the trigger is pulled forward, the remote control car will move forward at a high speed; When the trigger is pushed forward, the remote control car will reverse; When the direction steering wheel of the remote control unit is turned clockwise, the remote control car will steer to the right and when it is turned anti-clockwise, the car will steer to the left (the correct operation method is to hold the remote control unit with the left hand and use the fingers of the left hand to operate the trigger; use the right hand to operate the steering wheel).



3. If the remote control car fails to run in a straight line, adjust the direction adjustment rod on the bottom of the car by turning it slightly to the right/left until the straightest position is achieved.



4. When the antenna is pulled out to a certain length, the remote control operating distance of the remote control car will be increased accordingly.

5. When the remote control car is not in use, please switch off the power on both the remote control unit and the remote control car.

WARNINGS

- Use only batteries of the same or equivalent type as recommended.
- Insert batteries with the correct polarity direction.
- Remove exhausted batteries from the toy.
- Do not mix old and new batteries.
- Do not mix alkaline, standard(carbon zinc), or rechargeable (nickel cadmium) batteries.
- Please take out batteries when not in use.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.

SPECIAL WARNINGS TO PARENTS

Please retain this information for future reference.

FCC WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC STATEMENT:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.