

Caution:

- There should be at least 9 inches (20 cm) separation between the BeaconPoint and users.
- Any changes or modifications not expressly approved by Chantry Networks could void the user's authority to operate the equipment.
- The BeaconPoints shall be powered by UL approved limited power source adapter or UL approved limited power source power over ethernet (P.O.E.).
- The BP200 product will automatically discontinue transmission in case of either absence of information (no frames transmitted through Ethernet) to transmit or operational failure.



Chantry Beaconworks

Addendum to Quick Start Guide Release 1.1

Updated June 17th, 2004

Warning:


- When the BP200E is enabled in the 5.15 to 5.25 GHz band, it is authorized for indoor deployment only.
- When the BP200E is enabled in the 5.15 to 5.25 GHz band, the antennas are permanently attached to the access point. Do not attempt to disconnect.

Note:

The BP200 has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- Install ferrite bead onto the BeaconPoint 200 data cord as illustrated below.




RJ45 Data Cord.

- Install ferrite beads onto the BeaconMaster power and data cords as illustrated below.



Power Cord.



RJ45 Data Cord.