

ARCHER

Wireless Headset

User Guide



SOLTERAS™

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

1. INTRODUCTION

Congratulations on owning the *Solteras ARCHER* headset with *Bluetooth*® technology. Now you can enjoy the freedom of making and receiving calls while conducting your daily activities. This headset lets you connect to any *Bluetooth*® enabled device that supports *Bluetooth*® Headset and/or Hands-free profile.

Please carefully read over this user's manual before operating your headset. More detailed information is also provided by your phone's user guide. Both the headset's and phone's manual should be read carefully to understand the operation modes as well as important safety and maintenance information.

2. BLUETOOTH

Bluetooth® wireless technology allows connection of devices using built-in radio transceivers that operate on a globally available radio frequency without the need to be in direct line of sight. The two devices can easily connect within a proximity of 10 meters of each other, although the connection quality can vary from types of obstructions, such as walls, or from other electronic devices.


You may have different experience when connecting this headset with different devices; not all functions described in this user's manual will be supported by all phone models. In some countries, there may be restrictions on using *Bluetooth*® devices. Please check with your local authorities.

3. PACKAGE CONTAINS:


Check that you have all of the following items.

All pictures shown are for illustration purposes. Actual design and specifications are subject to change without notice.

- Headset




- Boom microphone
(1 short, 1 extended)




- Ear buds
(2-regular, 2-large)




- A/C charger



- Stickers
(various colors)



- Carabiner carrier



4. SPECIFICATIONS

Wireless Standard:

Bluetooth 1.2 compliant

TX Power: 0dbm (class 2)

Weight: 20 g/ 0.8 oz

Transmission Range: 10
meter/ 30 feet

Battery Type: NiMH


Talk time: up to 6 hours*

Standby time: up to 10
days*

Caller ID: Voice (numeric)

*All talk and standby times are approximate. Battery performance depends on signal strength, operating temperature, and other usage patterns.

5. FEATURES



6. PREPARING YOUR HEADSET

Charging the battery

First-Time Use: plug the charger into your headset's charger port for at least 8 hours (or until the LED turns off). You may charge your battery from either of the 2 jacks on your headset.

Recharging: This headset contains rechargeable NiMH battery. Three (3) consecutive beeps are generated in one minute interval to indicate low battery status. Connect your AC charger plug to the charging port of your headset. FLASHING RED LED on your headset indicates charging while SOLID RED LED indicates charge complete.



CAUTION

Do not disassemble, expose to temperatures above 60°C/140°F, or immerse in water. Keep batteries out of the reach of children.



Contact your local recycling center for proper disposal of battery. Never dispose of batteries in fire - this may result in explosion.

Using the charger

The charger can be plugged into either of the 2 charging ports

Note: Headset will not work while charging.


Installing the boom microphone

The microphone can be plugged into either of the charging jack depending on left or right ear wear.

Installing the Carabiner carrier.


Plug the carabiner in to either of the L/R jack that is not in use.

Note: The carabiner should be removed prior to wearing the headset.
Never use it for climbing nor to hold more than 1 lb.(½ Kg) of weight.




Applying the stickers

1. Align one end of the sticker to the start of the groove at the speaker end.
2. Apply the sticker by guiding it along the groove and applying pressure to squeeze out air pockets.
3. Repeat steps 1&2 for the remaining groove.




Installing the ear-bud

4. Insert the earbud onto the headset by pushing it over the speaker housing.



Wearing the headset



1. Open the headset if it is not already.

CAUTION: Do not bend the neck back more than 90° to prevent damage to your headset.



2. Make sure the boom is also open by rotating it down.

3. Place the earbud inside the ear with the ear-ark behind the ear.

4. While holding the earbud in place with your index finger, clamp the headset on your ear by pushing the ark to the back of the ear.

5. Adjust the headset position by rotating the ark up or down.

6. If necessary, adjust the mic. position by rotating it until it locks into the desired position.



7. USING YOUR ARCHER HEADSET

FUNCTION	KEY PRESS TIMING
ON/ STAND BY	PRESS and HOLD both buttons for 3 seconds and release.
OFF	PRESS Volume button first then Task button, and hold both for 2 seconds.
PAIRING <i>(Unit must be OFF to initiate pairing)</i>	PRESS AND HOLD both buttons simultaneously for 8 seconds. <i>(Enter pass code '0000' when prompt)</i>
PAIRING <i>(successful pair)</i>	
CHARGING	N/A
WHEN HEADSET IS TURNED ON & PAIRED ALREADY	
IN COMING CALL/ CALLER ID	N/A
ANSWERING	PRESS Task button once.
VOICE DIALING	PRESS Task button once. (then speak name when prompt)
REDIALING	Double PRESS Task button (within 2 second)
REJECTING CALLS	PRESS and HOLD Task button until beep tone.
ONLY DURING ACTIVE CALL	
VOLUME UP/DOWN <i>(Single button control for vol. +/-)</i>	Press Volumn button to desired level (6 level, loop)
TRANSFERING CALLS <i>(to and from phone)</i>	PRESS Task button once during a call to switch call to phone. PRESS Task button again to bring call back to headset.
CALL WAITING	Short PRESS Task button once during a call to answer new call, PRESS again to switch back to 1st call.
ENDING A CALL	PRESS and HOLD Task button until beep tone.
MUTE	PRESS and HOLD Volume button until beep tone.

FUNCTION	LED	STONE
ON/ STAND BY	Both buttons light up and then volume button flashes at 5 second interval when released.	Single beep(DOO)
OFF	Both buttons light up and then off when released.	N/A
PAIRING (putting unit into pairing mode)	Both buttons light up for 8 seconds then start to flash alternately at 1/2 second interval.	N/A
PAIRING (successful pair)	Volume button flashes at a 5 second interval.	
CHARGING	Both LEDs flashes at 1/2 second interval, solid when fully charged.	N/A
IN COMING CALL/ CALLER ID	Alternating flashes on both buttons at 1/2 second interval until call is answered or rejected.	Phone's ringtone -> caller ID -> ringtone
ANSWERING	Alternating flashes on both buttons at 1/2 second interval until call is answered. No LED after the call is picked up.	Phone's ringtone
VOICE DIALING	No LED activity.	N/A
REDIALING	Flashes at a 5 second interval on Volume button	
REJECTING CALLS	Flashes at a 5 second interval on Volume button (after rejecting)	Single beep (DOO) when call is rejected.
VOLUME UP/DOWN (Single button for vol. +/-)	2 quick flashes after Volume button is pressed.	Single beep (DOO) at the selected volume level.
TRANSFERING CALLS (to and from phone)	Flashes at a 5 second interval on Volume button (only when call is transferred to phone)	Audio channel close ringtone.
CALL WAITING	No LED activity.	Quick double tone(DOO,DOO) when another call comes in. Transfer to the new call after Task button is pressed.
ENDING A CALL	flashes at a 5 second interval (after ending)	Single beep (DOO) when call is rejected.
MUTE	flashes at 1 second interval	Single beep (DOO) when in mute.

8. TROUBLESHOOTING

If you cannot connect the Solteras Archer to your phone:

1. Make sure your headset is turned on by holding down both buttons for 3 seconds.
2. Make sure your phone is turned on and *Bluetooth*® feature is activated.
3. Checked for paired devices if you believe your headset is already paired.

If “Solteras Archer” does not appear on the paired devices list your must repeat the steps for pairing.

If “Solteras Archer” comes up on pair devices, repeat connecting the paired headset to your phone.

If your headset is paired and connected to your phone but does not respond to your actions as you know it should, proceed as follows: Power down the headset by holding down both buttons for 2 seconds and leaving it powered off for 1 minute before powering it back on again.

If you cannot get audio to the headset from a computer:

1. repeat connecting the paired headset to your computer.
(Make sure you are wearing the headset so you can hear the initiating audio tone. When you hear the tone, press the Task button on the headset to make the connection.)

LIMITED WARRANTY

This limited warranty shall apply to the Solteras Archer Bluetooth Headset product including all accessories as contained within the original package ("the Product"). Solteras, Inc. warrants that the Product is at the time of its original purchase free of defects in materials and workmanship ("Limited Warranty"). This Limited Warranty is subject to the following terms and conditions:

1. This Limited Warranty is given only to the original purchaser of the Product ("Customer"). It shall neither exclude nor limit a) any statutory rights of the Customer or b) any of the Customer's rights against the seller/dealer of the Product.
2. This Limited Warranty shall last for one (1) year from the date of original purchase ("Warranty Period") Proof of Purchase will be required. This Limited Warranty may not be sold-on, assigned, transferred or given to any subsequent purchaser or given to any subsequent purchaser or acquirer of the Product.
3. This Limited Warranty applies only to the hardware components of the Product as originally supplied.
4. If Solteras repairs or replaces the Product, the repaired or replaced Product shall continue to be warranted for the remaining time of the original Warranty Period.
5. THIS LIMITED WARRANTY SHALL NOT APPLY IF THE DEFECT WAS CAUSED THROUGH ANY OF THE FOLLOWING:
 - (a) Solteras or its authorized agent was not notified by the customer of the defect within fourteen (14) days after the appearance of the defect within the Warranty Period; or
 - (b) the Product was not returned to Solteras or its authorized service agent within thirty (30) days after the appearance of the defect within the Warranty Period; or
 - (c) deterioration of the Product due to normal wear and tear; or
 - (d) use other than in accordance with the user manual; rough handling; exposure to moisture; dampness or extreme thermal or environmental conditions or a rapid change in such conditions; corrosion; oxidation; unauthorized modifications or connections; unauthorized opening or repair; repair by use of unauthorized spare parts; accident; forces of nature; or other actions beyond the reasonable control of Solteras, Inc. (including but not limited to deficiencies in consumable parts, such as batteries which all by their nature have a limited lifetime) unless the defect was caused directly by defects in materials or workmanship; This Limited Warranty does not cover physical damage to the surface of the Product; or
 - (e) the Product serial number, the accessory date code has been removed, erased, defaced, altered or is illegible; or

- (f) the defect was caused by a defective function of the cellular network, cellular phone; or
 - (g) the defect was caused by the fact that the Product was used with or connected to an accessory not approved or provided by Solteras or used in other than its intended use and where it can be shown by Solteras, Inc. that such defect is not the fault of the Product itself; or
 - (h) the defect was caused by unauthorized modification to the core software.
6. In the event of Product failure, the Customer should take the following actions:
- (a) Refer to the user manual in order to identify and possibly correct the problem.
 - (b) If the problem cannot be resolved by reference to the user manual the Customer should then contact Solteras, Inc. on the number listed on our website:
WWW.SOLTERAS.COM
 - (c) Before the Customer calls to ensure prompt assistance the Customer should ensure the following information is at hand:
 - *The model and serial number
 - *The Customer's full name, address and phone number.
 - *A copy of the Customers original invoice, receipt or bill of sale of the purchase of the Product.

Solteras will provide the customer with instructions regarding how and when the defective product should be returned.

7. THIS LIMITED WARRANTY STATES THE ENTIRE WARRANTY GIVEN BY SOLTERAS, INC. TO THE CUSTOMER. ALL IMPLIED WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE RELEVANT WARRANTY PERIOD. IN NO EVENT SHALL SOLTERAS, INC. BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL LOSSES OR DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS TO THE FULLEST EXTENT THAT THOSE LOSSES OR DAMAGES CAN BE DISCLAIMED BY LAW.

This limited warranty does not affect the Customers statutory rights in law specific to the country of purchase, such rights remain protected.

Pass Key: 0000

www.solteras.com

1-866-SOLTERAS

© 2004 Solteras Inc. All rights reserved.

Solteras, the Solteras logo, and other Solteras marks are trademarks of Solteras and may be registered. All other trademarks are the property of their respective owners.

Bluetooth is a trademark owned by Bluetooth SIG, Inc. USA and licensed to Solteras.