

# Lost-n-Found

## Instruction Sheet

### To Operate:

1. Clip sensor(s) to item(s).
2. When you need to locate an item, turn on main unit.
3. Carry main unit from room to room and press the associated key.
4. When item is located, the sensor will beep three times.

### Replacing Batteries:

Lost-n-Found uses 2 x "AAA" batteries.

#### Suggest using good quality alkaline batteries.

1. Use a Phillips head screwdriver to loosen the screw on the battery compartment cover and lift the cover.
2. Put the batteries into the compartment using care to match polarity (+/-) as marked inside.
3. Replace the cover and tighten the screw.

#### Sensor Clip use one CR-2032 battery

1. Use a Phillips head screwdriver to loosen the screw on the battery compartment cover and lift the cover.
2. Put the battery into the compartment using care to match polarity (+/-) as marked inside

### CAUTION:

- Only adults should replace batteries.
- Replace the batteries when the Lost-n-Found stops operating properly.
- Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Use only fresh batteries of the required size and recommended type.
- Dispose of old batteries promptly and properly. Do not burn or bury them.
- If you do not plan to use your Lost-n-Found for several weeks, remove the batteries. Batteries can leak chemicals that can harm electronic parts.

### Compliance with FCC Regulations

This equipment has been tested in accordance with the requirements contained in the appropriate Federal Communications Commission regulations on Part 15. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio technician for help.

### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



© 2004 Summit Products, Inc.  
Trussville, AL 35173

Printed in China.