



VISUAL LAND
Bring the World Home

Prestige

android tablet

Guide Book

Copyright © 2014 Visual Land Inc. All rights reserved.

Google, Android, Gmail, Google Maps, Chrome, Chromecast, Android Wear, Nexus, Google Play, YouTube, Google+, and other trademarks are property of Google Inc. A list of Google trademarks is available at <http://www.google.com/permissions/trademark/our-trademarks.html>. All other marks and trademarks are properties of their respective owners.

This book introduces Android 5.0, Lollipop for Google Play edition devices. Its content may differ in some details from some of the products described or the software that runs on them. All information provided here is subject to change without notice.

For best results, make sure you're running the latest Android system update. To find your device's version number or check for the latest system update, go to  **Settings > System > About tablet** and look for **Android version** or **System updates**.

Table of contents

1	Welcome to Android	1
	About Android 5.0, Lollipop	1
	Android Wear	2
	Set up your device	2
	Make yourself at home	3
	Send an email	4
	Status bar	3
	Quick Settings	3
	Manage battery life	4
	Get around	5
	Navigation buttons	5
	Menus	6
	Organize your Home screens	7
	Touch & type	9
	Android version & updates	10

2 Essentials	00
Google Now	00
How it works	01
Try it	02
What you can ask Google to do for you	03
Turn “Ok Google” on or off	03
Display	03
Sound and notification	04
Manage accounts on your device	06
Add an account	06
Remove an account	07
Share your device with other users	08
Switch users	1/
Remove a user	1/
Guest user	1/
Security	10
Smart Lock	10
Protect against harmful apps	11
Chromecast	12
File storage	13
Screenshots	14

3	Use the keyboard	15
	Enter & edit text	15
	Use next-word suggestions	18
	Gesture Typing	2/
	Keyboard dictionaries	20
	Type by speaking	20
4	Try some apps	22
	All Apps	22
	Gmail	23
	Google Play	25
	Camera	26
	Photos	3/
	Contacts	30
	Hangouts	31
	Calendar	31
5	Settings	33
6	Accessibility	35

Welcome to Android

About Android 5.0, Lollipop

Android 5.0, Lollipop is the latest version of Android, the operating system that powers not just tablets, but also wearables, TVs, and even cars.

Android 5.0 features a bold and bright new design, 3D graphics support that are as good as on a desktop computer:

- Add guest users and other users without providing them access to your email, contacts, and whatever else you don't want to share.
- Easier ways to manage battery usage, including a battery saver feature to extend battery life.

Android Wear

Android Wear organizes your information, suggests what you need, and shows it to you before you even ask. Get messages from your friends, meeting notifications, and weather updates at a glance.

Set up your device

When you first turn on your tablet, you'll see a Welcome screen. Choose the language you want and touch the arrow to continue.

IMPORTANT: To complete the setup process, it's best to have a Wi-Fi connection.

When prompted, sign in with your Google Account or create one at that time. Signing in lets you immediately access everything associated with your Google Account, like Gmail. If you prefer, you can skip this step and create an account later.

An email address that you use for any of the following counts as a Google Account:

- Gmail
- YouTube
- Google Play
- Google Apps
- AdWords
- Any other Google product

Signing in with a Google Account helps you get up and running quickly. When you sign in, you can easily get all the apps you've purchased on Google Play onto your new device. All the email, contacts, calendar events, and other data associated with that account are automatically synced with your device.

If you have multiple Google Accounts, you can add others later from  **Settings > Personal > Accounts**. You can also add guest users in  **Settings > Device > Users**.

Make yourself at home

After you finish setting up your device, the Home screen appears for the first time. Here, you can add app icons and widgets (an "at-a-glance" view of an app's most important information) to your Home screens to easily find them.

- To move between Home screens, swipe left or right.
- To see notifications, swipe down from the top of the screen with one finger.

Send an email



Use the Gmail app to read and write email from your Gmail or other email addresses.

1. Touch Gmail on a Home or All Apps screen.
2. If you already signed into a Gmail account during setup, your email will be synced to your device. Otherwise, add an email address now.

Status bar

The status bar is at the very top of the screen. On the right, you can see the Wi-Fi and mobile signal strength, how much battery power is left, and the time. On the left, you can see which apps have sent you notifications. See ["Sound & notification" on page 19](#).


Quick Settings

Use Quick Settings to easily get to frequently used settings, like turning on airplane mode. To open Quick Settings, swipe down from the top of the screen with two fingers or twice with one finger. To change a setting, just touch the icon:

- **Wi-Fi network:** Turn Wi-Fi on or off. To open Wi-Fi settings, touch the Wi-Fi network name.
- **Airplane mode:** Turn airplane mode on or off.

- **Display brightness:** ☀️ Slide to lower or increase the brightness of your screen.
- **Auto-rotate:** ⏺ Lock your device's orientation in portrait or landscape mode.

Quick Settings look like this:



Open the main Settings app by touching  **Settings** in the top right.

You can also turn Auto Rotate on or off from Quick Settings, to lock or unlock automatic screen rotation.

Manage battery life

The status bar shows how much battery you have left, but you can also see the exact percentage and approximate time of battery life remaining. Swipe down from the top of the screen, then touch  **Battery**.

Your Android device's battery is built to get you through your day. When you're running low, Android's battery saver conserves your battery power.

To turn it on, go to  **Settings > Battery > Battery saver**. For more information, visit [Manage battery life](#).

Get around

At the bottom of every Home screen you'll find the Favorites tray: another quick way to get to your apps.



To open an app, touch it. To drag an app in or out of the Favorites tray or anywhere else on a Home screen, touch & hold it, then move it with your finger where you want it.

Navigation buttons

At the bottom of most tablet screens, no matter what you're doing, you'll always find the navigation bar with three buttons.



Back

Opens the previous screen you were working in, even if it was in a different app. Once you back up to the Home screen, you can't go back any further.



Home

Opens the central Home screen. To open Google Now, swipe up.



Overview

Opens a list of thumbnail images of screens you've worked with recently. To open one, touch it. To remove a screen from the list, swipe it left or right or touch on the X.

Some apps hide these buttons temporarily, or fade them to small dots in the same position. To bring them back, touch the dots, touch the screen in the middle, or swipe up from the bottom.

Menus

Many screens in Apps and in Settings include a  **Menu** icon at the top right of the screen. Touch it to explore additional options, including Help and Settings.

Organize your Home screens

- To change your wallpaper, add a widget, adjust Search settings, or change screen order, touch & hold the background of any Home screen.
- You can have any number of Home screens to the right. To add a new screen, swipe to the rightmost screen and drag an app or widget to the right edge.
- The screen to the left of the main Home screen is reserved for Google Now, and is available only when Google Now is turned on.
- To create a folder, slide one icon quickly on top of another.
- To name or rename a folder, open it and touch its name.

To change the wallpaper:

1. Touch & hold the background, then touch  Wallpapers.
2. Swipe right to left to choose a wallpaper image. Or choose an image from your Photos, Downloads or Drive.

To add an app icon to a Home screen:

1. Go to the Home screen where you want to place the app.
2. Touch  All Apps.
3. Swipe from right to left, if necessary, to find the app you want.
4. Touch & hold the app until the Home screen appears, slide it into place, and lift your finger.

To add a widget:

1. Touch & hold the background, then touch Widgets. Open **All Apps > Widgets**.
2. Swipe right to choose a widget, which provides a quick view or way to access information on your home screen, like a larger size clock or a view of information in your Google Play library.

To move an app or widget to another position:

1. Touch & hold the icon.
2. Slide your finger to the new position.

To move between Home screens, slide toward the edge of the screen.

To bump another icon out of the way, slide slowly into it.

3. Lift your finger.

Touch & type

To select or activate something, touch it.

To type something, such as a name, password, or search terms, just touch where you want to type. A keyboard pops up that lets you type into the field.

Other common gestures include:

- **Touch & hold.** To select an item, touch & hold it by not lifting your finger until something happens. This is how you access accent and other special characters on the keyboard. Slide your finger to the accented letter you need.
- **Touch, hold, & drag.** Touch & hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. You can move apps around on the Home screen.
- **Swipe or slide.** Quickly move your finger across the surface of the screen, without pausing when you first touch (so you don't drag something instead). Slide a Home screen left or right to view the other Home screens.
- **Double-tap.** Tap quickly twice on a map or image to zoom in and out.
- **Scale.** In some apps (such as Maps, Chrome, and Photos), you can scale by placing two or more fingers on the screen at once

and pinching them together (to enlarge scale) or spreading them apart (to reduce it).

- **Rotate the screen.** The orientation of most screens rotates with your device as you turn it. To keep your screen locked in Portrait mode, swipe down with two fingers from the top of any screen and touch  Portrait/Auto-Rotate in Quick Settings.

Android version & updates

To check your version number or get the latest system update, first go to  **Settings > System > About tablet.**

Then look for these labels:


- **System updates.** Touch to check whether you have any pending system updates.
- **Android version.** Look partway down the list for this heading and the number just below it.

Essentials

Google Now

Google Now is about getting you just the right information, at just the right time. It tells you today's weather before you start your day, how much traffic to expect before you leave for work, and even your favorite team's score while they're playing.

For example, here's a Google Now card that appears when you're about to start your commute:



After you start using Google Now, you don't need to do anything else. If you like, you can fine-tune some settings, but Google Now doesn't need any elaborate setup.

How it works

To know when to show information you'll find useful, Google Now uses contextual data from your device and from other Google products, plus data from third-party products that you allow Google Now to access. For example, if you have an appointment in Google Calendar that includes an address, Google Now can check traffic and suggest when to leave.

When you decide to use Google Now, you're also turning on Location Reporting and Location History:

- **Location Reporting** allows Google to periodically store and use your device's most recent location data in connection with your Google Account. Location Reporting is a per-device setting.
- **Location History** allows Google to store a history of your location data from all devices where you're logged into your Google Account and have turned on Location Reporting.

You can control how Google Now uses your current location. To view the relevant settings, go to  **Settings > Personal > Location**. When location services are turned on for your account on a given device, certain apps can use them to give you more relevant information, such as nearby restaurants or commute traffic.

To learn more about how Google Now uses your location and other information, visit <https://www.google.com/mobile/locationhistory/>.

Try it

You have a chance to turn on Google Now when you first set up your device. You can also turn it on or off at any time:

1. Touch & hold any empty space on your Home screen.
2. Go to  **Settings > Google Now.**

To open Google Now, swipe up from the Home button. Updates appear in the form of Google Now cards. When you don't need a card anymore, swipe it from left to right. Swiping from right to left returns you to the main Home screen.

When you want to see more cards, touch **More** at the bottom of the screen.

To adjust the way certain cards get updated:

- Manage reminders: From the  **Menu** at the top left of the screen, touch  **Reminders**.
- Request updates for your sports teams, stocks, and more: From the  **Menu**, touch  **Customize**.
- Customize other updates: At the top right of each card, touch the  three dots.

What you can ask Google to do for you

When you use Google Now, you can speak to your device to search, get directions, and create reminders. For example, say “Ok Google, do I need an umbrella tomorrow?” to see if there’s rain in the weather forecast.

Turn “Ok Google” on or off

You can start a search or task by saying “Ok Google.” To turn it off or on, open Google Now or the Google app and touch **Menu > Settings > Voice > OK Google detection**.

Display

Change the display settings on your device by following these steps:

1. Go to  **Settings > Device > Display**.
2. Choose from the following settings. Some of these settings may vary by your device and version of Android. All can affect battery life. See “[Manage battery life](#)” on page 8 for more information.
 - **Brightness level:** Move the  slider to set the brightness level on your device.
 - **Adaptive brightness:** Turn on adaptive brightness to automatically optimize the brightness level on your device based on the available light around you. Adaptive brightness is on by default. You can still adjust your brightness when needed.
 - **Sleep:** Change how long it takes for your device’s screen to go black when you’re not using it. Learn more about [Sleep Settings](#).
 - **Daydream:** Set up screensavers that display photos, color-

ful backgrounds, and more when your device is charging or docked.

Sound & notification

You can change the sound and notification settings on your device by going to  **Settings > Device >  Sound & notification**.

Notifications alert you to the arrival of new messages, calendar events, and alarms, as well as ongoing events, such as downloads:

- **Interruptions.** Prioritize sound notifications so they don't interrupt you. In Downtime, select which days and times you allow for sound notifications
- **When device is locked.** Sensitive content includes things like the title of a song you downloaded, who sent you an email, or the details of a calendar event. For more information, visit the [Help Center](#).
- **App Notifications.** Modify the notification settings individually for apps such as Gmail. The setting under **When device is locked** will always take precedence over the setting for an individual app.
- **Notification access.** See which apps can access your notifications.


When a notification arrives, its icon appears at the top of the screen. Icons for pending notifications appear on the left, and system icons showing things like the Wi-Fi signal, mobile carrier signal, or battery strength are on the right:



Certain notifications can be expanded to show more information, such as email previews or calendar events. The one at the top is always expanded when possible. To expand a notification, position one finger inside it and swipe down slowly.

To open the related app, touch the notification icon on the left. Some notifications also allow you to take specific actions by touching icons within the notification. For example, Calendar notifications allow you to Snooze (remind you later) or send email to other guests.

When you're finished with a notification, swipe it away. To dismiss all notifications, touch  **Dismiss** at the very bottom of the notifications list.



Manage accounts on your device

You can add accounts so that information associated with that account automatically syncs with your device. You'll need to set up an account on your device if you want to get email or get apps on Google Play.

You can also [add multiple users](#) for your device, like if several people share a tablet. Adding users is different from adding accounts. Each user has separate settings and can't access the accounts of other users, whereas a single user can have multiple accounts and switch between them anytime they're signed in. Make sure you're signed in as the correct user before adding or removing any account information.

Add an account

1. Go to  **Settings > Personal > Accounts**. Touch "Add account."
2. Touch the type of account you want to add. You may be able to choose from choices like "Google," "Personal (IMAP)," or "Personal (POP3)." If you're not sure whether to choose IMAP

or POP3, try IMAP first. Many email services use IMAP.

- i. Choose “Google” if you want to add your Google Account. When you sign in with a Google Account, all the email, contacts, calendar events, and other data associated with that account are automatically synced with your device.
- ii. Follow the on-screen instructions to add the account.

To change the settings of any of the accounts you added, follow these steps:

1. Go to  **Settings > Personal > Accounts.**
2. Select your account. If you’re using a Google Account, touch Google and then your account.

Remove an account

When you remove an account that you’ve added to your device, everything associated with that account, including email, contacts, and settings is also deleted. You can’t remove the account you used to initially set up your device.

To remove an account from your device, follow these steps:

1. Check to see if the account you want to remove is the account you used to set up your device.
 - If it’s not, go to step 2 and follow the instructions.
 - If it is, reset your device to its factory settings instead of following the steps below. This erases all of the data from your device and you’ll need a Google Account to set up your device again.
2. Open the  Settings menu on your device.

3. Under “Accounts,” touch the name of the account you want to remove. If you’re using a Google Account, touch Google and then the account.
 - When you sign out of your Google Account, all the email, contacts, Calendar events, and other data associated with that account will no longer automatically sync with your device.
4. Touch  **Menu** in the top right corner of the screen.
5. Touch **Remove account**.

Share your device with other users

You can easily share your device with family and friends by creating a separate user for each person. Each person has their own space on the device for custom Home screens, accounts, apps, settings, and more. You must be the device owner to add users.

To add a new user, follow these steps:

1. Go to  **Settings > Device > Users**.
2. Touch **Add user**, then touch **OK**.
 - i. If you’re with the new user: Touch “Set up now” and you’ll be taken to the lock screen. Select the new user, unlock the screen, and allow them to set up their Google Account and other details.
 - ii. If the new user isn’t around: Touch “Not now.” A “New user” will appear in the list. The next time you’re with the user, go back to the user list and select “New user” or click the user image on the lock screen.

After a user is set up, when you go to the lock screen, you’ll see a second user profile picture or avatar in the status bar. To choose a user, touch the picture and unlock the screen. Each user can [set their own screen lock](#).

Switch users

To switch users, swipe down from the top of any screen twice to open Quick Settings. Touch the image of the current user in the top right corner of the screen, then touch another user's image.

Remove a user

The device's owner can delete any user that they added:

1. Go to  **Settings > Device > Users**.
2. Touch  next to the user's name, then touch **Remove user**.

Other users can only delete their own space.

1. Go to  **Settings > Device > Users**.
2. Touch  **Menu > Delete *username* from this device**.

Guest user

If someone wants to temporarily use your device, but they don't need to be set up as a regular user, they can use it as a guest.

Guest users don't have access to your mail, your apps, or any content on your device that's tied to your account, like photos or downloaded files. You must be the device's owner to add a guest.

1. Go to  **Settings > Device > Users**.
2. Touch **Guest**.

When your guest is finished using your device, you can switch back to another user.

To switch to another user: Swipe down from the top of any screen, and then touch the bar at the top to open Quick Settings. To choose another user, touch the image in the top right corner of the screen, then touch another user's image.

Security

If a lock is set for your screen, the screen goes dark and locks when the display goes to sleep or if you press the Power button.

You can set locks of different strengths using Screen Lock settings:



1. Go to **Settings > Personal > Security > Screen lock.**
2. Touch the type of lock you'd like to use.

Even when your screen is locked, you can perform certain activities.

- **Quick Settings:** Slide down from the top of the screen to open Quick Settings without entering your password.
- **Camera:** Slide from right to left to open the Camera.

If you have a device that's set up for more than one user, you may need to touch your image at the bottom of the screen to see your own locked screen.

For more information, visit [Customize the screen lock](#).

Smart Lock

You can turn on Smart Lock to keep your device unlocked when it's clear that you have it with you—for example, when it recognizes your face.

Trusted devices and face matching

You can have your device unlock when it recognizes your face. After setting a trusted face, every time you turn on your device, it will search for your face and unlock if it recognizes you.

Note: Face matching doesn't store any photos of you. Data used to recognize your face is only stored on your device and is not accessible by apps or backed up on Google servers.

Protect against harmful apps

Apps from Google Play are always verified by Google to protect you and your device from harm. By default, your device doesn't allow the installation of apps from sources other than Google Play.

If you choose to allow the installation of apps from unknown sources and install apps from sources other than Google Play, it's more likely that apps will be installed that could harm you or your device.

If you allow the installation of apps from unknown sources, the Verify Apps feature protects you when installing apps outside of Google Play by continually checking your device to make sure that all apps installed are behaving in a safe manner, even after installation.

Chromecast

Chromecast is a small device that plugs into the back of your TV. It allows you to send videos and music straight from your or tablet to your TV. You can use Chromecast with apps like:

- YouTube
- Netflix
- Google Play Movies & TV
- Google Play Music
- Hulu Plus

To see more apps, visit chromecast.com/apps.

When using Chromecast, make sure your tablet is using the same Wi-Fi network as your Chromecast, and that Chromecast is selected as your TV's source input.

To display content from your tablet on your TV:

1. Open the video or music in one of the apps listed above.
2. Touch  Cast.
3. Play the content as usual to stream it to your TV.

File storage

Android 5.0 makes it easy to store and browse through pictures, videos, and other files on your device and attach them to an email, Hangout message, and so on. You can also use stored images as your Home screen wallpaper.

For example, to attach an image to an email you're composing, touch the  Paper Clip in the top right and choose to either **Attach file** or **Insert from Drive** to select stored images in your Drive folder.

From here, you can view any of these sources:

- **Recent** shows you the photos or videos you've taken or opened most recently.
- **Drive** lets you attach any files stored in Google Drive.
- **Images** displays any photos, videos, or other images on your device.
- **Downloads** includes most files (excluding Play content) you've downloaded from emails or the Web
- **Photos** lets you browse all the images and videos that are on your device or have been uploaded to your Google account.



Use the Downloads app to view, reopen, or delete files you download from Gmail or other sources (excluding Google Play books, videos, magazines, and other media.)

In the Downloads app:

- Touch an item to open it.
- In your list of downloads, touch & hold an item to select it. Touch  Share and choose a sharing method from the list.
- Touch  to delete.

Google Play streams purchases and rentals via the Internet. So the purchases and rentals don't always occupy storage space when you play them. Although you can download content in Google Play apps to access offline, Google Play content never appears in Downloads.

Screenshots

To take a screenshot:

1. Make sure the image you want to capture is displayed on the screen.
2. Press the Power and Volume down buttons simultaneously.

The screenshot is automatically saved in your Photos.


TIP: To easily share your screenshot via Gmail, Google+, and more, select your screenshot in Photos and touch  Share at the bottom. Touch  Edit to modify. Touch  to delete. For Google Play edition devices, touch  Share.

Use the keyboard

TIP: To select a keyboard language other than English, go to **Settings, Personal > Language & input**. For more details, visit the [Keyboard help](#).

Enter & edit text

Use the onscreen keyboard to enter text. Here's what it looks like:



Keyboards on tablets work in a similar way. To make the keyboard go away, touch the Back button below it.

Some apps open the keyboard automatically. In others, you first need to touch where you want to type.

Basic editing

Change where you want to type	Touch the cursor, then touch and drag the tab that appears below it to the new position.
Select text	Touch and hold or double-tap within the text. The nearest word highlights, with a tab at each end of the selection. Drag the tabs to change the selection.
Delete text	Touch the  Delete key to delete the characters before the cursor or selected text.
Type capital letters	To switch to capital letters for one letter, touch the  Shift key once. You can also touch and hold the  Shift key while you type or you can touch the  Shift key and slide to another key. When you release the key, the lowercase letters reappear.
Turn caps lock on	Double-tap or touch and hold the  Shift key so that it changes to. Touch the  Shift key again to return to lowercase.


Change word capitalization	If you want to quickly change the capitalization of a word you've already typed, you can select it and touch the  Shift key. You'll have the option to select the capitalized word or the word in all capital letters.
Type a symbol or character	To switch to symbol keys for one word, touch the symbol key  once. You can also touch and hold the symbol key  while you type or you can touch the symbol key  and slide to another key. When you release the key, the letter keys reappear.
View more symbols and characters	Touch and hold symbols or characters to get accented characters or additional symbols.
Cut, copy, paste	Select the text you want to cut or copy. Then touch the Cut button  or Copy button  . To paste, touch the space where you want to paste your text and then touch Paste . If you want to replace other text with the text you copied, highlight the text, then touch the Paste button  .

Emoji

Use Google Keyboard to choose from a variety of small, colorful images used to express emotion (known as emoji) to add some fun to your messages.

Depending on your device, you may need to touch and hold the Return key and then slide your finger to the happy face to display emoji. On a tablet, just touch the emoji symbol at the lower right.

You'll see a panel like this. To move between categories, swipe left or right or touch the symbols in the top row. To type an emoji, touch it:



Use next-word suggestions

1. Touch the location where you want to input text.
2. Start typing out a word. When the word you want is displayed in a list above the keyboard, touch it.
3. Continue to touch words unless the one you want doesn't appear. If so, type it.

Android continues to suggest words as you type.



To change your keyboard and input methods, go to **Settings > Personal > Language & input**.

To turn next-word suggestions on or off, go to **Settings > Personal > Language & input > Keyboard & input methods > Google Keyboard > Text correction > Next-word suggestions**.

Gesture Typing

Gesture Typing works best for English. Quality varies for other languages, and some don't support it yet.

To input a word using Gesture Typing:

1. Touch the location where you want to type to open the keyboard.
2. Slide your finger slowly across the letters of the word you want to input.
3. Release your finger when the word you want is displayed in the floating preview or the middle of the suggestion strip. To select one of the other words in the suggestion strip, touch it.

If the word you want isn't shown while using Gesture Typing, you can type it out manually. If you gesture a word and want to change it, touch the word to see other choices in the suggestion strip.

TIP: If there are letters you want to emphasize, like repeated letters, such as the "e" in sleep, pause over the "e" slightly longer before moving on to the next letter.

Use Gesture Typing without the space bar

When you use Gesture Typing, there's no need to use the space bar – just continue to slide your finger across the letters you want to input, then lift your finger to start the next word.



To change Gesture Typing settings, go to **Settings > Language & input > Keyboard & input methods > Google Keyboard > Gesture Typing**.

Keyboard dictionaries

To manage keyboard dictionaries, go to  **Settings > Personal > Language & input**.

Personal dictionary

You can add your own words to your personal dictionary so that your device remembers them. To add a word or phrase, including an optional shortcut, go to  **Settings > Personal > Language & input > Google Keyboard > Text Correction > Personal dictionary** and the language of the dictionary you want to modify, then choose Add and type in the word. When you use the optional shortcut when typing, your word or phrase appears as an option in the suggested words above the keyboard.

Add-on dictionaries

1. Go to  **Settings > Personal > Language & input > Google Keyboard > Text Correction > Add-on dictionaries**.
2. You'll see dictionaries for other languages that you can download to your device.
3. Touch the dictionary you want, then **Install**.

Type by speaking

You can speak to enter text in most places where you can enter text with the onscreen keyboard.

1. Touch a text field, or a location in the text you've already entered in a text field.
2. Touch the  **Microphone** key on the onscreen keyboard.
3. When you see the microphone image, speak what you want to type.

In some languages, you can also enter punctuation by speaking it, like "comma," "period," "question mark," "exclamation mark,"

or “exclamation point.” Supported languages include English, French, Italian, German, Spanish, and Russian.

To improve processing of your voice input, Google may record a few seconds of background noise in temporary memory at any time. This recording remains on the device only temporarily and is not sent to Google.



To change your speech settings, go to **Settings > Personal > Language & input**.

Try some apps

All Apps



To see all your apps, touch All Apps in the Favorites tray on any Home screen.

This is where you can see all your apps, including those you downloaded on Google Play. You can move app icons to any of your Home screens.

From All Apps, you can:

- **Move between screens.** Swipe left or right.
- **Open an app.** Touch its icon.
- **Place an app icon on a Home screen.** Touch & hold the app icon, slide your finger, and lift your finger to drop the icon into your desired Home screen.
- **Browse widgets.** Touch the Widgets tab at the top of any All Apps screen.
- **Get more apps.** Touch Google Play in the list of app icons.

To remove an app icon from the Home screen without removing it permanently from your device, touch & hold it, slide your finger toward the top of the screen, and drop the app over Remove.

To view info about an app from an All Apps screen, touch & hold it, slide your finger toward the top of the screen, and drop the app over  App Info.

TIP: Some apps can harm you or your device. However, you don't need to purchase anti-virus software for Google Play edition devices. Google can verify apps to help prevent harmful software from being installed.

Gmail



Use the Gmail app to read and write email from any mobile device. To open it, touch  Gmail on a Home or  All Apps screen.

Gmail isn't just about email. You can use your Gmail account to sign in to all Google apps and services, including these and many more:

- Google Now, for getting the information you need at just the right time
- Calendar
- People, for keeping track of your contacts
- Google Drive, for working with documents

While you're reading a message:

- Touch the icons along the top of the screen to archive, throw away, and mark as read. Touch  to mark a message as

unread. Look under the  Menu to move, change labels, mute, print and do other actions to the email.

- Swipe left or right to read the previous or next conversation.

Organize your conversations: From the Inbox, touch & hold a conversation to select it. Then use the icons and menu along the top of the screen to manage the selected messages.

To change your settings, add an account, or get help, touch the menu icon or button.

No matter where you are in Gmail, you can always get back to the Inbox by touching the  Back button at the top of the screen.

From the Inbox, touch Menu to open the drawer that reveals available accounts, labels, and so on.

TIP: You can access your email from other accounts, like Microsoft Exchange, in Gmail by adding the account in Gmail Settings.

To add a non-Gmail email account to Gmail:

1. Go to  **Settings > Personal > Accounts > Add account.**
2. Touch the type of account you want to add. You may be able to choose from choices like “Google,” “Personal,” or “Work.”
3. Choose “Google” if you want to add your Google Account. When you sign in with a Google Account, all the email, contacts, Calendar events, and other data associated with that account are automatically synced with your device.
4. Follow the on-screen instructions to add the account.

To change the settings of any of the accounts you added, follow these steps:

1. Open the  Settings menu on your device.
2. Under "Personal," touch "Accounts" and select your account.
If you're using a Google account, touch Google and then your account.

Google Play



Google Play brings together all your favorite apps & games, movies & TV shows, books, music, and news & magazines in one place, so you can reach it from any of your devices.

To open the Google Play app, touch  Google Play.


If you purchased content on Google Play in the past, you'll automatically have access to this content on any Android device – just make sure you're signed in using the same account that you used to purchase it. To check:

1. Open the  Google Play app.
2. Touch  Menu at the top left.

From here, you can view the current account or switch to another, view your purchased apps, check your wish list, and so on.

To set preferences, clear your search history, and turn on user controls, go to  Menu > **Settings**. For example, to filter apps based on maturity level or require a PIN for purchases, touch **Content filtering** or **Require authentication for purchases**.

To find your content, open any of the Google Play apps from the  All Apps screen and touch  Menu.



Google Play support

For more details about Google Play, including email support options, visit support.google.com/googleplay.

Camera



The Camera app lets you take photos, panoramic photos, videos, and immersive 360-degree photo sphere shots, including what's above and below you.

To open Camera:

- From the lock screen, swipe from right to left.
- From the Home screen, touch  Camera.

The first time you open Camera, you may be asked if you want it to remember photo locations. This allows you, for example, to pinpoint the location of a particular photo with Google Maps.

When you open Camera, you can choose from five different camera modes. To see the modes, swipe left to right.

The  Camera icon indicates Camera mode. To take a picture:

1. Frame your subject and watch for the focus ring.
To focus on a different part of the image, touch it. To zoom in, pinch two fingers outwards. To zoom out, pinch two fingers inwards.
2. When the focus ring brackets disappear, touch the shutter button, which is the camera button.
3. To see the image you just took, swipe from right to left. To see stored photos, touch  Photos in the top right. When viewing stored photos, touch  to share,  Edit to modify photos and  to delete.

Keep swiping to see other images in Photos.

To change to a different mode, swipe left to right to show the list of camera modes:




Photo Sphere	To capture a 360-degree or wide angle shot, pan or tilt until the circle in the center of the screen moves over a blue dot and records that portion of the image. Keep moving over the dots until you're finished, then touch the check mark at the bottom of the screen.
Panorama	<p>Touch Panorama to begin taking a panoramic photo.</p> <p>Find your starting point, and touch the shutter to take the first picture in the panorama.</p> <p>To take the subsequent pictures, slowly swivel in place to move the target icon over each gray dot until the dot turns blue.</p> <p>Keep hovering over the dots until all of them are blue and your image is complete. Then touch the check mark at the bottom of the screen.</p>
Lens Blur	Touch Lens Blur, then slowly raise the device following the arrow.
Camera	Touch Camera to take regular pictures.
Video	To start recording a video, touch the video button. Touch it again to stop.

To change settings for each mode such as flash, exposure, and so on, touch the circle with the three dots at the bottom right of the framed image.

Photos



The Photos app gives you instant access to all your photos and videos associated with any Google Account set up on your tablet. To open it, touch  Photos.

To open Photos from the:

- Camera app. Swipe from right to left.
- All Apps screen. Touch  Photos.

When you're signed into your device with your Google Account, the Photos app makes it easy to auto-backup all the photos and videos you take, organize them, and share with friends.

You can also browse, search, crop, edit, and tag photos, and create albums and movies.

Touch  **Menu** to:

- Switch to or from Google+.
- Organize and edit your photos and videos.
- Create and browse albums.
- Explore Auto Awesome animations, panoramas, or merged group shots created for you automatically.
- Browse photos of yourself.

Contacts



The **Contacts** app gives you quick access to everyone you want to reach. To open it, touch the **Contacts** icon on a Home or All Apps screen.

When you first turn on your device and sign into a Google Account, existing contacts from that account are synced with your Contacts app. After that, your contacts stay in sync automatically on your different devices or a Web browser.

If you use Exchange, you can also sync that contact information with **Contacts**.

All your **Contacts** information is available from Gmail, Google Talk, and other apps. As you add contacts from different sources, they're synced automatically across all the places you need them.

When you open the **Contacts** app, you can:

- **View all contacts or favorites.** Choose from the top of the screen.
- **Add a contact.** Touch
- **Read details.** Touch a name to see details for a contact or group.
- **Share the contact** or place a frequently used contact on the Home screen. Touch
- **Edit details.** While viewing a contact, touch
- **Change your settings.** While viewing the main list screen, touch

Hangouts



With Hangouts, you can share photos and your location with others. On some devices, Hangouts is also your default messaging app.

Calendar



Use the Calendar app to view and edit your schedule. To open it, touch **Calendar** on a Home or All Apps screen.

When you first set up your Android device, you have a chance to configure it to use a Google Account (such as Gmail). The first time you open the Calendar app on your tablet, it displays any existing calendar events from that Google Account on the web.

As you edit events, they're synced automatically across all the places you need them.

To change the Calendar view, touch the **⋮ Menu** and choose **Schedule**, **Day**, or **Week** from the top of the screen.

From any of these views, you can:

- **Read or edit event details.** Touch an event to view its details.
- **Manage events and calendars.** Touch icons across the top of the screen or the menu to search or create events, return to today, or adjust settings.

To email everyone who is invited to an event, you have two

- Open the event from the Calendar app at any time and touch **Email guests**. You have a list of quick responses or you can write your own.
- When a notification of the event arrives just before the meeting starts, swipe down the notification shade. Then swipe using one finger to expand the notification if necessary, and touch **Email guests**.

Settings



Settings controls the core Android settings for networks, hardware, location, security, language, accounts, etc.

The fastest way to adjust system settings that you access frequently, such as Wi-Fi or brightness, is through Quick Settings. See “[Quick Settings](#)” on page 7.

You can control many other settings for your device and account by swiping down from the top of the screen twice and touching . These are the main types of device or account settings available.

- [Wireless & networks](#). Wi-Fi, data usage, Android Beam, and related settings.
- [Device](#). Sound, battery, sleep, and other display settings.
- [Location](#).
- [Language](#).
- [Sync](#).
- [Backup/reset options](#).
- [Accounts](#).
- [Security](#). Passwords and certificates, screen lock, encryption, and app installation sources.
- System. [Date, time, accessibility](#), and [device information](#).

Most apps also include their own settings, typically available from the  menu on the upper left side of the app, or from the  **Menu > Settings**. On Google Play edition devices, settings may be in the Menu button.

Some useful settings are also available from the Google Settings app.



The Google Settings app let you adjust preferences for commonly used Google apps and services in one place, including Google+, Location, Search, and the Android Device Manager.

To open Google Settings, touch the  in  All Apps.

From here, you can also:

- Control how interest-based Google ads are displayed in non-Google apps.
- Under Connected apps, you can view all the apps that have access to your Google Account information, including the type of access granted to each app.

Accessibility

To use the accessibility options, open  **Settings > System > Accessibility**.

To view detailed information about setting up these options, visit [Android Accessibility](#). Options for people with visual impairments include the following:

Captions: You can turn on captions for your device and specify the language, text size, and style. For some apps, you have to turn on the captions in the app itself.

TalkBack is a screen reader.

It uses spoken feedback to describe events, such as notifications, and the results of your actions, such as opening an app. When TalkBack is on, you have to double-tap in order to select something. TalkBack settings let you control the nature of TalkBack speech, feedback, and touch exploration (Explore by touch).

Explore by touch is a system feature that works with TalkBack, allowing you to touch your device's screen and hear what's under your finger via spoken feedback. It is helpful to people with low or no vision. In TalkBack settings, you can change the settings of Explore by touch, like managing gestures and how lists are scrolled.

Display and sound accessibility options include increasing the text size, changing the speed at which text is spoken, color inversion, color correction, and high contrast text.

If you have low vision and don't plan to use Explore by Touch, visit support.google.com/android to see Help content formatted for sighted users. You can make reading and navigating this material easier by increasing the text size – just open Chrome, go to **Menu > Settings > Accessibility**, and drag the slider to adjust the text size.

You can also try magnification gestures, which allow you to zoom in and out, as well as temporarily magnify what's under your finger. To try magnification gestures, go to  **Settings > Accessibility > Magnification gestures**.

FCC Compliance:

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including Interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

