

Bluetooth®Keyboard
Instruction manual

Thank you for purchasing the Tech & Go Bluetooth®Keyboard. It pairs easily with phones, media players, tablets, laptops, desktop computers and other devices equipped with wireless Bluetooth® capabilities.

Before using your Bluetooth®Keyboard for the first time, please read these instructions carefully.

Package contents
Bluetooth®Keyboard
This user manual

Important safety information

This keyboard requires the installation of either disposable or rechargeable batteries. Improper use of batteries can result in corrosive fluid release, overheating or explosion. Battery fluid is both toxic and corrosive and can cause burns. To reduce risk of injury, keep your batteries out of reach of children. Do not open or puncture batteries. Do not incinerate or heat batteries, and keep them out of hot places. Remove batteries from the keyboard if they are worn out or if you won't be using the keyboard for an extended period of time. Batteries need to be disposed or recycled in accordance with local laws. To recycle used batteries, contact your local hazardous waste processor, or contact Call2Recycle (website call2recycle.org, phone 877.273.2925) to find the nearest drop-off location for expired batteries. If a battery leaks inside the battery compartment, carefully remove all batteries and clean the battery compartment with a damp paper towel, taking care to not contact skin with the battery fluid. If battery fluid comes into contact with skin, flush with water immediately.

Other precautions

Keep the Bluetooth® Keyboard away from children. This product is not a toy.
Do not drop or toss the keyboard or use excessive force when operating it.
This product is not waterproof and should not be used around water or in areas with excessive moisture.
Keep the keyboard away from excessive heat or cold. Do not expose it to direct sunlight. Avoid operating or storing the keyboard near fire, on stoves, or inside sealed cars in hot weather.

Schematics

Navigation keys

Multimedia control keys

Bluetooth® status indicator

Numeric keys

Enter/return key

"fn" key (hold down to activate F1-F12)

Power switch

Pairing reset button

Battery compartment cover

Installing batteries

The Bluetooth® Keyboard requires two "AAA" batteries which are not included. Your keyboard will perform best with disposable alkaline or rechargeable nickel metal hydride (NiMH) batteries. To install batteries, first remove the cover from the battery compartment. Then slide the batteries—negative terminal first—into the compartment. Replace the battery compartment cover.

Pairing

Before using, you must first pair the Bluetooth® Keyboard to your Bluetooth®-equipped device or computer. Your Bluetooth®-enabled device must be able to use the HID profile (not all Bluetooth® devices include this profile).

To pair the device, first slide the power switch to "on". The indicator should blink one second. Press connect button. The Bluetooth® status indicator should slowly blink blue.

Use your device's Bluetooth® menu to activate device searching. The menu might say "Search for new devices," but the exact wording may vary. Once you have begun searching, the device name "Tech&Go Bluetooth Keyboard" should appear in the menu. Choose to pair with the "Tech&Go Bluetooth Keyboard" Your device will then provide you with password pairing code. Using the numeric keys on the top of the keyboard, type the password pairing code provided by your device and then press the "Enter/return" key. If the pair is successful, the Bluetooth® status indicator should turn off.

If the pair is not successful, use a paper clip or small screwdriver to hold down the pairing reset button on the bottom of the keyboard until the Bluetooth® status indicator slowly blinks blue. Then try the pairing process again.

Keyboard use

The keyboard should function like a normal wired keyboard. You should be able to operate the keyboard

up to about 32 feet (10 meters) from the Bluetooth® receiver.

Special function keys

The navigation keys and the multimedia control keys can be used as operational shortcuts. These keys may perform differently based on the type of device connected to the keyboard. For example, not all devices and computers will respond to the audio controls. Function keys that work with iPhone® devices may not function identically with Android™ devices, and vice versa.

Troubleshooting tips

- If you're having trouble pairing the keyboard to your mobile device, first ensure the power switch is in the "on" position.
- Then check to see if the status indicator is slowly blinking with a blue light; if not, turn the keyboard off and then on again.
- If the status indicator remains dark when you turn the power switch to "on," the batteries in the keyboard need to be charged or replaced.
- Your device needs to have Bluetooth® active and it needs to be actively searching for new devices.
- Some Bluetooth®-equipped devices do not carry the HID profile; your device needs to be equipped with the HID profile to use the keyboard.
- The distance between your device and the keyboard may need to be less than 32 feet (10 meters); for pairing it may be optimal to keep your device next to the keyboard.
- The password will be different with each pairing. Remember that you must type the password on the Bluetooth® Keyboard, not on your device, and you must press "Enter/return" afterwards.
- To clear the Bluetooth® Keyboard's memory of paired devices, hold down the pairing reset button until the Bluetooth® status indicator slowly blinks blue.

One-Year Limited Manufacturer's Warranty

E-filliate warrants to the consumer that the Product and all accessories provided in the sales package ("Product") are free from material defects in material and workmanship when used normally and in accordance with operation instructions. The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase.

If we repair or replace a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to repaired or replacement Products for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining on the original one-year limited warranty, whichever is longer. During the limited warranty period, E-filliate will repair or replace (at E-filliate's option) without charge, a Materially Defective Product. If we repair this Product, we may use new or refurbished replacement parts. If we choose to replace this Product, we may replace it with a new or refurbished Product of the same or similar design. E-filliate will return repaired or replacement Products to you in working condition. We will retain defective parts, or equipment. Repair or replacement of Product is your exclusive remedy.

This warranty does not cover Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion, or Product that has been damaged due to repair, alteration or modification by anyone other than an E-filliate authorized representative.

Customer service

We're here to help. If you have a problem with this product or have questions on how to use it, please contact E-filliate Inc. You do not need to contact the retailer you purchased this product from. Please contact one of our service representatives before shipping merchandise to us.

www.efilliate.com

support@efilliate.com

(800) 592-7031

(916) 858-1000

FAX (916) 858-1009

11321 White Rock Road

Rancho Cordova CA 95742

Customer service representatives are available between 8 a.m. and 5 p.m. Pacific Time, Monday-Friday.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Trademarks

Tech & Go is a trademark of E-filiate Inc.

Android™ is a trademark of Google Inc.

Bluetooth® is a registered trademark of Bluetooth® SIG, Inc.

iPhone® is a registered trademark of Apple Inc. This product is not licensed, designed, endorsed or manufactured by Apple Inc.

All other marks are properties of their respective owners.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS
EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S
AUTHORITY TO OPERATE THE EQUIPMENT.