

Wireless Module User Manual

Ambient Corporation 79 Chapel Street Newton, MA 02458 USA

Tel.: +1-617-332-0004 Fax: +1-617-332-7260

WWW: http://www.ambientcorp.com

Email: info@ambientcorp.com

Ambient and the Ambient logo are trademarks of Ambient Corporation.

© Copyright 2003-2005 Ambient Corporation. All rights reserved.

IMPORTANT INFORMATION

DISCLAIMER OF WARRANTIES

AMBIENT DISCLAIMS ALL WARRANTIES OF ANY KIND WITH RESPECT TO THE AMBIENT PRODUCT(S), EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ALL WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL AMBIENT, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR THE LOSS OF PROFIT, REVENUE OR BUSINESS, PROPERTY DAMAGE, PERSONAL INJURY, LIABILITY, LOSS OF LIFE, LOSS OF USE OF DATA OR INTERRUPTION OF BUSINESS EVEN IF AMBIENT SHALL HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. AMBIENT DOES NOT WARRANT THE FUNCTIONING OF THE AMBIENT PRODUCT(S) IN CONJUNCTION WITH SOFTWARE OR HARDWARE NOT PURCHASED, LICENSED, SUBLICENSED OR OTHERWISE APPROVED FOR USE WITH THE AMBIENT PRODUCT(S) BY AMBIENT. OR THAT THE OPERATION OF THE AMBIENT PRODUCT(S) WILL BE UNINTERRUPTED OR ERROR FREE. THE LIABILITY OF AMBIENT HEREUNDER SHALL IN NO EVENT EXCEED THE MAXIMUM AMOUNT PAID TO AMBIENT BY CUSTOMER FOR THE AMBIENT PRODUCT(S).

COPYRIGHT NOTICE

THIS DOCUMENT IS SUBJECT TO U.S. COPYRIGHT LAWS. YOU MAY NOT COPY, REPRODUCE OR TRANSMIT ANY PART OF THIS DOCUMENT WITHOUT THE EXPRESS WRITTEN PERMISSION OF AMBIENT. COPYING INCLUDES TRANSLATION INTO ANOTHER LANGUAGE OR FORMAT.

Important Information	Wireless Module User Manual
THIS PA	GE INTENTIONALLY LEFT BLANK
	D N 00 0001 001 7
Page iv	Doc. No. 06-0021-001 Rev. 1.1

Table of Contents

Regu	ulatory Notice	1
1.1	Federal Communication Commission Interference Statement	1
1.2	End Product Labeling	2
1.3	Manual Information That Must be Included	2
Spec	cifications	3
2.1	General	3
2.2	RF Information	3
2.3	Environmental	4
2.4	Physical Specifications	4
Insta	allation	5
3.1	Module Installation	5
3.2	Antenna Installation	5
Soft	ware Configuration	7
Tech	nnical Support	9
	1.1 1.2 1.3 Spec 2.1 2.2 2.3 2.4 Insta 3.1 3.2 Soft	1.2 End Product Labeling 1.3 Manual Information That Must be Included Specifications 2.1 General 2.2 RF Information 2.3 Environmental 2.4 Physical Specifications Installation 3.1 Module Installation

Table of Contents	Wireless Module User Manua
Table of Contents	Wireless Module User Manual
	4.THIS PAGE INTENTIONALLY LEFT BLANK

1. Regulatory Notice

1.1 Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device is intended only for OEM integrators under the following conditions:

- (1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- (2) The antenna should be integral if the end device is intended to be operated in 5.15 ~5.25GHz frequency range.

As long as the 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.).

IMPORTANT NOTE:

In the event that these conditions can not be met (for example, certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

1.2 End Product Labeling

This transmitter module is authorized only for use in device where the antenna may be installed such that 20 cm may be maintained between the antenna and users (for example: Access Point, Router). The final end product must be labeled in a visible area with the following: "Contains TX FCC ID: SPKCOPWRLAA"

1.3 Manual Information That Must be Included

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the users manual of the end product which integrate this module.

The users manual for OEM integrators end users must include the following information in a prominent location:

"IMPORTANT NOTE: To comply with FCC RF exposure compliance requirements, the antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter".

If the end product integrating this module is going to be operated in $5.15 \sim 5.25 \text{GHz}$ frequency range, the warning statement in the user manual of the end product should include the restriction of operating this device outdoor could void the user's authority to operate the equipment

2. Specifications

2.1 General

Radio Data Rate 802.11a: 6, 9, 12, 18, 24, 36, 48, 54 & 108Mbps turbo mode (Auto-rate capable)

802.11g: 6, 9, 12, 18, 24, 36, 48, 54 & 108 Mbps turbo mode

802.11b: 1, 2, 5.5, 11Mbps

Network Standards WECA (Wi-Fi & Wi-Fi Compliant), IEEE802.11, IEEE802.11a,

IEEE802.11g draft, IEEE802.11b, draft IEEE802.11e, f, h and I

standards, IEEE802.11x (Optional)

Security IEEE802.11x Support for LEAP (Optional)

WPA – Wi-Fi Protected Access (64, 128, 152-WEP with TKIP)

Network Architecture Support ad-hoc, peer-to-peer networks and infrastructure

communications to wired Ethernet networks via Access Point

Drivers Windows 98/ME/2000/XP

Access Protocol CSMA/CA with ACK

Roaming IEEE802.11b compliant

Operating Voltage 3.3V/5V

Regulation

FCC Part 15/UL, ETSI 300/328/CE

Certifications

LED Indicator RF Link activity

2.2 RF Information

Frequency Band 802.11a: 5.15 to 5.25GHz

5.25 to 5.35GHz 5.725 to 5.825GHz

802.11b/g: 2.412 to 2.462GHz (United States)

2.412 to 2.484GHz 2.412 to 2.472GHz 2.457 to 2.462GHz 2.457 to 2.472GHz

Modulation 802.11a/g: OFDM (64-QAM, 16-QAM, QPSK, BPSK)

Technology 802.11b: DSSS (DBSK, DQPSK, CCK)

Receive Sensitivity

(Typical)

802.11a: -86dBm@6Mbps, -80dBm@18Mbps, -70dBM@

48Mbps, -84dBm@9Mbps, -77dBm@24Mbps, -

68dBM@ 54Mbps, -82dBm@12Mbps, -

73dBm@36Mbps

802.11b/g: -91dBm@1Mbps, -85dBm@9Mbps, -77dBM@

36Mbps, -89dBm@2Mbps, -82dBm@12Mbps, -

76dBM@ 48Mbps, -87dBm@5.5Mbps, -80dBm@18Mbps, -73dBM@ 54Mbps, -86dBm@6Mbps, -78dBm@24Mbps

Transmit Output

Power

802.11a: Up to 18dBm

802.11b/g: Up to 21dBm

2.3 Environmental

Temperature Range -10 deg C to 60 deg C (14 deg F to 140 deg F) – Operating

-40 deg C to 70 deg C (-40 deg F to 158 deg F) - Storage

Humidity

(non-condensing)

5% to 95% Typical

2.4 Physical Specifications

Interface Mini PCI TypeIII A

Antenna Two Antenna Connectors(U.FL)

Dimensions 50.9(L) mm x 59.6(W) mm x 4.8.(H) mm

2 (L) in x 2.3(W) in x 0.2.(H) in

3. Installation

3.1 Module Installation

The installation procedure for the wireless module may vary and fully depends upon the design of the particular networking device. Therefore, the OEM shall seek advice from Ambient for the proper installation procedure.

3.2 Antenna Installation

The Wireless Module must be used ONLY with one of the following antennas:

- portable rubber duck for indoor and outdoor applications (Nearson, Model: S181TR-2450R), or,
- omni-directional for outdoor applications (Netgate, Model:ANT-8-OMNI-RPNF)

Section 3 - Installation		Wireless	Module	User	Manual
THIS PAGE	INTENTIONALLY LEFT B	SLANK			
Page 6		Doc No. (ne nn21	001 5	2ov 11

4. Software Configuration

To enable and configure WiFi, edit the following values in the File ds2pl.conf file:

802.11 WIFI configuration

WIFI interface Enabled/Disabled

WIFI=no

Set to YES to enable WiFi

#Mode should be 802.11g or 802.11a or 802.11b

MODE 80211=802.11g

Set to one of the listed values to set the card appropriately. That the supplied antenna must support the desired mode.

#Access_point should be 'yes' to act like an access point and 'no' if not

ACCESS POINT 80211=yes

Should not be edited

#ESSID sets the network name for the wireless network

ESSID 80211=Ambient

The 802.11 name the node will advertise itself as

#Specifies the channel to use - can be obtained using iwlist command

CHANNEL 80211=1

The channel the node will service wireless clients on (values of 1 to 11 permitted)

#Specifies the encryption key to use

ENCRYPTION KEY 80211=6173320004

Set this to the hex value for the WEP encryption key in hex digits XXXX-XXXX-XXXX or XXXXXXXXXXX.

An ASCII string can be used by setting this value to "s:value"

Consult Ambient for the procedure to edit this file.

Section 4 - Software Configuration	Wireless Module User Manual
THIS PAGE INTENTIONALLY LEFT BI	_ANK
	D N 00 0001 001 0
Page 8	Doc. No. 06-0021-001 Rev. 1.1

5. Technical Support

For technical support, contact:

Ambient Corporation 79 Chapel Street Newton, MA 02458 USA

Tel.: +1-617-332-0004 then press 5 for support

Fax: +1-617-332-7260

E-mail: cs@ambientcorp.com

Web site: http://www.ambientcorp.com

Section 5 - Technical Support	Wireless Module User Manual
THIS PAGE INTENTIONALLY LEFT BI	_ANK
Page 10	Doo No 06 0024 004 Dov 4.4
Page 10	Doc. No. 06-0021-001 Rev. 1.1