

2.4GHz WIRELESS
DUAL-WAY
DIGITAL DOORPHONE



FC




USER MANUAL

Features

- 2.4G wireless digital technique, anti-interference and clear communication.
- Wireless dual-way doorphone. Easy installation for DIY market.
- Wireless door release function with encryption technique.
- Adjustable volume

Outdoor station

- Working temperature:
-10°C~50°C
- Adapter
Input voltage: 120V, 60Hz
Output voltage: 12V, 1000 mA
- Dimension
108(W)*157(H)*46(D)mm



- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- This equipment complies with FCCjS and IC's RF radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must be installed and operated to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. Installers must ensure that 20cm separation distance will be maintained between the device (excluding its handset) and users.

Operation instruction

- From outdoor unit to indoor unit: press the push button of outdoor unit, graceful sound from indoor unit will be heard; pick up the handset for talk. Press the door release button to open the door; when the door is open, separate indicating sound will be heard from both indoor unit and outdoor unit. Hang up the handset, both indoor unit and outdoor unit will be in standby status.
- From indoor unit to outdoor unit: no need to pick up the handset, directly press the CALL button, after the indicating sound is heard then pick up the handset for talk; hang up the handset, both indoor unit and outdoor unit will be in standby status.
- Adjustable volume.

Accessories

■One indoor unit	■Two adapters	■One user manual
■One outdoor station	■One bracket	■Screws
■One door releaser	■1m connection cable	

Warning

- Caution: The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.
- Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.

Indoor unit

- Working temperature: -10°C~50°C


- Adapter

Input voltage: 120V, 60Hz

Output voltage: 9V, 300 mA





Wiring diagram



Installation

A. Outdoor station



① Remove the screws and back cover.

② Connect the wire with door releaser and fasten the back cover.



③ Remove the screws and aluminum cover.

④ Take down the name plate for family name or room number and then fasten the outdoor unit on the wall.



⑤ Fasten the aluminum cover.


⑥ Fasten the screws.



⑦ Connect the wire between lock and door releaser as per the wiring diagram and fasten the door releaser on the wall.

⑧ Install the door releaser in the house.

B. Indoor unit



① Fasten the bracket of indoor unit on the wall.

② Hang the indoor unit on the bracket.

③ Plug the adapter in the power jack or outlet.

④ Plug output pin into the power jack or outlet.