

DPV-156 transmitter User manual

FCC CAUTION:

Changes or modifications to this unit not expressly approved by the party responsible for compliance will void the user's authority to operate the equipment. Any change to the equipment will void FCC grant.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
-

All other devices shall bear the following statement in a conspicuous location on the device: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Function and specifications

1. This transmitter can set the frequency signal to between 88.1MHz---107.9MHz and then transmit.
2. This transmitter can memory 4 transmit channels.
3. The LCD screen shows frequency of transmit channels and the LCD have background light, once press the button, the background light will be light accordingly and will be go off automatically after 5 seconds.
4. There are 4 buttons of this transmitter, on/off, up, down and Mem.
5. Frequency of this transmitter is 88.1MHz---107.9 MHz, and can be adjusted every other 0.1MHz.
6. The length of frequency wire for connecting MP3 is 150mm, it's outlier and wrap the shell
7. Use 2 X AAA battery, can also use DC12V power, when input the DC12V power, the battery power will be cut automatically.
8. Size of transmitter: 80*47*20

□□Operation

1. Press button “on/off” to turn on, the LCD screen shows the latest memorized frequency (e.g.: 89.5MHz), then means it’s using the frequency of 89.5MHz to transmit.
2. Press button “on/off” to turn off, the LCD screen shows nothing, if you want to start again, please press button “on/off” once more, then the LCD screen shows the latest memorized frequency.
3. Once need plus frequency, please press button “up”, 0.1MHz/time, if you need plus more, please keep press the button “up” for more than 3 seconds.
4. Once need minus frequency, please press button “Down”, 0.1MHz/time, if you need minus more, please keep press the button “down” for more than 3 seconds.
5. Memory frequency setting:
 - 1) Adjust the transmit frequency to the frequency which need memorized.
 - 2) Keep press on “Mem” for 2 seconds, once see the flashing M1, M2 or M3, then stop pressing button “Mem”, adjust button “Up” or “Down”, set the memorize frequency which you need to use between M1-M4, then press “Mem” again, by then, the flashing M1, M2 or M3 will stop flashing, and the frequency need to be memorized will be memorized between M1 to M4.