
UIC680EZ


Contactless Smart Card Reader

Specification:

Reader	UIC680EZ
Communication Interface	Ethernet LTE (optional) UART x2 USB Host/Device (depend on UIC680FGP model)
SAM	4 slots (Optional)
I/O Connector	Independent Mode: 1. Connector x1 : RS232 w/ 5VDC 1A power input. 2. Connector x1 : UART. 3. Connector x1 : Ethernet. 4. Connector x1 : USB Host/Device(SW config) 5. Connector x1 : I2C connect SAM board. 6. Connector x1 : DC IN CONN
LED Indicators	LAN Indicator x2 (IO Board) Power Indicator x1 (IO Board) System Indicator x2 (IO Board)
Power Supply	5VDC +/- 5%, 4A
Physical Dimension	93 mm x 82 mm x 29.3 mm (Holder Type)
Safety	FCC Class B, CE Class B, IC(ISED)
ESD	±8KV Contact
Operating	Temperature -30°C to 70°C
Storage	Temperature -30°C to 80°C
Humidity	5 to 90% (Non condensing)

Installation guide(RS232 Interface)	
1	Plug the RS232 cable to the port of PC or system
2	The reader will boot up automatically

Photos:



CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF exposure statements

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body or nearby persons..

Canadian Compliance Statement

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) l'appareil ne doit pas produire de brouillage;
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.