



 <p>105.00 mm</p> <p>140.00 mm</p> <p>Wake up light speaker</p> <p>Thank you for choosing our product. Please read this manual carefully before using it.</p>	<h3>UNPACKING YOUR DEVICE</h3> <p>When unpacking, ensure that the following elements are included:</p> <ul style="list-style-type: none"> 1 x Sunrise Alarm Clock (insert 1 x CR2032 battery) 1 x Micro USB Cable 1 x Power Adapter 1 x Instruction Manual <h3>PRODUCT DESCRIPTION</h3> 	<h3>SET UP</h3> <p>Your alarm clock operates on DC 5V 2A power.</p> <ol style="list-style-type: none"> 1. Connect the USB cable to the power adapter and alarm clock. 2. Plug the power adapter to the power socket. <p>only 1 of below adapters is included</p> 	<h3>CLOCK</h3> <h4>Time setting</h4> <p>Once the alarm clock is connected to power, the display flashes.</p> <ol style="list-style-type: none"> 1. When the hours flash, use \downarrow or \uparrow to set the hours. Press \textcircled{A} to confirm and continue. 2. When the minutes flash, use \downarrow or \uparrow to set the minutes. Press \textcircled{A} to confirm and continue. <p>Display brightness</p> <p>Press \textcircled{I} to choose display brightness: low, high or off. Default is high.</p>	<h3>SUNRISELIGHT SIMULATION</h3> <h4>Sunset sound</h4> <p>Under alarm mode F1 or F2 the sunset starts 30 minutes before your alarm time, gradually increasing to match the setted brightness at your alarm time. You need to activate the alarm before you go to sleep.</p> <h4>Alarm mode</h4> <p>5. Press $\textcircled{-}$ or $\textcircled{+}$ to select alarm mode F1, F2 or F3. (F1=Light + Sound; F2=Light; F3=Sound)</p> <h4>Voice recorder</h4> <p>1. Press and hold $\textcircled{Z} / \textcircled{Q}$ until \textcircled{E} displays after voice prompt "DI". 2. When the minutes flash, use \downarrow or \uparrow to set the minutes. Press \textcircled{A} to confirm and continue.</p> <h4>Sound volume</h4> <p>5. Use $\textcircled{-}$ or $\textcircled{+}$ to set the volume from 01 to 15 levels. 6. Press \textcircled{A} to confirm and continue.</p> <h4>Alarm sound</h4> <p>7. Use $\textcircled{-}$ or $\textcircled{+}$ to set a alarm sound (1-8 is preset sound, 9 is recording voice, 10 is FM radio)</p> <h4>Sunset brightness</h4> <p>7. Use $\textcircled{-}$ or $\textcircled{+}$ to set the brightness of sunset light from 01 to 30 levels.</p> <h4>Alarm volume</h4> <p>9. Use $\textcircled{-}$ or $\textcircled{+}$ to set the volume from 01 to 15 levels. 10. Press \textcircled{A} to confirm and continue.</p> <p>Note: Voice recorder function is NOT available during snooze mode.</p> <h4>Sunrise light brightness</h4> <p>Under mode F1 or F2 the sunrise light starts at the setted brightness/sound volume with \textcircled{L} flashes and gradually fades to off over selected minutes with \textcircled{L} appears.</p> <h4>ALARM</h4> <h4>Alarm time setting</h4> <p>11. Use $\textcircled{-}$ or $\textcircled{+}$ to set the brightness of sunrise light from 01 to 30 levels.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. No operation after 10 seconds, the numbers will stop flashing and the interface would drop out and setting would not be saved. 2. Press and hold \textcircled{A} for 3 seconds to start searching for active channel. Once channels are located, they will be saved as P01, P02, up to P4. 3. Press $\textcircled{-}$ or $\textcircled{+}$ to search channel at every 0.1MHz. 4. Press and hold $\textcircled{-}$ or $\textcircled{+}$ to select the saved channel. 5. Use $\textcircled{-}$ or $\textcircled{+}$ to set the volume (0-1). <p>Note:</p> <ul style="list-style-type: none"> To get a good radio signal, pull/unwind antenna and move it around until you get good reception. 	<h3>SUNRISELIGHT SIMULATION</h3> <h4>Sunset sound</h4> <p>3. Use $\textcircled{-}$ or $\textcircled{+}$ to set a sunset sound (1-8 is preset sound, 9 is recording voice, 10 is FM radio)</p> <h4>Alarm mode</h4> <p>4. When the alarm goes off, press any button except $\textcircled{Z} / \textcircled{Q}$ to stop the alarm and turn off the sunset. If no operation, alarm and light would turn off automatically after 5 minutes.</p> <h4>Snooze function</h4> <p>11. Use $\textcircled{-}$ or $\textcircled{+}$ to set the brightness of sunrise light from 01 to 30 levels.</p> <p>Note: During sunrise working, the alarm and radio will work normally at alarm time in the next day.</p> <h4>ALARM</h4> <h4>Alarm time setting</h4> <p>11. Use $\textcircled{-}$ or $\textcircled{+}$ to set the brightness of sunrise light from 01 to 30 levels.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. No operation after 10 seconds, the numbers will stop flashing and the interface would drop out and setting would not be saved. 2. Press and hold \textcircled{A} for 3 seconds to start searching for active channel. Once channels are located, they will be saved as P01, P02, up to P4. 3. Press $\textcircled{-}$ or $\textcircled{+}$ to search channel at every 0.1MHz. 4. Press and hold $\textcircled{-}$ or $\textcircled{+}$ to select the saved channel. 5. Use $\textcircled{-}$ or $\textcircled{+}$ to set the volume (0-1). <p>Note:</p> <ul style="list-style-type: none"> To get a good radio signal, pull/unwind antenna and move it around until you get good reception. 	<h3>BESIDE LIGHT</h3> <h4>Sunset sound</h4> <p>Your alarm clock can be used as a dimmable or coloured bedside light.</p> <h4>Sound volume</h4> <p>1. Press $\textcircled{Z} / \textcircled{Q}$ to turn on white light.</p> <p>2. Use $\textcircled{-}$ or $\textcircled{+}$ to adjust the white light brightness level up to 30. Default is level 10.</p> <h4>Alarm sound</h4> <p>3. Press $\textcircled{Z} / \textcircled{Q}$ to turn off the light directly.</p> <h4>Sunrise light brightness</h4> <p>4. Press $\textcircled{Z} / \textcircled{Q}$ to turn off the light directly.</p> <h4>Alarm volume</h4> <p>5. Press $\textcircled{Z} / \textcircled{Q}$ to preview the recording and quit out after 30 seconds.</p> <p>Note: Voice recorder function is NOT available during snooze mode.</p> <h4>Sunrise function</h4> <p>10. Press $\textcircled{Z} / \textcircled{Q}$ to confirm and finish the sunset setting.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. No operation after 10 seconds, the numbers will stop flashing and the interface would drop out and setting would not be saved. 2. Press and hold \textcircled{A} for 3 seconds to start searching for active channel. Once channels are located, they will be saved as P01, P02, up to P4. 3. Press $\textcircled{-}$ or $\textcircled{+}$ to search channel at every 0.1MHz. 4. Press and hold $\textcircled{-}$ or $\textcircled{+}$ to select the saved channel. 5. Use $\textcircled{-}$ or $\textcircled{+}$ to set the volume (0-1). <p>Note:</p> <ul style="list-style-type: none"> To get a good radio signal, pull/unwind antenna and move it around until you get good reception. 	<h3>BLUETOOTH SPEAKER</h3> <h4>Bluetooth</h4> <p>1. Press $\textcircled{Z} / \textcircled{Q}$ when radio is on, BT speaker starts with voice prompt.</p> <p>2. Connect the speaker with your mobile, use $\textcircled{-}$ or $\textcircled{+}$ to select music and \textcircled{L} or \textcircled{R} to adjust volume.</p> <p>3. Press $\textcircled{Z} / \textcircled{Q}$ again to turn off BT.</p> <h3>SPECIFICATION</h3> <ul style="list-style-type: none"> • AC/DC Adapter Input: 100-240V~50/60Hz 0.5A • Output: 5V 2A • Output for phone charging: 5V = 1A • Power Consumption: 10W • FM frequency band: 87.5-108 MHz 		
<p>1</p>	<p>2</p>	<p>3</p>	<p>4</p>	<p>5</p>	<p>6</p>	<p>7</p>	<p>8</p>	<p>9</p>	<p>V2</p>

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.