

# 2.4GHz radio manual


Item No.: B1160

## 1) Transmitter

Before turning on your vehicle, please familiarize yourself with the controls of the radio transmitter.

You may use the following diagram to confirm the location and function of each of these features.

- A. ON/OFF Switch: Controls power to the transmitter.
- B. Steering Wheel: Steering the vehicle left and right.
- C. Throttle Trigger: Controls the speed and the Forward/Reverse direction of the vehicle.
- D. Throttle Trim: Adjusts the neutral position of the throttle so your vehicle responds correctly to the trigger.
- E. Steering Trim: Adjusts the neutral position of the throttle so your vehicle travels straight.
- F. Throttle Reverse Switch: Reverse the forward/reverse direction of the steering wheel.
- G. Steering Reverse Switch: Reverse the left/right direction of steering wheel.
- H. Antenna: Transmits radio signals to your receiver.
- I. Recharging Jack: you can charge the battery with your charger if you are using rechargeable batteries in your transmitter.  
Caution: You can not recharge Non-rechargeable batteries.
- J. Battery Power Indicators: Signal when it is time to replace your transmitter batteries when the red indicator lit.
- K. Steering Knob: Adjusts the steering angle.
- L. Start button: Channel 3.



## Pin Jumper



## 2) 2.4GHz Frequency Pin Setup

1. Switch on the transmitter.
2. Turn on the receiver power (you can choose any channel), plug the jumper into "BIND/BATT" of receiver. When the indicator starts flashing, that means the receiver comes into the set code mode. At this point, pull out the jumper immediately.
3. The receiver can automatically find the nearest transmitter to match with. Once they match successfully, the indicator would keep lighting (at this moment please plug the jumper into "BIND/BATT" again.) And if the indicator continuously flashes, that means they haven't matched successfully.

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.