

User's Guide

1000DPI  
Mobile Optical Mouse  
Wireless



7

## Approvals

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


## FCC NOTE

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

1




**English** At the bottom of the mouse, follow the direction of the arrow to push gently, at the same time, to pull out the battery cover in opposite direction, to pull out the battery cover.

2



**English** Follow the arrow where how to put the batteries in the right direction.

3




**English** Insert nano wireless receiver into the computer's USB port, turn on the computer power supply, mouse will working normally.

5

**English** When not using the mouse, press the power button on the bottom of mouse for 3~5 seconds to shut down the mouse power for battery power saving. Then press the power button again to re-start the mouse power.



4



**English** **To readily carry the mouse:** (a) Open the battery case. (b) Insert nano wireless receiver inside the compartment by the direction of the arrow. (c) Close the battery case back.

6

**English** **If the mouse LED is blinking blue,** please replace the batteries. **If the mouse is not working:** 1. Make sure the mouse power is on (turn-on / working). 2. Check the battery capacity and installation. 3. Check receiver installation. 4. Try another USB port.



**English** **Battery Warning** Remove batteries when not using your cordless device for long period of time. If the cursor on your screen does not move or moves erratically when you move your mouse. Please change batteries, and exercise care when handling batteries.