

Air pressure transmitter (Starting Equipment)

User's Manual

Version. 2.0(25.5.2010)
THE YOKOHAMA RUBBER CO., LTD.
INDUSTRIAL PRODUCTS TECHNICAL DEPARTMENT

Notice:

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



1. Introduction

This manual covers the composition and the operation, boot and halt, of the air pressure transmitter (FW02).

2. Transmitter

2.1 Composition of the transmitter

The air pressure transmitter consists of a battery section and an antenna section, and is covered with plastic. The features and the composition of the transmitter are shown in Fig 1.



(b) Composition

Fig. 1 Features and composition of the transmitter

3. Operation

3.1 Starting equipment

The air pressure transmitter is controlled by using the starting equipment as shown in Fig 2.





Fig 2 Starting equipment

3.2 Boot & Halt

Put the transmitter on the boot area of the starting equipment, and then boot up and halt the transmitter according to the procedure as below.



■ Power off

