

MODEL #100342 USER GUIDE (PRELIMINARY)

Wireless Remote Temperature Sensor

Uses 3 AAA Alkaline batteries (sold separately)
Mounts to wall with single fastener
Fahrenheit or Celsius modes

OPERATING TEMPERATURE

-20 C to +50 C
-4 F to 122 F

OPERATING VOLTAGE

4.5V (3 AAA Alkaline batteries)

INSTALLATION AND OPERATION

Remove 4 screws, open back cover. Insert batteries. (Follow symbols marked inside of battery compartment.)
Set C/F switch to desired operation. (Celsius/Fahrenheit) Close cover, secure with 4 screws. The unit will start sending signals.
This unit may be hung on a wall over a nail using the keyhole slot in back.
Note: Effective range can be impacted by position of the sending and receiving units, extreme temperatures, and certain building materials. Reposition as necessary to obtain best performance.

FCC STATEMENTS

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.