

**INSTRUCTIONS**

Remove from pool when not in use or while cleaning so unit is not damaged by skimmers or other devices.

This product should be operated in at least 12 inches of water to get the maximum water height.

It is recommended to clean out the filter screen at bottom of unit periodically to ensure proper water flow.

**NOTE:** MP3 player and speakers are not included.

**BATTERY INSTALLATION**

Make sure the product is thoroughly dry before replacing batteries.

**Main Unit**

1. Turn cap on battery casing counter clockwise to open.
2. Remove battery cover and insert four (4) "D" batteries.
3. Line up the notches of the battery cover with the notches on the battery casing and press firmly.
4. Screw cap on battery casing and tighten securely to ensure that water does not seep into battery casing.

**Remote Control**

1. Compress the battery door latch and remove battery door.
2. Insert one (1) 9V battery making sure that the terminals are aligned.
3. Re-insert the battery door into the notches on the casing.
4. Push the door closed until the battery door re-latches.

**NOTE!**


- Do not mix old and new batteries.
- Do not dispose battery into fire. Batteries may explode or leak.
- Do not mix alkaline, standard, or rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- The supply terminal is not to be short circuited.
- Remove exhausted batteries promptly and dispose of properly.
- Batteries are to be inserted with the correct polarity.

**REMOTE CONTROL SET UP**

- Connect 3.5mm jack to audio source (MP3 player, stereo)

**NOTE:** The remote control is a pass through analyzer. The music passes through the remote, unchanged. The fountain will 'dance' without having speakers plugged into the remote control. To hear the sound, you'll need something plugged into the output of the remote control.

**IMPORTANT:** Do NOT put amplified, speaker-level signal into the **Dancing Fountain** remote – only signal level (not amplified, or meant for headphones). Amplified speaker power levels will destroy the remote, and void the warranty.



- Plug speakers into the "OUT" jack on the back of the remote control. A 3.5mm input jack is required (not included).

- Turn on music source. Adjust output volume to MIDDLE setting. Turn on speakers. Adjust volume to preference. Note that the volume of the amplified speaker system does not affect the light display – the frequency analysis happened by the time the signal gets to the speakers.



Great American Merchandise & Events™ (GAME™)  
16043 N. 82nd Street  
Scottsdale, AZ 85260 - 1800 USA  
tel: 888DUCKY88 (382.5988) email: [products@game-group.com](mailto:products@game-group.com)  
fax: 602.957.POOL (7665) [www.game-group.com](http://www.game-group.com)

Designed in the USA.  
Made in China.  
U.S. Patent 7,413,319

- Turn on Dancing Fountain Remote by pressing the ON button. A red LED will light up.
- If you don't want to play music, you may press the Fountain button on the Remote to put the Fountain into "Random Non-Dancing" mode. The Fountain will switch OFF automatically after one hour of use in Random Non-Dancing mode.
- Remote reacts to a sound signal of any type. A hiss or other noise will be interpreted as signal. Most MP3 type players do not have this problem, older stereo systems or computer-based systems may.
- When you switch on music, Fountain switches to Dancing mode, and reacts to the frequencies.
- The Remote analyzes the music, and divides it into four frequencies: Bass, Mid-Bass, Midrange, and High End. When volume of these levels reaches a certain point, it causes a set of LEDs to switch on.
- Remote has a Sensitivity Wheel. This adjusts the volume at which the LEDs activate. This depends on two things: The output volume from your source (MP3 Player, Stereo) and the adjustment of the sensitivity wheel.

**Example 1:** Leaving your Audio Source at mid-volume output, you can adjust the sensitivity wheel on the Remote. The light show will change depending on the musical data and where you adjust the sensitivity wheel. The volume of the amplified speakers will not go up or down.

**Example 2:** You adjust the output (volume) of your player up, and leave the sensitivity wheel set where it is. The light show will change, and the output volume of the amplified speakers will also go up (the output from the audio source, which the speaker system is amplifying, has gone up.)

When you are done playing music, and switch your Audio Source "off", the Fountain will automatically switch "off" in 10 seconds. After this time, you may press the "Fountain" button on the Remote, and activate the "Random Non-Dancing" mode on the Fountain.

**LIGHTS ONLY mode** - press the LIGHTS button on fountain. Lights will run in Dancing and Random mode with no spray until the Fountain is switched off (or switches Off automatically) or LIGHTS button is pressed again.

- The Input wire on Remote plugs into your Audio Source.
- Your speaker system or headphones plug into the Remote's Output jack.
- The Audio Source volume control affects light show.
- The Sensitivity wheel on Remote affects the light show.
- The sensitivity wheel adjusts volume levels from Audio Source at which LEDs are switched on or off at their respective frequencies.
- The volume on amplified speaker system does NOT affect the light show.
- The Remote is a pass-through, does not create sound nor adjust volume.
- Fountain switches off 10 seconds after music ends, or one hour after Random Non-Dancing mode is activated.

## **WARNING: SEIZURES - PEOPLE WITH PHOTOSENSITIVE EPILEPSY CAN HAVE SEIZURES TRIGGERED BY FLICKERING OR FLASHING LIGHTS SUCH AS STROBE OR DISCO LIGHTS.**

### **KEEP OUT OF REACH OF CHILDREN. THIS IS NOT INTENDED AS A TOY.**

**CAUTION:** Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.**

This Class B digital apparatus complies with Canadian ICES-003.

### **LIMITED WARRANTY STATEMENT**

**General Terms** This Limited Warranty applies to the product enclosed ("the Product") distributed by Great American Duck Races, Inc., an Arizona corporation, doing business as Great American Marketing and Events ("GAME"), sold with this Limited Warranty Statement. This Limited Warranty is applicable in all countries. • GAME warrants that the Product you have purchased from GAME is free from defects in materials or workmanship under normal use during the warranty period. The warranty period starts on the date of purchase and continues for ninety (90) days. Your dated sales or delivery receipt, showing the date of purchase of the Product, is your proof of the purchase date. • During the warranty period, GAME will repair or replace any defective parts with new parts, or, at GAME's discretion, used parts that meet or exceed performance specifications for new parts. All parts removed under this warranty become the property of GAME. The replacement part takes on the warranty status of the removed part or product. • This Limited Warranty does not apply to expendable parts. This Limited Warranty does not extend to any product from which the serial number has been removed or that has been damaged or rendered defective (a) as a result of accident, misuse, abuse or other external causes; (b) by operation outside the usage parameters stated in the Instruction Sheet that shipped with the Product; (c) by the use of parts not manufactured or sold by GAME; or (d) by modification or service by anyone other than GAME.

**Limitation of Liability** GAME is not liable for any damages caused by the Product or the failure of the Product to perform, including any direct or indirect damages for personal injury, lost profits, lost savings, incidental damages, consequential damages, or any other pecuniary loss arising out of the use or inability to use the Product. GAME is not liable for any claim made by a third party or made by you for a third party. • This limitation applies whether damages are sought, or a claim made, under this Limited Warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation cannot be waived or amended by any person. This limitation of liability will be effective even if you have advised GAME or an authorized representative of GAME of the possibility of any such damages.

**EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY, GAME MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. GAME EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS WORLDWIDE LIMITED WARRANTY STATEMENT.**

**WARNING: GAME™ has in the past, and will in the future, take any and all legal steps necessary in order to protect our proprietary trademarks, patents, trade dress, and copyrights. This applies to, but is not limited to, products, product design, graphics, packaging and literature. We will prosecute to the fullest extent of the law any persons or entities who infringe upon these rights.**