

GT-200 3G GPS Tracker

Quick Guide

Operation temperature: -20~60°C

Power rating:

DC 4.5-5.5V, 1.0-1.5A

(from USB port)





DC 3.15-4.3V, 1430mAh

(Battery)

Copyright © Navisys Technology Corp.

All rights reserved.


Ver. 01




8

Logging in /out


Log in by entering the user account and password, or tapping the camera icon.




Tapping  to log out.

**12**

Setting Geo-fence



3: Tap / slide here to change fence location

**9**

Live tracking


The color of icon will be on if the tracker connects to the server. Otherwise, it is



gray (as the tracker is still for a while, GPS or cellular signal is not available etc.)

**10**

Setting icon



Suggest to activate the Cloud Notify function for faster alert function.


11

Setting/checking functions


Tapping icons at bottom of APP for single/group live tracking, normal/search mode, Augmented Reality (AR), history/event review, setting, etc.

**13**

Setting SOS phone numbers



Setting reporting interval

**14**

SOS Button

Pressing SOS button to call or send SMS to preset phones. Orange & green LEDs blink alternately before SOS actions are done.



Internet connecting button

(for GT-200 H sub-model only)

Pressing internet button by thin pin; Green LED blinks slowly for 5 minutes. Setting SOS/SMS phone numbers during this time period.

**15**

Note

- 1).Orange LED blinks every 5 seconds as battery power is low. Please charge the battery as soon as possible.
- 2). Tracker is designed for safe-guarding elderly, kids, or assets. Please use it with care - not to infringe privacy laws.
- 3). RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

CAUTION!



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC SAR exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CE Statement

Hereby, Navisys Technology Corp. declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

RF exposure (SAR): The device can safely be used with a distance of 5 mm to the human body.

SAR Statement

Federal Communication Commission (FCC) Radiation Exposure Statement:

This EUT is compliance with SAR for general population/uncontrolled exposure limits in ANSI/IEEE C95.1-1999 and had been tested in accordance with the measurement methods and procedures specified in OET Bulletin 65 Supplement C. This equipment should be installed and operated with minimum distance 5mm between the radiator & your body.

To maintain compliance with FCC RF exposure requirements, use only belt-clips, holsters or similar accessories that does not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.