

<u>DosaLink – 540 Wireless LAN IEEE</u> 802.11 a/b/g Access Point User's Manual

Version E.1.1



Copyright statement

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, whether electronic, mechanical, photocopying, recording, or otherwise without the prior writing of the publisher.





Table of Contents

1.	Intro	duction	4
2.	Feat	ures	5
3.	Spec	cifications	6
4.	Exte	rior view	7
5.	Insta	alling the Hardware	8
5		Before Installing	
5		Connecting the Cables	
_		Configuration Information	
_		Factory Default Settingfigure the computer for sharing the Internet	
		Configuration for Windows 2000 and XP	
O	6.1.1	<u> </u>	
	6.1.2		
_	6.1.3		
7.		munication between user's PC and the DosaLink – 540	
8.	Con	nect the Internet via the configuration window of DosaLink – 540	16
9.	Conf	figuration the DosaLink – 540	21
_		ADSL (PPPoE) users	
_		Cable and VDSL Users	
_		Static IP UsersRemove all the Network related Programs	
_		vork Connection Status	
11.	Desc	cription the Menu of DosaLink – 540	25
	1.1.	LAN Setup	
	1.2.	Server	
	1.3.	Access Control	
-	1.4.	Port Forwarding	
	1.5. 1.6.	Static RoutingSystem	
	1.7.	Wireless Setup	
	1.8.	nESA Setup	
_	1.9.	Advanced	
	1.10. 1.11.	Wireless Distribution System (WDS)	
	1.12.	IEEE 802.1x	39
	1.13.	, , , , , , , , , , , , , , , , , , , ,	
	1.14.	` ,	
		ory Resetting	
1	2.1.	Resetting via the Web	44



™DosaLink

12.2.	Hardware Reset	47
13. Confi	iguration via Console	47
13.1.	Connection	47
13.2.	Status	49
13.3.	LAN Setup	50
13.4.	WAN Setup	51
13.5.	Server	55
13.6.	Access Control	57
13.7.	Port Forwarding	
13.8.	Static Routing	
13.9.	Wireless Setup	61
13.9.		
13.9.2	-	
13.9.3	•	
13.9.4	4. MAC Filtering	66
13.9.	•	
13.9.0	6. nESA Key Setup	69
13.9.7	•	
13.9.8	8. WPA/ WPA2	70
Appendix	I: Abbreviations and Acronyms	





1. Introduction

Thank you for purchasing the DosaLink – 540 Wireless LAN Secure Access Point (AP). This User's Manual will help you to configure and operate the DosaLink – 540 Access Point.

The other bands exept ISM Band, 5150~5250MHz, shall be used at only Indoor.

The package you have received contains the following items:

- DosaLink 540 Wireless LAN IEEE 802.11a/b/g Secure AP
- 2 Antennas connected to DosaLink 540 AP
- AC-DC Power Adapter, Ethernet Cable, and Serial Cable
- CD containing the User's Manual

Note: if any items are missing, please contact your vendor.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Exposure Requirements: (According as FCC Part 15.407(f))

The compliance with RF exposure requirements has been demonstrated for both fundamental and unwanted emissions

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction 20cm wth any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.





2. Features

- Enhance security of your Wireless Local Area Network (WLAN) with the initiation of the nDosa Enhanced Security Algorithm (nESATM). The novel concept of security solution is applied to WLAN.
- Introduce the novel security key management system LinkAuthenticaTM for managing the security key of WLAN networks.
- Simple installation and configuration:
 - Supporting Secure Socket Layer (SSL) Web management (https://).
 - Easy to control user interface and display.
 - Easy to configure network with regard to user network environments (driving Dynamic Host Configuration Protocol (DHCP) onto LAN interface).
 - Enhanced security over wireless link (The nESA[™] is set as default).
- Supporting Network Address Translation (NAT)
 - Minimize the lowering throughput due to NAT by using high speed processing.
 - Up to 253 users may be able to share the network simultaneously.
- Strong phased security functions:
 - The Firewall functioning of NAT is able to block an intrusion from any untrusted external networks.
 - By utilizing the Demilitarized Zone (DMZ) function, it can be served actively for requesting outside information.
 - The security policies can be established by using the Internet Protocol (IP) Filtering and Media Access Control (MAC) Filtering functions.
 - Complete WLAN security solution by using Wired Equivalent Privacy (WEP), Wi-Fi Protected Access (WPA), IEEE 802.1x, nESA, and etc.
 - Supporting IEEE 802.1x Extensible Authentication Protocol (EAP)-Message-Digest algorithm 5 (MD5)/ Transport Layer Security (TLS)/ Tunneled Transport Layer Security (TTLS).
- Three 10/100 Mbps Ethernet Ports.
 - Cable Auto Sensing (Auto-Medium Dependent Interface Crossover (MDIX))
- Supporting Point-to-Point Protocol over Ethernet (PPPoE).
- Supporting various Network Protocols.
- Supporting Wireless Distribution System (WDS) and Bridge functions.
- Supporting Simple Network Management Protocol (SNMP) V1, V2.





3. Specifications

WAN Interface	- 10/100Base-TX Auto Negotiation 1 Port (RJ-45) Auto		
	MDIX		
	- IEEE802.3af Power Over Ethernet		
LAN Interface	10/100Base-Tx Auto Negotiation 3 Port (RJ-45) Auto MDIX		
Wireless LAN Interface	IEEE802.11a/b/g		
	- Transmit Power:		
	less than 30 dBm (2.4GHz),		
	less than 30 dBm (5725~5825 MHz)		
	less than 17 dBm (5150~5250 MHz)		
	- Indoor: 70m, Outdoor: 300m		
	- Transmit Speed:1/2/5.5/6/9/11/12/18/24/36/54Mbps		
	Auto & Manual Selectable		
Reset	- Factory Default Value		
LED Indicator	- PWR, WAN, LAN1, LAN2, LAN3, DIAG, WLAN		
Operation Environment	- Ambient Operation Temperature: 0°C to 40°C		
	- Storage Temperature: -10°C to 50°C		
	- Maximum Altitude: 3000m		
	- Relative Humidity: 90% Non-Condensing		
Power Requirement	DC 5V / 2A		
	- AC 90 ~ 260 V, 50 ~ 60Hz		
Dimensions	- W[190], H[30.6], D[125.3]		
Protocol	- IP, ARP, ICMP, UDP, TCP		
	- PPPoE, Telnet		
	- IP Static Routing & DHCP Server/Client/Relay		
Security	- nESA (256 bits)		
	- nESA with LinkAuthentica		
	- WEP (64/128 bits)		
	- WPA-PSK & WPA (TKIP/AES)		
	- WPA2-PSK & WPA2 (TKIP/AES)		
Authentication	- IEEE802.1x (MD5/TLS/TTLS)		





Wireless Function	- Point to Point/Point to Multipoint Bridge & WDS	
Firewall	NAT	
	- MAC Filtering, IP Filtering	
Management	- SNMP V1/2, Wireless & Ethernet MIB	
	- HTTPS(SSL)	
	- WEB Base Configuration	
	- Console Base Configuration	

Table 1 DosaLink – 540 Specifications

4. Exterior view



Figure 1 DosaLink - 540 Top Views

·			
	Indicates the status of the power		
PWR	Off – the power is not connected		
	On – the power is connected		
	Indicates the operation status of AP		
DIAG	Off – Normal operation		
	On – Malfunction status		





WAN		Indicates the connection status of Wide Area Network (WAN) Link		
		Off – The physical connection is not completed		
		On – The physical connection is completed		
		Blinking – The packets are sending and receiving with normal connection		
	Port1	Indicates the connection status of Local Area Network (LAN) Link		
		Off – The physical connection is not completed		
LAN	Port2	 On – The physical connection is completed 		
	Port3	Blinking - The packets are sending and receiving with normal connection		
		Indicates the connection status of WLAN		
WLAN		Off – Malfunction		
		On – Normal operation		
		Blinking - The packets are sending and receiving with normal connection		

Table 2 Indications of the Front side LED



Figure 2 DosaLink - 540 Back View

5. Installing the Hardware

5.1. Before Installing

- The user's MODEM should be plugged into the power after configuring the DosaLink – 540.
- In the case of an Automatic connection MODEM among Asymmetric Digital Subscriber Line (ADSL) MODEM users, "Cable, VDSL" should be selected in the "WAN Setup" menu on the DosaLink 540's configuration window.
- The Automatic connection MODEM has built-in "user account" and "password", which are required to authenticate the PPPoE, so it may be able to connect to the Internet without any connection program.





5.2. Connecting the Cables

- Connecting LAN port(s) of the Ethernet to WAN port of the DosaLink 540.
 Since WAN port of the DosaLink -540 have built-in AUTO DI/MDI function, either a direct cable or cross cable can be used.
- Connecting LAN port(s) of the DosaLink -540 to corresponding user's PC. Since LAN port of the DosaLink – 540 have built-in AUTO MDI/MDIX function, either a direct cable or cross cable can be used.




Figure 3 Example of connecting cables

5.3. Configuration Information

The following information is required for configuring the DosaLink -540:

- Type of broadband (ADSL, VDSL, Cable, Static IP).
- "User Name (Login Name)" and "Password" for ADSL user.
- In the case of a Static IP Address: IP Address, Subnet Mask, Gateway, DNS Server Address, etc.

5.4. Factory Default Setting

LAN interface IP: 192.168.1.1

DHCP: Server

Assigned IP Address of DHCP Server: 192.168.1.2 ~ 254

WAN: Cable, VDSL/ Dynamic IP





SSID: nDOSAChannel: 6User ID: root

User Password: admin

Wireless Encryption: nESA with Default Key

6. Configuring the computer for sharing the Internet

- For sharing the Internet through the DosaLink 540, the computer should be configured while the communication between the user's PC and DosaLink – 540 is normal.
- Since LAN IP of the DosaLink 540 is 192.168.1.1, the user's PC should have the following network IP address – 192.168.1.2 ~ 254 – for connecting to the DosaLink – 540.
- There are two ways to assign IP Address to user's PC. First, the user's PC obtains an IP address automatically from the Dosalink 540 assigned IP address. Second, the IP address can be assigned by the user. However, a static IP address should be assigned for operating servers such as Web, FTP, etc.
- Configuring the user's PC may vary depending on the Operating System (OS) being utilized. This manual is written for users of Windows 2000 and XP.

6.1. Configuration for Windows 2000 and XP

6.1.1. Obtain an IP address automatically for DosaLink – 540

- 1. "Control Panel" => "Network Connections" => "Local Area Connection" => "General" => click "Properties", and then Figure 4 pops up. In this "Local Area Connection Properties" window, select "TCP/IP" and click "Properties".
- 2. In the "Internet Protocol (TCP/IP) Properties" window, select "obtain an IP address automatically" and "obtain DNS server address automatically" as shown in Figure 5. Then, click "OK" to save the configuration.








Figure 4 "Local Area Connection Properties" Window




Figure 5 "Internet Protocol (TCP/IP) Properties" Window





6.1.2. Confirm and Renew the IP address

The saved configuration information may be confirmed by using the "ipconfig" command in the DOS window.

1. Select "Start" => "Run" and input "cmd". Then, click "OK" to execute the DOS window.




Figure 6 "Run" Window

2. The IP address, Subnet Mask, and Gateway that are assigned automatically should be confirmed with inputting the command "ipconfig" on the DOS window. If it is normal, then the IP address should be assigned "192.168.1.xxx" as shown in Figure 7.




Figure 7 DOS Window ("ipconfig")

3. If the assigned IP address is outscope of "192.168.1.xxx, then it should be renewed by "ipconfig /release" and "ipconfig /renew" commands as shown in Figure 8.








Figure 8 DOS WIndow (ipconfig / release & ipconfig /renew)

4. If the assigned IP address is an outscope of "192.168.1.xxx" or it has failed to get an IP address even though the above steps for getting an IP address were excuted, then the static IP address should be assigned by the user with regard to the following section.

6.1.3. Assign the static IP address

This section explains how to assign the static IP address to the user's PC when the DosaLink – 540 cannot assign an IP address to the user's PC or a server is operating on the network.

- 1. "Control Panel" -> "Network Connections" -> "Local Area Connection" -> "General" -> click "Properties", and then Figure 9 pops up. In this "Local Area Connection Properties" window, select "TCP/IP" and click "Properties".
- 2. In the "Internet Protocol (TCP/IP) Properties" window, select "Use the following IP address" and "Use the following DNS server addresses" as shown in Figure 10. Then, input the correct addresses and click "OK" to save the configuration.








Figure 9 "Local Area Connection Properties" window

3. If several user's PCs need to be assigned IP addresses, then the information for Subnet Mask, Gateway, and DNS server should be the same and the IP address should be selected between 192.168.1.2 and 192.168.1.254.








Figure 10 "Internet Protocol (TCP/IP) Properties" window

7. Communication between user's PC and the DosaLink – 540

- The communication between the user's PC and the DosaLink 540 should be confirmed before configuring the PC by utilizing the configuration window of the DosaLink - 540. For this purpose the "ping" command can be used.
- "Start" => "Run", input "cmd" and press "OK". The DOS window will be open.
- Once performed "ping 192.168.1.1", should appear as shown as Figure 11. If it does not appear, then the sequence should be performed again after pressing "reset", which is located on the back of the DosaLink -540, and rebooting the user's PC.








Figure 11 "ping" in the DOS window

8. Connect the Internet via the configuration window of DosaLink – 540

1. First, run the web browser to connect to the Internet. However, it is not connected to the Internet because the DosaLink – 540 is not configured yet. On the web browser's menu, select "tools" => "Internet options...".




Figure 12 "Internet Option"

2. To Delete the temporary Internet Files in the Internet options window click on "Delete Cookies..." and "Delete Files..." Then select "Connections".








Figure 13 "Delete Cookies" & "Delete Files"

3. At "Dial-up and Virtual Private Network settings" menu, select "Never dial a connection" then click "LAN Settings..." as shown in Figure 14.







Figure 14 "Dial-up and Virtual Private Network settings"

4. In the "Local Area Network (LAN) Settings" window, remove the check marks (V) as shown in Figure 15 and select "OK" to save the configurations.








Figure 15 "LAN Settings" window

5. After configuration enter https://192.168.1.1 into the "Address" window of web browser as shown in Figure 16.




Figure 16 https://192.168.1.1

6. Since the SSL is implemented to enhance the security, if the message as shown in Figure 17 appears, then select "Yes".







Figure 17. SSL Message

7. The Default "ID" and "Password" to connect to this web page, shown in Figure 18, are 'root' and 'admin', respectively.



Figure 18 Default User ID and Password

8. If it connects, as shown in Figure 19, the initial page to manage the DosaLink – 540 wil appear.








Figure 19 initial Page for DosaLink -540 Access Point

9. Configuration the DosaLink - 540

Since all configuration information is saved to the DosaLink – 540, automatically, it may be necessary to configure only once from any user's PC.

9.1. ADSL (PPPoE) users

In the case of the Automatic connection MODEM users among ADSL subscribers, "Cable, VDSL" is selected for "Internet Service Type" in the "WAN Setup" menu.

- 1. Choose "ADSL (PPPoE)" for "Internet Service Type" in the menu of "WAN Setup".
- 2. Input "User's Name" and "Password".
- 3. Click "Submit" to apply to the DosaLink 540.





4. Then, move to the "Status" menu and confirm and check the connection status. Note) "MTU" means the maximum permissible packet size, which the default value is 1440. This value may vary depending on the Internet Service Provider (ISP).





Figure 20 Configuration Windows for ADSL Users

9.2. Cable and VDSL Users

- The same as above, the Automatic connection MODEM users should select "Cable, VDSL" for "Internet Service Type" in the "WAN Setup" menu as shown in Figure 21.
- 2. Since most ISPs confirm the configured MAC address initially, as shown in Figure 21, press "Clone" and the initial PC's MAC address is appeared. Then, click "Submit".
 - "Restore" is for reconfiguring the factory default setting of user's PC.
- 3. Click "Submit", and the configuration is applied. Then, the PC will reboot with the message on web browser.







* After configuration, the status of the connection in the menu will be confirmed.

Figure 21 Configuration Windows for Cable & VDSL Users

9.3. Static IP Users

- 1. From the "WAN Setup" menu, select "Static IP".
- 2. Input the IP address, Subnet Mask, Gateway, and DNS from your ISP.
- 3. Click "Submit".



^{*} After configuration, it will be confirmed by the "Status" window.






Figure 22 Configuration window for Static IP Users

9.4. Remove all the Network related Programs(Daemons)

1. For configuring Dosalink-540 as simple Access Point like HUB device, select "None".

10. Network Connection Status

After configuration of "WAN Setup", "LAN Setup", and "Wireless Setup", theIP address can be confirmed at the "Status" menu. As shown in Figure 23 below, the "WAN Setup Status" indicates "Connected" and the addresses appear if it is connected to the Internet.








Figure 23 Status Window

- (1) Firmware & AP Name: Software Version for DosaLink 540
- (2) LAN Setup Status: LAN Setup Status
- (3) WAN Setup Status: Status of WAN Port and the Status for IP Address, Subnet mask, and Gateway of WAN Port
- (4) Wireless Setup Status: Wireless Setup Status
- (5) DNS: IP of DNS Server for WAN

11. DosaLink – 540 Menu Description

11.1. LAN Setup

1. The IP address and Subnet Mask's range is configured in this menu. The configured IP address is the Gateway of LAN Ports.





2. If DHCP server is operating, then the IP address assigned to users connecting the DosaLink – 540 should also be in the range of the configured IP address in this menu.




Figure 24 "LAN Setup" Window

11.2. Server

In this menu the related functions to DHCP and DNS are configured.

DHCP is the protocol that manages and assigns the IP address automatically. Thus, the new IP address can be assigned to the user's computer automatically when it connects to the network, at anywhere in the network. However, in the case of using Web and FTP servers, the static IP address should be used.

- (1) In the menu of "DHCP Server", select "Enable" or "Disable".
 - If "Disable" is selected, then the "DHCP Relay Agent" should be selected as "Enable" so that the client adapters are able to be assigned the IP address for the server that connects to the DosaLink 540.
 - If "Enable" is selected, then just configures "DHCP start and end Range" to specify the range of the IP address.
- (2) Configuration Domain Name Server (DNS)
 - "Real": Use the DNS Server that is assigned by DHCP client or PPP. All DNS query messages are transmitted to one of the DNS servers that are found dynamically.
 - "Custom": Use the configured DNS Sever. All DNS query messages are sent to one of the DNS Servers that will be designated. The IP address of DNS Server should be input.





- "Proxy": The Gateway IP address of device is the DNS' IP address.
- (3) DHCP Relay Agent is the function that assigns the IP address to Local LAN or WLAN's Client from the DHCP Server, which connects to WAN. If it is configured, then the requested DHCP from the Local PC transmits to the DHCP server over the WAN. For this operation, NAT can be disabled and user should choose "Disable" for DHCP function.
 - In the case of selecting "Enable", the IP address for the DHCP should be written into the menu as shown in Figure 25.




Figure 25 Configuration Window for "Server"

11.3. Access Control

This menu allows users to configure the access control to terminals that connect to the DosaLink – 540. The configuration is established on the basis of the IP addresses that are assigned to each terminal. This can be applied to a specific terminal for the access control. It is able to restrict access of the output to a specific terminal from the DosaLink





– 540, the input to the DosaLink – 540 from a specific terminal and the WAN or LAN through the DosaLink – 540. In general, it is described as the function of IP Filtering.




Figure 26 Configuration Window for "Access Control"

- (1) Host Name: A name for the terminal (PC) to be controlled. This is configured by the user.
- (2) Policy: Configure the Chain such as Input, Output, or Forward.
- (3) Protocol: To restrict the specific protocols such as TCP and UDP. If it is configured to "All", then all protocols are blocked.
- (4) Set the range for Source IP's registration information Net Mask and Port of Input, Output, and Forward in Policy.
- (5) To register the information of Destination IP for the above (4).
- (6) After the configuration above, click "Add". It is then registered to the Access Control Table. The user may confirm and delete the information that is registered in the Access Control Table.

11.4. Port Forwarding





To write the IP address of the PC to set the DMZ among the PCs that are connecting to the LAN, select "Enable" and click "Submit". To establish the DMZ that the function operates as the same state, which does not utilize the firewall functionality of the DosaLink – 540 by forwarding all the packets, connected to the official IP that is assigned to the DosaLink – 540 from the outside of the network, to the specific PC that is connecting to the DosaLink – 540. If, at the specific PC, some special services such as a Web Server and FTP Server are able to be operated by utilizing various firewall functions that the DosaLink – 540 has, then it is possible for the external to access to the DosaLink – 540 and impossible to access to the specific Programs of PC that connects to the DosaLink – 540. In case that it is necessary for the external to forward to the specific program at the specific PC, the Port Forwarding is used for this purpose.




Figure 27 "Port Forwarding" Window

- (1) Select "Enable" from the menu of "DMZ". User can arbitrarily select the "Host Name".
- (2) The IP address of the PC to be used as DMZ over the LAN is input. Then click "Submit". "Protocol" can be set to "TCP", "UDP", or "ALL".
- (3) To set the range of the specific Port Number, from the external.
- (4) To input the IP address of the PC to which the specific Port is forwarding.
- (5) To establish the range of Port Numbers to be used by the PC that is set in (4).
- (6) Press "Add" to register the above setting into the "Port Forwarding Table". If "Reset" is pressed, the configuration is initialized.
 - * Click "Port Forwarding Table" to confirm the registered configuration.





11.5. Static Routing

Static Routing is the opposite of Dynamic Routing. It is the function that transfers the data through the specific path. It is set in advance. The route can be configured with regards to the IP address of the specific PC and the Gateway.




Figure 28 "Static Routing"

- (1) To set the "Network Name" arbitrarily.
- (2) To input the range of "Destination IP", connecting to the intra network.
- (3) To input "Subnetmask".
- (4) To input the "Gateway IP" of the "Destination IP" being used in the intra network.
- (5) Press "Add". Click "Reset" to initialize the configuration.
 - * Click the "Static Routing Table View" to confirm the registered configuration.

11.6. System

This Menu offers various functions to manage the DosaLink – 540.








Figure 29 "System" Window

- (1) The "User ID" can not be modified and is used to connect to the configuration window of DosaLink 540.
- (2) The "New Password", used to modify the User Password, is used to connect to the configuration window of DosaLink 540. The default is "admin".
- (3) The "Factory Default" is used for resetting all the current configured values to the initial values. When "Submit" is pressed, it is applied. The system should be "Reboot".
- (4) The "System Rebooting" is to reboot the DosaLink 540.
- (5) The "Log Messages" shows the events that have occurred in the DosaLink 540. Its function can be helpful to manage the DosaLink 540.
- (6) The "System Firmware Upgrade" is used to upgrade the system software of DosaLink 540.
- * Click "Browse", and select the system software to be used for upgrading. Then, press "Upgrade" to apply.
- ** The name of the system software should be "image.cramfs".





- *** It takes about 3 min. to operate normally when upgrading. If "On/Off" power or "Rebooting" of the DosaLink 540 occurs while upgrading, it may cause fatal damages to the DosaLink 540.
- (7) The "nESA EDATA UPLOAD" is used to modify the Data that is related the nESA the enhanced wireless security function is offered by the DosaLink 540. The uploaded "EDATA", supporting the nESA, may not be deleted even if "Factory Default" is applied.
- ** The file name of the "EDATA" should be "edata.str".

11.7. Wireless Setup

This Menu guides users to set the basic wireless configuration for the DosaLink – 540. Users can establish and operate the WEP, the basic WLAN security of the IEEE 802.11 standards, in this menu.




Figure 30 Wireless Setup





- (1) The "AP Name" is for naming the DosaLink 540. It can be any name the user chooses to manage the AP.
- (2) The "Operation Mode" is for defining the application of DosaLink 540.
 - Select "AP" for using DosaLink 540 as the Access Point.
 - If the DosaLink 540 is used for the Wireless Bridge such as the Point-to-Point (PtP) and Point-to-MultiPoint (PMP), then select either "Wireless Bridge (Master)" or "Wireless Bridge (Slave)". If it is connected to the Internet or upper layer network, then select "Wireless Bridge (Master)". If it is connected to the wireless master bridge for relaying the network, then select "Wireless Bridge (Slave)".
 - In the case of Wireless Bridge, the "Using WDS" should be enabled and the MAC Addresses of DosaLink 540 to be connected should be registered in the Menu of "WDS". Therefore, the client adapters can not be connected to the DosaLink 540 that is set to "Wireless Bridge".
- (3) The "Country Code" can not be modified from what is set in the DosaLink 540.
 - Frequencies for each country are different.
- (4) The "SSID" is an abbreviation for Service Set Identifier. It is a 32 byte character unique identifier attached to the header of packets sent over a WLAN. The "SSID" between the DosaLink 540 and the user's PC should be the same.
 - It should use the alphabet or the number. In case of the alphabet, it should be distinguished between the lower and upper case.
- (5) IEEE 802.11 Standards are selected in this menu "Wireless Mode Selection". For instance, if "802.11g only" is selected, then its users only connect. In case of selecting "802.11b+g mixed", since the users of 802.11b are able to connect, it may cause a slow transmission speed for the users of 802.11g. Also, if "802.11a only" is selected, then its users only connect.
- (6) The "Channel Select" menu is for channel selection methods of the DosaLink 540.
 - The DosaLink 540 supports the selection of either "Manual" or "Auto" for the method of channel selection.
 - When "Manual" is selected, the channel in "Channel Number" is set. When "Auto" is selected, the channel that has good signal strength and receiving sensitivity is selected automatically from all possible channels. In the case of selecting "Auto" of 802.11a standard, if the chosen channel in "Channel Number" is the one of channels of 802.11a, then it will be selected automatically among the possible channels of 802.11a.
- (7) The "Channel Number" menu is only available when the "Channel Select" is set to "Manual".
 - Channel 6 is the Factory Default value.
- (8) The WEP can be selected in the "WEP" menu.
 - If the WEP, an encryption to protect the data over the wireless area, is selected "Enable", then the user's PC to connect to the DosaLink 540 should also be set with the same WEP information as in "Key length", "Authentication Type" and "KEY"(64bit, HEX or Passphrase).





(9) When the WEP is "Enable", the user can also select the key length of WEP according to the following Table. (The encryption key can be made of the number (0 ~ 9) and the alphabet (A ~ Z)).

Key Length	Number Code		
Rey Length	ASII	HEX	
64 bits	5 Char.	13 Char.	
128 bits	10 Char.	26 Char.	

- (10) The menu "Authentication Type" is three different types of authentication of the wireless device.
 - "Open System": All users' PCs, with the corresponding channel information, are able to connect to the DosaLink 540.
 - "Shared Key System": Only the users' PCs with the corresponding channel information and WEP key can connect to the DosaLink – 540.
 - "Both System": Is controlled automatically. All wireless equipment should be using the same authentication method.
 - The basic setting is "Open System".
- (11) There are 4 keys for the WEP.
- (12) The stored WEP key should be selected.
- (13) For configuring WEP with "Passphrase", input narative sentence in the box of "Passphrase" (ex: I am a boy). There is no required grammar of the sentence.

11.8. nESA Setup

The WLAN, communicating over a wireless medium, is vulnerable in nature. For that, the IEEE802.11 Task Group (TG) has generated the various security solutions such as WEP, WPA, WPA2, 802.1x, and etc. However, it has been reported that these technologies are not enough to cure the weakness of WLAN. Its security vulnerability has made users' obstacles adapt to the WLAN system. To resolve the security issue of WLAN is to hide the WLAN network from the outside and to encrypt all the data, transmitted and received over the WLAN network.

The nDosa Enhanced Security Algorithm (nESA) developed by nDosa Technologies Inc. is the only security solution that makes the WLAN network invisible. The DosaLink – 540 is equipped with the nESA technology and this menu leads the user to configure the nESA. All the information that is set in this menu should be established at the user's PC to be connected to the DosaLink – 540. In addition to the nESA technology, there is the novel key management system, called LinkAuthentica, for the enterprise users.

The features of LinkAuthentica are summarized as follows:

The novel concept of the key management system for the nESA security keys does not have the problems that the Pre-Shared key method has.





- Each user on the same subnet is assigned a unique user key which is different from the other users.
- Since each user's key is not compatible with other users', it is not a concern if it is lost.
- Strong security and excellent flexibility can be offered to the user.
- LinkAuthentica is composed of two parts Key Generator and Client Manager.
 - Key Generator: Generates the Master Key and the unique user key for each user on the same subnet.
 - Client Manager: The program, resides on the client adapter, generates a
 Master Key by using the unique users keys that the Key Generator
 generates and the user inherent information so that the client adapter can
 be connected to the DosaLink 540.
- * The Master Key is not revealed outside or transmitted over the network.
- * Please refer to the LinkAuthentica User Manual for more information.




Figure 31 nESA Set

- (1) There are 4 different selections to operate the nESA in the menu "nESA Key Type".
 - Disable: The nESA is not used.
 - Default Key: It means the Factory Default. It is not necessary for theuser to input the key.
 - User Key: The user should input 64 Hex numbers for the nESA key into "User Key" or "Passphrase".





- LinkAuthentica: This selection, the nESA Key Management System, is for the enterprise customers.
- (2) If the "User Key" is selected in the "nESA Key Type", then the user should input the key into this menu and click "Submit".
- (3) If the "LinkAuthentica" is selected in the "nESA Key Type", then using "Browser..." searches for the related key file (the file name should be "linkA_AP.key") and click "Upload". And then click "Submit" toactivate the key. The file "linkA_AP.key" can be generated by the LinkAuthentica Key Generation program. Please refer to the LinkAuthentica User's Manual for more information.
- (4) The menu, "Passphrase", generates the key automatically with inputting a user specific word or phrase. If the user wants to generate the WEP key manually, then this menu should be blanked. First, input user specific ASCII into the menu and click "Key_Generation, then it is generates the key automatically and applies the key to the system. Second, click "Submit" to activate the setting.

11.9. Advanced




Figure 32 Advanced

- (1) The transmitting power of the system can be controlled in this menu, "Tx Power Control". There are 4 different steps to control "AUTO, 100%, 70% and 50%".
- (2) The transmitting data rate can be controlled in the menu of "Tx Rate" at 1 ~ 54 Mbps and AUTO.





- (3) The permissible packet size over wireless medium is defined in this menu "Fragmentation Threshold". The packet size of 2346 is recommended. If the fragmentation packet error rate is high, a fragmentation threshold of between 256 and 2346 can be controlled gradually. If the "Fragmentation Threshold" is established too low, then the communication performance may be poor.
- (4) The frame size is set in this menu "RTS Threshold". There are two signals (Request-to-send (RTS) and Clear-to-send (CTS)) to control the WLAN communication. The recommended value is 2437. If the communication flow is not smooth, then use this menu to control the "RTS Threshold" between 0 and 2437.
- (5) The "Beacon Period" controls the interval of Beacon Frame that is generated from the DosaLink 540. The default value of 100 is recommended.
- (6) The number of Beacon Interval in the Delivery Traffic Indication Message (DTIM) is defined in this menu "DTIM Interval". It can be set between 1 and 255.

11.10. Wireless Distribution System (WDS)

The WDS function is established in this menu.

The WDS is the function that the DosaLink – 540, is connecting the Ethernet, connects to the other DosaLink – 540, is not connecting the Ethernet, in the same subnet so that the data traffic that is from the DosaLink of not connecting the Ethernet relays to the DosaLink – 540 that is connecting to the Ethernet. It is possible to set the links between six of the DosaLink – 540 in max. The user's PC can be connected to any DosaLink – 540 that connects in WDS. The ways to set the WDS between the DosaLink – 540s that are able to extend a WLAN network in the same subnet are the Point-to-Point (PtP) and the Point-to-Multipoint (PMP).

- (1) The menu of "WDS" is for the selection of use of the WDS. If the "Wireless Bridge (Master or Slave)" is selected in the 10.7 "Wireless Setup", then it should also activate the WDS.
- (2) The "MAC Address 1 ~ 6" is for the MAC Address of the DosaLink 540s, which may be connected by the DosaLink 540 that is activated for WDS or Wireless Bridge (Master or Slave).








Figure 33 WDS

11.11. MAC Filtering

The user's PC has its own unique MAC Address. Access to the DosaLink – 540 can be controlled based on this information.

- (1) The access control of DosaLink 540 based on the MAC address of the user's PC is established in this menu MAC Filtering.
 - Disable: Do not use the MAC Filtering
 - Accept: Only the user's PC with a MAC address that is listed in the MAC Filtering Table are able to access the DosaLink – 540.
 - Deny: The user's PC with a MAC address that is listed in the MAC Filtering Table are denied access to the DosaLink – 540.
- (2) The new MAC address that is registered to the MAC Filtering Table is set in this "MAC Address" menu. The registered MAC addresses can be confirmed by clicking the "MAC Filtering Table".








Figure 34 MAC Filtering

11.12. IEEE 802.1x

The IEEE 802.1x is the standard Port Access Protocol that authenticates the user via the Radius Authentication Server. By using the information from the user's PC (Authenticator, ID, Password, etc.) it is authenticated to control access to a wireless network. For these procedures, the Extensible Authentication Protocol (EAP) is used between the Radius Authentication Server and the user's PC in the standard of IEEE 802.1x. The information from the user's PC, passing through the EAP, can be verified by the Radius Authentication Server. Depending upon its verification it should decide to connect to a wireless network. Depending upon the types and results of the authentication the Dynamic Unicast Session Key or Static Broadcast Key which the IEEE 802.1x EAP packets contain is transferred to the authenticated user's PC. The Session Key can be different for each authenticated user's PC. This information can be utilized to encapsulate the data that are between the DosaLink – 540 and the authenticated user's PC.

The DosaLink – 540 supports the following authentications:

- EAP-MD5 (Message Digest): This type of EAP authentication offers the basic level of EAP. User ID and User Password of the user's PC are used for authentication. Since MD5 algorithm is used one-way harsh function, the authentication between the user's PC and the Radius Authentication Server is processed one-way.
- EAP-TLS (Transport Layer Security): EAP-TLS provides for mutual authentication based on the certificates between the user's PC and the Radius Authentication Server. The keys for authentication are generated dynamically.





EAP-TTLS (Tunneled Transport Layer Security): EAP-TTLS is the protocol
that improved EAP-TLS. It provides for mutual authentication and generation
of dynamic user's or sessions secret keys based on the certificates between
the user's PC and the Radius Authentication Server via the encrypted
channel (or the tunnel). EAP-TTLS requires only the Radius server-side
certificates.

The DosaLink – 540 supports the Web Redirection.

When the user's PC that connects to the DosaLink – 540 fails to authenticate, it allows the user's PC to point the specific WEB Site.




Figure 35 802.1x

- (1) Select IEEE 802.1x authentication function in the menu of "802.1x".
- (2) Input an IP address of the Authentication server into the menu of "Authentication Server IP1". The Port number that associates with the Authentication Server should be written into "Port". The default value is 1812.
- (3) The "Shared Secret" is a text string that serves as a password, registered at the authentication server. It must be the same "Shared Secret" between the authentication server and the DosaLink 540.





- (4) An IP address of the accounting server should be written into the menu of "Accounting Server IP1". The Port number that is associated with the accounting server should be input into this menu. The default value is 1813.
- (5) The "Shared Secret" is a text string that serves as a password, registered at the accounting server. It must be the same "Shared Secret" between the accounting server and the DosaLink 540.
- (6) This menu is for the second authentication server, accounting server, port numbers, and shared secrets. If there is not a second choice, then it may be blanked.
- (7) In the "RETRY_PRIMARY_INTERVAL" the time interval when it is requested to connect to the second authentication server after failing to authenticate from the first authentication server is established in the case of using a couple of authentication servers.
- (8) The time from failing to authenticate to requesting to reauthenticate is set in this menu of "ACCT_INTERIM_INTERVAL".
- (9) WEB_REDIRECTION: Select to use the Web Redirection function in this menu.
- (10)WEB_REDIRECTION_IP: Input the IP address of Web site that is to be connected automatically when IEEE 802.1x authentication is failed.
- The function of Web Redirection is associated with MD5 of IEEE 802.1x.
- When the function of Web Redirection is activated, the message for re-booting the DosaLink 540 appears. Click "OK" to re-boot the DosaLink 540. After this, the function of Web Redirection can be used.

11.13. Wi-Fi Protected Access (WPA)/ WPA2 (IEEE 802.11i)

The DosaLink – 540 is offered the following two modes:

- WPA and WPA2: It is associated with IEEE 802.1x so that the user's PC is authenticated and its keys are distributed to the authenticated user's PC. The Radius Authetication Server is needed and either the EAP-TLS or the EAP-TTLS, are used to authenticate.
- WPA-PSK and WPA2-PSK: The Pre-Shared Key (PSK) mode is not used that Radius Authentication Server and associated with IEEE 802.1x. The PSK that is formed, either 256 bits – 64 hexadecimal or 32 alphanumeric characters, is inputed directly by a user.








Figure 36 WPA

- (1) Select to use the WPA in the menu of "Using WPA".
- (2) The menu of "Authentication Type" selects to use either WPA-PSK or WPA-EAP when the WPA is enabled.
- (3) If the WPA-EAP is selected, then the Radius Server's IP address, Port, and Shared Secret are written into this menu "Radius Server".
- (4) Select to use either "AES" or "TKIP" in this menu "Cipher Suite".
- (5) Select to use either "Passphrase" or "Hexa" in the "Pre-Shared Key Format" if the WPA-PSK is selected.
- (6) Input the keys in format "Pre-Shared Key".





- Input 8 63 characters if the "Passphrase" is selected.
- Input 64 chracters if the "Hexa" is selected.
- (7) The menu of "Using RSN/WPA2" is for selecting to use of WPA2.
- (8) This is same as (2).
- (9) Select to use of the "Preauth" function.
- (10) Establish the "Preauth Life Time".
- (11) This menu is same as (3).
- (12) This menu is same as (4).
- (13) This menu is same as (5).
- (14)This menu is same as (6).
- (15) Establish the "Rekey Time".
- (16) Set the "Rekey Packets".
- (17) Set the "Reauth Time".

11.14. Virtual Local Area Networks (VLAN)

A virtual LAN (VLAN) is a method of creating independent logical networks within a physical network. Several VLANs can co-exist within such a network. This helps to reduce the broadcast domain.

A VLAN consists of network computers and devices that exist on the same domain. They may actually be physically connected to different segments of a LAN. The network administrator configures VLANs through software rather than hardware, which makes them flexible.

The VLAN technology is applied to the WLAN networks by using the IEEE 802.1q tagging protocol.

The DosaLink – 540 supports the Port base VLAN. For the purpose of using this function, the wired network connecting to the DosaLink – 540 should be segemented by the VLAN and it should be consisted of switches, routers, DHCP Server, and Radius Authentication Server that are supporting the network.








Figure 37 VLAN

- (1) Select to use the VLAN.
- (2) The authenticated client's VLAN ID value is set in this menu "Authenticated VLAN ID" (2 ~ 4095).
- (3) The unauthenticated client's VLAN ID value is set in this menu "Unauthenticated VLAN ID" (2 ~ 4095).

12. Factory Resetting

The Factory Resetting means to set the configuration of DosaLink – 540 as the initial values.

 The most recent uploaded EDATA via "nESA EDATA UPLOAD" should be maintained even though the Factory Resetting is performed.

12.1. Resetting via the Web

- (1) Go to the configuration window of DosaLink 540 (https://192.168.1.1). Refer to the menu "Connecting the Internet via the configuration window of DosaLink 540.
- (2) Press the "Submit" of "Factory Default" in the below Figure 38.








Figure 38 System

- (3) When Fgure 39 appears, press "OK" to return the previous display.
 - The DosaLink 540 reboot after changing to the Factory Default.








Figure 39 Result Page

(4) If the "Submit" of "System Reboot" in Figure 40 is pressed, then it has completed the Factory Resetting with rebooting the DosaLink – 540.








Figure 40 System

12.2. Hardware Reset

If the Reset Button, located in the back of DosaLink – 540, is pressed for 5 seconds, then all the configuration values are back to the Factory Resetting. Approximately one or two minutes is needed to reboot the DosaLink – 540 automatically.

13. Configuration via Console

Refer to "Menu Descriptions of DosaLink – 540" section for detailed descriptions of the functions.

13.1. Connection

1. Connecting "telnet" in the Dos window.








Figure 41 connecting telnet

2. Input "login ID" and "Password" (the defaults are "root" and "admin", respectively).




Figure 42 Login





3. This is the initial display of connecting Console.




Figure 43 Initial Display for connecting Console

- 1. Status: Shows the current configuration status of DosaLink 540.
- 2. LAN Setup: Input the LAN IP address.
- 3. WAN Setup: Select the method to connect to WAN and configure it.
- 4. Sever: Select and set the DHCP Server and DHCP RELAY AGENT.
- 5. Access Control: Set the firewall functions by using the IP addresses.
- 6. Port Forwarding: Establish the DMZ and Port Forwarding functions.
- 7. Static Routing: Configure the communication paths.
- 8. System: Confirms modifying Password, Factory Resetting, etc.
- 9. Wireless Setup: Set the basic wireless configuration.

13.2. Status








Figure 44 Status window

- (1) F/W Version: Shows the Firmware Version of DosaLink 540.
- (2) LNA Status: The configured LAN IP, Subnetmask, and use of DHCP Server are confirmed in this menu.
- (3) WAN Status: Shows the status of WAN, WAN IP Address, Subnetmask, Default Gateway.
- (4) Wireless Status: Shows SSID, current Channel, nESA Key setting, etc.
- (5) DNS: Shows the information for DNS.

13.3. LAN Setup








Figure 45 LAN Setup

- 1. IP: LAN IP address is shown. It can be changed. If the IP address is modified, a communication currently connected with the user's PC is disconnected.
- 2. NetMask: The NetMask is set in this menu.
- 3. s. save: Register the newly configured information.
- 4. r. return: Back to the previous display.

13.4. WAN Setup

The connection method for WAN is selected and configured in the WAN Setup (Default is "Cable/VDSL").








Figure 46 WAN Setup

If PPPoE (ADSL) is used, then select 1. PPPoE Setup in Figure 47.




Figure 47 PPPoE Setup

1. Select "1", which is "User Name" and input ID (User Name), is registered at ISP.








Figure 48 PPPoE Setup

- 2. Select "2" "Password" and input the Password that is registered at ISP.
- 3. The value of "MTU" may be modified as shown in figure 48 above.
- 4. Save the configured values.
 - If Cable or VDSL is used, then select "2. Cable/VDSL Setup" from the "WAN Setup". If the DHCP server is operated, it is also established via "Cable/VDSL Setup". An ISP controls access to the network from clients based on the client's MAC Address. If it is needed, then the MAC clone function should be utilized to access the network.








Figure 49 Cable/ VDSL Setup

(1) Select "MAC Address" and change the Mac address.




Figure 50 MAC Address

(2) If the previous MAC Address needs to be restored, then select "Restore MAC Address".





• If the static IP address is used, then select "3. Static Setup" from the "WAN Setup".




Figure 51 Static Setup

(1) Input IP Address, NetMask, GateWay Address, and DNS Server IP which are assigned to the DosaLink – 540.

13.5. Server

This is for setting the DHCP Server. The basic settings in this menu are the DHCP Server Enable and DHCP RELAY AGENT Disable. Both the DHCP Sever and DHCP RELAY AGENT are not to be set to "Enable" at the same time.








Figure 52 Server Setup

(1) 1. DHCP Server Setup: Configure the DHCP Server.




Figure 53 DHCP Server Setup

- (1) DHCP: Select to use the DHCP Server.
- (2) Start Addr and End Addr: Specify the assigned range of IP for the DHCP Server.





- (3) DNS Server: Configure DHCP Server
 - The default is "Proxy" so that AP is operated as Proxy Server.
- (4) DNS Addr1 and DNS Addr2: If the configuration of DNS Server is not Proxy, then IP address should be input to DNS Server.
- (5) DHCP Client Table: The registered information of DHCP Client Table may be confirmed.
- (2) 2. DHCP Relay Setup: Configure DHCP Relay Agent.




Figure 54 DHCP Relay Setup

- (1) DHCP Relay: Select either "enable" or "disable".
- (2) DHCP Server: Input the IP address that connects to the WAN port of DosaLink 540.

13.6. Access Control

This is for setting the Firewall by using IP Filtering function.



^{*} In case of selection of DHCP Relay, the "DHCP" of "DHCP Server" must be set "Disable".





Figure 55 Access Control Setup

- 1) Host Name: Arbitrary Name (No space).
- 2) Policy: Select among Input/ Output/ Forward
- 3) Protocol: Select the specific protocols, for example TCP/UDP, to be controlled. If it is configured to "All", then all protocols are controlled.
- 4) Set the range for Source and Destination IP registration information, Net Mask, Port of Input, Output, and Forward in the "Policy".
 - Source IP: 0.0.0.0 for every available IPs.
 - Src NetMask: 0.0.0.0
 - Src Start Port and Src End Port: The specified ranges for Port can be assigned. If no address is input, then it is for all Ports.
 - Destination IP: Is for WAN IP of AP.
 - Dest NetMask: May not need any input.
 - Dest Start Port and Dest End Port: May not need any input.
- 5) Print: Allows user to confirm and delete the information that is configured.

13.7. Port Forwarding

Configure the DMZ to the specific PC and the Port Forwarding to the specific Port.








Figure 56 Port Forwarding Setup

1) DMZ Setup




Figure 57 DMZ Setup

- (1) DMZ: Select either "enable" or "disable".
- (2) IP Address: Input the IP address of the user's PC to be configured.





2) Port Forward




Figure 58 Port Forward Setup window

- (1) Host Name: Choose the name arbitrarily.
- (2) Protocol: Can be set to TCP, UDP, or ALL.
- (3) Dest Start Port/ Dest End Port: Set the range of the specific Port Number, from the external.
- (4) Internal IP: Input the IP address of PC to which the specific Port is forwarding.
- (5) Internal Start Port/ Internal Stop Port: Establish the range of Port Numbers to be used by the PC that is set in (4).
- (6) P: Confirm the information that is registered at the Port Forwarding Table.

13.8. Static Routing








Figure 59 Static Routing Setup

- 1) Network Name: Set the "Network Name" arbitrarily.
- 2) Destination IP: Input the range of "Destination IP", connecting to the intra network.
- 3) Subnet Mask: Input "Subnet Mask".
- 4) GateWay: Input the Gatway IP (WAN IP), as used in the intra network.
- 5) p: Confirm the registered configuration at the Static Routing Table.

13.9. Wireless Setup

This section outlines how to set the wireless configuration for the DosaLink – 540.








Figure 60 Wireless Setup

- 1. Primary Setup: Set to the basic configuration for WLAN such as SSID, Channel, WEP Key, nESA Key, etc.
- 2. Advanced Setup: Set to the advanced configuration for WLAN such as Tx Power, Rate, Threshold values, etc.
- 3. WDS: Set to the communication path between one DosaLink 540 and another DosaLink 540 via WDS configuration.
- 4. MAC Filtering: Can be controlled to access the DosaLink 540 based on the MAC address of user's PC.
- 5. 802.1x setup: Control access from user's PC by associating with the Radius Authentication Server.
- 6. VLAN Setup: Configure to cooperate with the wired network which VLAN is structured.

13.9.1. Primary Setup








Figure 61 Primary Setup

- 1. AP Name: For naming the DosaLink 540. User can select any name that will be easy to manage.
- 2. Operation Mode: Is for defining the application of DosaLink 540. If the DosaLink 540 is used as AP, then select AP. If the DosaLink 540 is used for the Wireless Bridge such as the Point-to-Point (PtP) and Point-to-MultiPoint (PMP), then select either "Wireless Bridge (Master)" or "Wireless Bridge (Slave)". If it is connected to the Internet or upper layer network, then select "Wireless Bridge (Master)". If it is connected to the wireless master bridge for relaying the network, then select "Wireless Bridge (Slave)". In the case of the Wireless Bridge, the WDS should be enabled and the MAC Addresses of DosaLink 540 should be connected and registered in the Menu of "WDS". Thus, the client adapters can not connected to the DosaLink 540 that is set to "Wireless Bridge".
- 3. Country Code: This can not be modified from what is set in the DosaLink 540. Each country's frequency is different.
- 4. Wireless Mode: IEEE 802.11 Standards are selected in this menu "Wireless Mode Selection". For instance, if "1" is selected, then 802.11g users only connect. In case of selecting "0", since the users of 802.11b are able to connect, it may cause a slow transmission speed for the users of 802.11g. If "2" is selected, then 802.11a users only connect.
- 5. SSID: Is a 32 byte character unique identifier attached to the header of packets sent over a WLAN. The "SSID" between the DosaLink 540 and the user's PC should be the same. It should use the alphabet or the number. When using the alphabet, it should be distinguished between the lower and upper case.
- 6. Channel Select: The "Channel Select" menu is for channel selection methods of the DosaLink 540. The DosaLink 540 supports the selection of either "Manual" or





"Auto" for the method of channel selection. When "Manual" is selected, the channel in 7 Channel Number is set. When "Auto" is selected, the channel that has good signal strength and receives sensitivity is selected automatically from all possible channels. In the case of selecting "Auto" of 802.11a standard, if the chosen channel in 7 Channel Number is one of the channels of 802.11a, then it can be selected automatically among the possible channels of 802.11a.

- 7. Channel Number: The "Channel Number" is only available when the "Channel Select" is set to "Manual". The Channel 6 is the Factory Default value.
- 8. WEP Key Setup: If the WEP, an encryption to protect the data over the wireless area, is selected "Enable", then the user's PC to connect to the DosaLink 540 should also be set to WEP with the same information.




Figure 62 WEP Key Setup

- (1) WEP Use: Select either "enable" or "disable".
- (2) WEP Key Length: When the WEP is selected "enable" in "WEP Use", the user can select the key length of WEP from the following Table. (The encryption key can be made of numbers $(0 \sim 9)$ and the alphabet $(A \sim Z)$).

Key Length	Number Code	
	ASII	HEX
64 bits	5 Char.	13 Char.
128 bits	10 Char.	26 Char.

(3) Authentication Type: There are three different types of authentication of the wireless device.





- "Open System": All users' PCs with corresponding channel information, are able to connect to the DosaLink – 540.
- "Shared Key System": Only users' PCs with corresponding channel information and WEP key can connect to the DosaLink – 540.
- "Both System": Is controlled automatically. All wireless equipment should use the same authentication method.
- The basic setting is "Open System".
- (4) There are 4 keys for the WEP.
- (5) The stored WEP key should be selected.

13.9.2. Advanced Setup




Figure 63 Wireless Advance Setup

- (1) Tx Power Control: The transmitting power of the system can be controlled in this menu, "Tx Power Control". There are 4 different settings "AUTO, 100%, 70% and 50%".
- (2) Tx Rate Control: The transmitting data rate can be controlled at 1 ~ 54 Mbps and AUTO.
- (3) Fragmentation Threshold: The permissible packet size over wireless medium is defined. The packet size of 2346 is recommended. If the fragmentation packet error rate is high, a fragmentation threshold between 256 and 2346 can be controlled gradually. If the "Fragmentation Threshold" is established too low, then the communication performance may be poor.
- (4) RTS Threshold: The frame size is set in this menu "RTS Threshold". There are two signals (Request-to-send (RTS) and Clear-to-send (CTS)) to control the WLAN





- communication. The recommended value is 2437. If the communication flow is not smooth, then use this menu control to set the "RTS Threshold" between 0 and 2437.
- (5) Beacon Period: The "Beacon Period" controls the interval of Beacon Frame that is periodically generated from the DosaLink – 540. The default value of 100 is recommended.
- (6) DTIM Interval: The number of Beacon Interval in the DTIM is defined. It can be set to between 1 and 255.

13.9.3. WDS




Figure 64 WDS Setup

- (1) WDS Use: Select for use of the WDS. If the "Wireless Bridge (Master or Slave)" is selected in the "Wireless Setup", then it should also activate the WDS.
- (2) Mac Address: The "MAC Address 1 ~ 6" is for the MAC Address of the DosaLink 540, which may be connected by the DosaLink 540 that is activated for WDS or Wireless Bridge (Master or Slave).

13.9.4. MAC Filtering








Figure 65 MAC Filtering Setup

- (1) MAC Filtering: The access control of DosaLink 540 based on the MAC address of the user's PC is established in this menu.
 - Disable: Do not use MAC Filtering
 - Accept: The user's PCs whose MAC addresses are listed in the MAC Filtering Table are able to access the DosaLink – 540.
 - Deny: The user's PCs whose MAC addresses are listed in the MAC Filtering Table are not able to access the DosaLink – 540.
- (2) MAC Address: The new MAC address that is registered to the MAC Filtering Table is set in this "MAC Address" menu.
- (3) p: The registered MAC addresses can be confirmed.

13.9.5. 802.1x








Figure 66 802.1x Setup

- 1. 802.1x: Select either "enable" or "disable" for the use of 802.1x authentication function.
- 2. Authen Server: Input an IP address of the Authentication server.
- 3. Authen Port: The Port number that is associated with the Authentication Server should be input. The default value is 1812.
- 4. Authen Share: The "Shared Secret" is a text string that serves as a password, registered at the authentication server. It must be the same "Shared Secret" between the authentication server and the DosaLink 540.
- 5. Account Server: Input an IP address of the accounting server.
- 6. Account Port: The Port number that is associated with the accounting server should be input. The default value is 1813.
- 7. Account Share: The "Shared Secret" is a text string that serves as a password, registered at the accounting server. It must be the same "Shared Secret" between the accounting server and the DosaLink 540.
- 8. Retry Interval: The "Retry Interval" time is the amount of time after failing to authenticate from the first authentication server that a connection to the second authentication server is established in the event of using a couple of authentication servers.
- 9. Acct Interval: Set to the time interval from failing to authenticate to requesting to reauthenticate.
- 10. Web Redir: Select to use the Web Redirection function.
- 11. Web Redir IP: Input the IP address of the Web site that is to be connected automatically when IEEE 802.1x authentication is failed.





When the function of Web Redirection is activated, the message for rebooting the DosaLink – 540 appears. Then, click "OK" to reboot the DosaLink – 540. After this, the function of Web Redirection can be used.

13.9.6. nESA Key Setup




Figure 67 nESA Key Setup

- 1. TYPE: Set the Key for operating the nESA. The Key consists of 256 bits and uses a Hexadecimal number.
 - Disable: The nESA is not used.
 - Default Key: It means the Factory Default. It is not necessary for the user to input the key.
 - User Key: The user should input 64 Hex numbers for the nESA key into "User Key" or "Passphrase".
 - LinkAuthentica: This selection, the nESA Key Management System, is for the enterprise customers.
- 2. KEY: If "User" or "Passphrase" is selected in the "TYPE", then the user should input the key value manually.

13.9.7. VLAN

1. VLAN: Select to use the VLAN.





- Unauthentication VLAN ID: Set the unauthentication client's VLAN ID value (2 ~ 4095).
- 3. Authentication VLAN ID: Set the authentication client's VLAN ID value (2 ~ 4095).




Figure 68 VLAN Setup

13.9.8. WPA/ WPA2

- 1. WPA USE: Select either "enable" or "disable".
- 2. WPA AUTH TYPE: Select to use either WPA-PSK or WPA-EAP when the WPA is enabled.
- 3. WPA RADIUS IP: If the WPA-EAP is selected, then the Radius Server's IP address is input.
- 4. WPA RADIUS PORT: If the WPA-EAP is selected, then the Radius Server Port is assigned.
- 5. WPA RADIUS SECRET: If the WPA-EAP is selected, then the Radius Server's Shared Secret is input.
- 6. WPA CIPHER SUITE: Select to use either "AES" or "TKIP".
- 7. WPA KEY FORMAT: Select to use either "Passphrase" or "Hexa" in the "Pre-Shared Key Format" if the WPA-PSK is selected.
- 8. WPA PRE-SHARED KEY: Input the keys as set in "WPA KEY FORMAT".
 - Input 8 63 characters if the "Passphrase" is selected.
 - Input 64 chracters if the "Hexa" is selected.





9. RSN/WPA2 USE: Select to use WPA2.




Figure 69 WPA/ WPA2 Setup

- (a) RSN AUTH TYPE: This is the same as 2.
- (b) RSN PREAUTH: Select to use of this function.
- (c) RSN PREAUTH LIFE TIME: Establish the "Preauth Life Time".
- (d) RSN RADIUS IP: If the WPA-EAP is selected, then the Radius Server's IP address is input.
- (e) RSN RADIUS PORT: If the WPA-EAP is selected, then the Radius Server's Port is input.
- (f) RSN RADIUS SECRET: If the WPA-EAP is selected, then the Radius Server's Shared Secret is input.
- (g) RSN CIPHER SUITE: Select to use either "AES" or "TKIP".
- (h) RSN KEY FORMAT: Select to use either "Passphrase" or "Hexa" in the "Pre-Shared Key Format" if the WPA2-PSK is selected.
- (i) RSN PRE-SHARED KEY: If the WPA2-PSK is selected, then input the Pre-Shared Key.
- (j) REKEY TIME: Establish the Rekey Time.
- (k) REKEY PACKETS: Set the Rekey Packets.
- (I) REAUTH TIME: Set the Reauth Time.





Appendix I: Abbreviations and Acronyms

ADSL Asymmetric Digital Subscriber Line
AES Advanced Encryption Standard

AP Access Point
CTS Clear-to-send

DHCP Dynamic Host Configuration Protocol

DMZ Demilitarized Zone

DTIM Delivery Traffic Indication Message
EAP Extensible Authentication Protocol

IP Internet Protocol

ISP Intenet Service Provider

LAN Local Area Network

MAC Media Access Control

MD5 Message-Digest algorithm 5

MDIX Medium Dependent Interface Crossover

NAT Network Address Translation

nESA[™] nDosa Enhanced Security Algorithm

OS Operating System
PMP Point-to-MultiPoint

PPPoE Point-to-Point Protocol over Ethernet

PSK Pre-Shared Key
PtP Point-to-Point
RTS Request-to-send

SNMP Simple Network Management Protocol

SSID Service Set Identifier SSL Secure Socket Layer

TCP Transmission Control Protocol
TKIP Temporal Key Integrity Protocol

TLS Transport Layer Security

TTLS Tunneled Transport Layer Security

UDP User Datagram Protocol

VLAN Virtual Local Area Network

VPN Virtual Private Network

WAN Wide Area Network





WDS Wireless Distribution System
WEP Wired Equivalent Privacy
WLAN Wireless Local Area Network

WPA Wi-Fi Protected Access

