



User's Manual

Normal Operation:

Press the Lock button to lock the device.

Press the Unlock button to unlock the device.

Teaching a new FOB:

Press and hold the teach button on the receiver until the LEDs blink once. Then, press any button on the FOB several times until the LEDs blink twice in confirmation that the FOB has been taught. Press the teach button on the receiver to exit teach mode.

Changing the Battery:

To change the battery, remove the two screws on the FOB. Slide the old battery out of the holder and recycle. Slide the new battery in, observing proper polarity. The + side faces away from the circuit board.

NOTE: After changing batteries, press a button on the FOB three times to resynchronize the rolling code to the receiver.

Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement (Part 15.105 (b))

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Statement per Section 4.0 of RSS-100

The term "IC:" before the certification / registration number only signifies that the Industry Canada technical specifications were met.

Section 7.1.5 of RSS-GEN

Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.