

StellaCam Wireless Controller

User's Manual



For use with StellaCam II, StellaCam³ and Wat-120N, Wat-120N+ astro-video cameras

INSTRUCTION TO THE USER

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

The Receiver Unit has been tested to comply with FCC standards. FOR HOME OR OFFICE USE.

Developed and maintained by
CosmoLogic Systems, Inc.
Latest Revision 6-30-08

Contents

I. Description	4
A. Transmitter Handbox	4
Handbox Features	5
B. Receiver Unit	7
Installation On The Camera	8
II. Operating The StellaCam Wireless Controller	9
Computer Interface	9
Control Using Batch Files	10
Control Using HyperTerminal	12
III. StellaCam Wireless Controller Commands	16
IV. Receiver-Transmitter ID Matching	16
V. Troubleshooting	17
VI. Specifications	18
VII. Warranty Statement	19
Product Registration Form	19

Thank you for purchasing the StellaCam Wireless Controller for use with your StellaCam II, StellaCam3 or Wat-120N, Wat-120N+ astronomy video camera. The StellaCam Wireless Controller provides you with convenient wireless operation of your camera up to distances of 1000 feet. In addition to wireless operation, the controller also provides an easy to use computer interface allowing you to control your camera from a personal computer or send control commands from another software application.


For StellaCam3 and Wat-120N+ owners, the controller enhances your camera's operation by providing automatic exposure timing far beyond the maximum setting of 8.5 seconds available on the wired handbox. The wireless controller will now give you automatic exposure timing from 1/2000th of a second up to a full 90 minutes – including a convenient countdown display for exposures greater than one second.

I. Description

The StellaCam Wireless Controller consists of two components: a transmitter handbox unit and a receiver unit. The receiver unit plugs into the R/C control input of your camera. Power for the receiver is supplied by the camera through the R/C connector – therefore, **the receiver must be connected to the camera before applying power to the camera**. When powered on, the transmitter handbox unit sends commands to the receiver over a wireless RF data link. The handbox may be turned on either before or after the receiver/camera is on.

Each transmitter/receiver pair are matched by a unique ID address, however the receiver unit can be automatically re-programmed to match its ID with any other StellaCam wireless transmitter – see section IV for a description of this capability.

A. Transmitter Handbox



Handbox Features

Handbox Features:

(1) Exposure / Expose Timer Display:

Displays exposure time in minutes and seconds.

Displays exposure countdown timer when selected by Timer Display Switch.

(2) Gain Display:

Displays video amp gain as a percentage of full gain.

(3) Exposure Control & Timer Display Switch:

Controls exposure time when rotated.

Toggles display between “exposure time” and “exposure countdown timer” when pressed

(4) Gain Control & LED Intensity Adjust:

Controls gain of video amp when rotated.

Controls intensity of LED displays when rotated while being pressed down.

(5) Video Frame Read Display & Freeze Switch:

Flashes green when a video frame update occurs.

Turns red and freezes the current video frame when pressed. Unfreezes and starts a new exposure when pressed again.

(6) Iris Control Switch:

Enables or disables camera control over the iris of an external lens.

(7) Gamma Control Switch:

Switches gamma correction between Off, Low and High.

(8) RS232 Data Port:

Provides connectivity to a host computer using the supplied RS232 interface cable.

(9) Power On/Off Switch:

Turns power on or off when pressed.

(10) External Power Port:

Provides operation by using an external power adapter ranging from 6vdc up to 35vdc.

Uses standard 2.1mm power connector with center positive polarity.

Disables the battery saving timeout when external power is connected.

The transmitter handbox can operate up to 200 hours on 2-AA standard alkaline batteries (depending on LED intensity setting) or indefinitely from its external power input. You can also use 1.5v lithium AA batteries for much longer operation. Power is applied by pressing the POWER On/Off button. When operating on batteries and the power is left on, a “battery saving” timeout feature will automatically turn the handbox off if no settings are changed within a certain timeout period. The timeout period is factory set to 30 minutes, however the user can change it from 1 minute up to 2 hours, or disable the timeout such that it will not automatically turn off. While external power is connected, the timeout feature is automatically disabled. Battery saving timeout control is accessed over the serial RS232 data link (see Computer Interface section).

A “Batt Lo” indication is momentarily displayed at regular intervals when the battery voltage drops down to 2.7v or less. The handbox will operate for several hours following a “Lo Batt” warning, however it is recommended that either external power be applied or that the batteries be replaced when possible.

The handbox supports two different modes of operation: StellaCam II mode and StellaCam3 mode. The default is StellaCam3 mode. The operating mode is displayed on the LED readout immediately after power is turned on. The StellaCam II mode is indicated by “SC-2” and the StellaCam3 mode is indicated by “SC-3”. The two modes of operation are identical except for the exposure times that are supported. In the “SC-2” mode, only the StellaCam II exposure times of .017sec to 8.533sec are allowed. In the “SC-3” mode, exposure times ranging from .0005 seconds to 90 minutes are allowed. It should be noted that either operating mode will control all of the supported cameras, however only the exposure times appropriate to the camera being used will actually be implemented. The operating mode can be changed by accessing it over the serial RS232 data link (see Computer Interface section).

All handbox settings are stored in non-volatile memory so when you turn the power on, the settings will be the same as they were the last time it was used – including the LED intensity setting.

The handbox contains rotary knobs and switches allowing the operator to control the following camera parameters:

- Exposure Time
- Gain
- Freeze Frame
- Iris Control
- Gamma Setting

Exposure Time

Exposure times are displayed on a 4-digit LED readout. The exposure times are “dialed in” by turning a rotary knob to the desired setting. Exposure times ranging between 1 second and 5 minutes are selected with a 1-second resolution. Exposure times from 5 to 90 minutes are selected with a 1-minute resolution.

The rotary knob used for setting the exposure time also doubles as a push button switch for displaying an exposure countdown timer. When pressed, the LED readout toggles between displaying the exposure time and displaying the exposure countdown timer. If the rotary knob is turned while the countdown timer is being displayed, then the new exposure time is momentarily displayed – exposure countdown resumes after the new selection is made.

When exposure times are changed, the current exposure is adjusted to satisfy the new setting. For example, suppose the exposure time was set to 40 seconds but changed to 50 seconds. If the current exposure had been running for 20 seconds, then it will now continue for an additional 30 seconds to give you a 50-second exposure. Now suppose the 40-second exposure setting was changed to 30 seconds. If the current exposure had been running for 20 seconds, then it will now continue for only 10 more seconds to give you a 30-second exposure.

Gain

The camera’s gain is displayed on a 2-digit LED readout. The gain settings are “dialed in” by turning a rotary knob to the desired setting. The gain setting ranges from 00 to 99 corresponding to the camera’s video amplifier gain of 8dB to 38dB. Therefore the gain resolution is 0.3dB per step change. The gain setting can be interpreted as a percentage of the camera’s gain range - going from 0% (8dB) to 99% (38dB).

The gain rotary knob also doubles as an LED intensity adjustment. When pressed down while rotating, the intensity of the LED displays (including the Freeze/Read LED) is adjusted. Turning the knob clockwise increases LED brightness, turning it counter-clockwise decreases LED brightness.

Freeze Frame

When the exposure has finished (countdown goes to zero) the “READ” LED will flash green indicating that the camera video frame has been updated with a new image. The READ LED doubles as a Freeze Frame control switch. When pressed, the LED turns red indicating that the camera’s video image has been “frozen” indefinitely. When pressed again, the red LED turns off and a new exposure begins.

Iris Control

The Iris Control switch enables or disables camera control over the iris of an external lens. When a lens with auto-iris capability is connected to the auto-iris control port of the camera, the control feature of the camera can be enabled or disabled. With the Iris Control switched to the “OPEN” position, the camera control is disabled forcing the lens iris to be fully open. With the Iris Control switched to the “CTRL” position, the camera will have auto control over the lens iris, adjusting the iris opening based on the intensity of light.

Gamma Setting

Gamma correction is used to compensate for the non-linear voltage/intensity response of a monitor displaying an image from the camera. Gamma correction basically controls the overall brightness of the image.

The Gamma Setting switch allows you to choose three different levels of gamma correction to the video image. Setting the switch to the OFF position disables gamma correction (gamma = 1.0). Setting the switch to LO applies a gamma correction of 0.45 to the video image (increased intensity). Setting the switch to HI applies a gamma correction of 0.35 to the video image (highest intensity).

B. Receiver Unit

The receiver unit performs all of the camera control operations. It comes standard with an external 1.25” whip antenna, but is optionally available with an internal planar antenna. The internal antenna version has about 12% less range than the external version, but may come in handy for applications where space is limited or a small cross-sectional area is desired (i.e. reducing aperture blockage with HyperStar mounting).


The receiver unit receives commands from the transmitter handbox over a wireless RF data link. All of the camera control parameters are saved in non-volatile memory so that when you turn the power on, the settings will be the same as they were the last time it was used. If the handbox is turned off or automatically shuts down, the receiver will continue to control the camera based on the last settings it received from the transmitter.

The receiver automatically detects which type of camera it is connected to and controls it based on the commands received by the transmitter along with the camera’s capabilities. Upon power up, the receiver’s LED will flash three times if it is connected to either a StellaCam3 or Wat-120N+. The LED will flash twice if it is connected to either a StellaCam II or Wat-120N. This indicator tells the operator that the receiver has correctly detected the camera type and is functioning properly. If the receiver’s LED does not exhibit this when power is applied, then either the camera’s power plug should be pulled out and re-connected or the camera’s power source should be turned off and then back on.

Installation On The Camera

The receiver unit is installed on the camera by plugging it into the R/C port of the camera. This must be done before applying power to the camera. Installation is accomplished by orienting the receiver with respect to the camera as shown in the diagram below and then gently inserting the connector ring into the mating circular slot on the camera. Rotate the receiver slightly while applying a small amount of pressure until you feel the connector pins engage properly in their respective sockets. The receiver should be aligned vertically with the camera body. Once you achieve proper alignment of the pins, apply additional pressure until the connector ring is completely seated into the camera.

The receiver unit is very light and small, therefore it may be desirable to just leave it in the camera while the camera is being stored and not in use. This would reduce the set-up time plus eliminate wear on the connector components.



Receiver Installation


II. Operating the StellaCam Wireless Controller

The StellaCam Wireless Controller was designed to be as simple to use as possible. Simply plug the receiver unit into the R/C connector of your camera, power up the camera, and turn the transmitter handbox power on. You may now control your camera using the handbox up to 1000 feet away.

Several of the StellaCam Wireless Controllers may be operated within range of each other (at star parties) without concern for interference. They have been designed with unique ID addresses and data timing characteristics that prevent them from interfering with one another.

Computer Interface

The transmitter handbox may be operated remotely from a personal computer by using its serial RS232 data link. This feature gives you the ability to control your camera from a host computer. A serial interface cable is supplied with your wireless controller system that connects the handbox to the com port on your computer. The interface cable uses standard RJ11 phone line, therefore it can easily be extended in length if desired. If your computer does not have a COM port, then a Serial-to-USB adapter may be connected to the cable in order to connect to one of your computer's USB ports.



Computer Interface Cable Connection

To control the handbox from your computer, you can either send “text” commands from a batch (.bat) file or run a communications program such as Procomm or HyperTerminal. You can also write your own application software to send the supported “text” commands.

Control Using Batch Files

The StellaCam Wireless Controller can be controlled from your computer by using batch files to send commands to the handbox. You can create simple batch files that can be “double-clicked” to send commands directly to the handbox. A batch file consists of text commands that are executed when you double-click the file’s icon. A text editor such as Microsoft Notepad can be used to create a batch file. Below is an example of a batch file called “Set to SC2 Mode .bat”, which changes the operating mode of the wireless controller to “StellaCam II” :

Example File: “Set to SC2 Mode .bat”

```
MODE COM1: BAUD=4800 PARITY=N DATA=8 STOP=1 TO=ON XON=ON OCTS=OFF ODSR=OFF IDSR=OFF DTR=ON RTS=ON
PRINT "SC2" > COM1
```

The first line in this file initializes the com port (COM1 in this case) with the proper settings for communication with the handbox. Once the com port is initialized, data can be sent via PRINT commands. In this case, the text command “SC2” is sent out the serial COM1 port to the handbox. The com port only needs to be initialized once, however it’s usually a good idea to include the initialization command at the beginning of each batch file just to make sure the com port gets set up properly. Also, please note that only com ports 1-9 are supported by the PRINT command.

Suppose you wanted to turn off the “battery saving feature” such that the controller does not automatically shut itself off after a timeout period.* The example batch file below would accomplish this by changing the timeout period to 121.

Example File: “Turn Battery Savings Off .bat”

```
MODE COM1: BAUD=4800 PARITY=N DATA=8 STOP=1 TO=ON XON=ON OCTS=OFF ODSR=OFF IDSR=OFF DTR=ON RTS=ON
PRINT "BTO121" > COM1
```

Perhaps you would like to change the timeout period to be one hour. The batch file below accomplishes this by commanding the battery saving timeout period to be 60 minutes.

Example File: “Set Battery Saving Time-out To 60min .bat”

```
MODE COM1: BAUD=4800 PARITY=N DATA=8 STOP=1 TO=ON XON=ON OCTS=OFF ODSR=OFF IDSR=OFF DTR=ON RTS=ON
PRINT "BTO060" > COM1
```

Several controller commands can also be sent at the same time within a single batch file. This feature allows you to easily configure your camera with “pre-stored” settings for various stellar objects that you may be interested in viewing. For example, you could have a folder containing optimal camera settings for “DSO objects” that you had previously determined. To configure the camera for a particular object, you would just connect the data cable between your computer and the handbox, then double-click on the “setting” file for that object. The camera (and handbox) will then be configured with your desired settings. After this, you can disconnect the data cable and the settings will be maintained indefinitely until you decide to change them again.

* NOTE: The battery saving feature is temporarily disabled whenever external power is connected to the handbox.

Comment lines may also be added to a batch file, however they must be preceded by the text “rem” (remark). Below is an example of a typical batch command file called “M51 Camera Settings .bat”, which sends a set of commands to the handbox that may configure the camera for optimal viewing of M51:

Example File: “M51 Camera Settings .bat”

```
Echo off
```

```
Rem - Optimal Settings for SC3 camera to view M51 (Whirlpool Galaxy) with 12" LX200GPS scope at f/3.3 located in my back yard
```

```
MODE COM1: BAUD=4800 PARITY=N DATA=8 STOP=1 TO=ON XON=ON OCTS=OFF ODSR=OFF IDSR=OFF DTR=ON RTS=ON
```

```
Rem - Set Exposure To 45sec Gain=73% Gamma=LO Iris = OPEN Un-Freeze The Display
```

```
PRINT "XPS045" "GN73" "GAM1" "IRS0" "FRZ0" > COM1
```

The “Echo off” batch file command inhibits the text in the file from being sent to the screen during execution. When sending multiple commands using a batch file, all of the text commands may be on the same line following the PRINT command. Each text command must be enclosed by quotes and there must be at least one space between them. The end of the line must have the “> COMn” (where n = 1-9) designator to specify which com port is being used.

A list of supported text commands can be found in section III of this manual. This list can also be displayed when using HyperTerminal by selecting the “Display PC Commands” item in the parameter menu list, then press the Right or Left arrow key (refer to the “Control Using HyperTerminal” section).


Control Using HyperTerminal

HyperTerminal is a standard communications accessory that comes with all Windows operating systems. With HyperTerminal running, you will get a display showing all of the wireless controller parameters along with instructions on how to modify them.

To invoke HyperTerminal*, click “Start” (lower left of your computer screen), then go through the following menus:

Programs > Accessories > Communications > HyperTerminal

When HyperTerminal is invoked, the following screen will appear:




* If HyperTerminal is not on your system, then you will need to insert your Windows CD and install it.

Type in a connection name (such as “ Wireless Controller”) and click OK.




Now the following “Connect To” screen appears:



Click on the “Connect using” pull-down menu and select a com port. If you are connected to your computer’s com port then choose COM1. If you are using a Serial-to-USB adapter, then choose the com port number assigned to your adapter.* Click OK.


Now the following “COM Properties” screen appears:



Change the “Bits per second” to 4800. Set the other parameters to: Data bits = 8, Parity = None, Stop Bits = 1, Flow Control = None or XON/XOFF
Click OK.


* To identify your adapter’s com port assignment, look in the Device Manager under “ports” (Control Panel>System>Hardware>Device Manager). It will show your adapter with the assigned com port in parenthesis.

You will now have the HyperTerminal screen running as shown:



At the lower left of the screen, a clock should be running showing the elapsed time since the connection was started.

Connect the interface cable from the handbox to your computer and the message "Press ENTER Key To Connect" should be displayed on the screen. Press ENTER and a display similar to the one below will appear:



You can select a parameter by pressing the Up/Down arrow keys, then change its value by pressing the Left/Right arrow keys.

Parameters can also be changed by sending commands located in text files by using the HyperTerminal “Transfer” menu operation. For example, suppose you would like to save the optimum settings for viewing certain stellar objects in a folder. You would like to be able to just select a file that sets up the camera for optimal viewing of your favorite DSO. This can easily be done by creating text files that specify the desired settings you would like for each object. Text files can be created with a text editor such as Windows Notepad and stored in a folder. They can then be “executed” by using the HyperTerminal “Transfer” operation. In HyperTerminal you would click on “Transfer”, then select “Send Text File...”. This operation opens a popup window allowing you to select a command file from your designated folder. Double-clicking on your command file (or clicking on “Open”) causes the commands to be sent to the handbox. The new settings are then displayed on both the handbox and the HyperTerminal screen.

Below is an example of a typical text command file called “M51 Camera Settings .txt”, which may configure the camera for optimal viewing of the Whirlpool Galaxy.

Example File: “M51 Camera Settings .txt”

Optimal Settings for SC3 camera to view M51 (Whirlpool Galaxy) with 12" LX200GPS scope at f/3.3 located in my back yard

Set Exposure Time To 45 Seconds:

XPS045

Set Gain To 73%:

GN73

Set Gamma To LOW:

GAM1

Set Iris Control To OPEN:

IRS0

Un-Freeze The Display (if it was currently frozen):

FRZ0

This file consists of comment lines and command lines. Each command in this file is located directly under the comment describing it. The comment lines are optional and are only used for descriptive purposes. The command lines are required and each command must be on a separate line. A list of supported text commands can be displayed by selecting the “Display PC Commands” item in the parameter menu list, then press the Right or Left arrow key. The list can also be found in section III of this manual.

When exiting HyperTerminal, it will ask you if you want to save the connection. If you select YES, a HyperTerminal setup file (Wireless Controller.ht) will be created. The file will be located in the HyperTerminal Folder (Programs > Accessories > Communications > HyperTerminal [folder]). So the next time you want to control the handbox using HyperTerminal, just click on the “Wireless Controller.ht” icon. For convenience, you may want to create a link to “Wireless Controller.ht” and save it to your Windows desktop or some other appropriate folder.

III. StellaCam Wireless Controller Commands

The following is a list of text commands that are supported by the StellaCam Wireless Controller's RS232 computer interface:

COMMAND	DESCRIPTION	NUMERIC RANGE	UNITS
SC2<cr>	Set To StellaCam 2 Mode		
SC3<cr>	Set To StellaCam 3 Mode		
GNxx<cr>	Set Gain	00 to 99	Percentage (0%-99%)
GAMx<cr>	Set Gamma	0, 1 or 2	Off, Low or High
IRSx<cr>	Set Iris	0 or 1	Open or Control
FRZx<cr>	Set Freeze	0 or 1	Run or Freeze
BTOxxx<cr>	Change Batt Saving Time-Out	001 to 121	Minutes (121 = Always On)
XPMNxx<cr>	Set Exposure Time in Minutes	01 to 90	Minutes
XPSxxx<cr>	Set Exposure Time in Seconds	001 to 299	Seconds
XPSSxx<cr>	Set Exposure Time in Sub-Seconds	00 to 04	= .0005 .001 .002 .004 .008sec (SC3 Only)
S#<cr>	Display Serial Number ID Code	05 to 10	= .017 .033 .067 .133 .267 .533sec

Notes:

- All of the text command characters must be “upper case”.
- “x” represents a numeric value between 0 and 9.
- <cr> represents a Carriage Return (inserted in a text file by pressing the Enter key).
 - Carriage Returns are not needed when commands are used in batch files and enclosed by quotes.

IV. Receiver-Transmitter ID Matching

Each StellaCam Wireless Controller transmitter unit is “hard programmed” with a unique ID address, which is transmitted whenever data is sent to the receiver. The receiver unit has been pre-programmed with the same ID address to match its corresponding transmitter, however it is capable of automatically re-programming itself to match its ID with any other StellaCam wireless transmitter. This unique feature provides the user with flexibility for applications where multiple wireless systems may be used. For example, a single handbox could be used to control several different cameras simultaneously.

Automatic programming of the receiver's ID can be accomplished by pressing an orange pushbutton switch located on the internal circuit board – just to the right of the antenna. In order to do this, you must remove the enclosure cover of the receiver unit and install the receiver back in the camera with the circuit board exposed. Power is then applied to the camera and the orange pushbutton is pressed. The receiver's LED will blink three times to indicate that it is now ready to receive an ID signal from the transmitter. Next, turn the handbox power on and you will see the receiver's LED flash about eight times – it is now pre-programmed to match up with that handbox. Change some settings on the handbox and the receiver's LED will flash to indicate that it is receiving signals from the handbox transmitter. Turn the camera/receiver power off, remove the receiver, replace its enclosure cover, and re-insert it back in the camera. You can now control the camera with the handbox via the newly programmed receiver.

V. Troubleshooting

The StellaCam Wireless Controller utilizes Microprocessor based Control Units (MCUs) to provide all of the display and control functions. The handbox MCU generally operates fine even with very low battery conditions, however a momentary glitch on the voltage to the MCU can cause the processor to “hang up”. If this were to occur, the LED displays may freeze or go blank and the controls would become non-responsive. This situation can easily be corrected by resetting the MCU. To reset the MCU simply remove one of the AA batteries, then reinstall it (make sure that external power is not connected before doing this).

If the batteries in the handbox are getting low, a “Batt Lo” warning message will momentarily appear on the LEDs. This low battery condition may cause voltage glitches to occur when turning the power on or off. It may also cause a glitch to occur when disconnecting the external power while the handbox is on. If the batteries are low, it is recommended that they either be replaced with new batteries or that the handbox be connected to an external power source.

Even if the handbox were to “freeze up”, this would not affect the exposure timing, gain, or any other camera parameter. These parameters are controlled by the receiver unit and are independent of the handbox when no transmissions are being received from the handbox. The receiver unit is powered by the camera’s regulated 5-volt supply and is therefore not prone to problems caused by low battery voltages.

On rare occasions, the receiver may experience problems at power-up. When plugging a power connector into the camera, transients on the supply voltage may affect the receiver’s “power-on reset” circuit causing the receiver’s processor to “hang up”. When power is applied, the receiver’s LED should flash either 2 or 3 times depending on which camera it is connected to. This indicator tells the operator that the receiver has correctly detected the camera type and is functioning properly. If the receiver’s LED does not exhibit this when power is applied, then either the camera’s power plug should be pulled out and re-connected or the camera’s power source should be turned off and then back on.

VI. Specifications

Operating Temperature Range:	-35 °C to 70 °C (-31 °F to +158 °F)
Transmitter/Receiver Operating Range:	Up to 1000 feet (depending on obstacles)
Receiver Power Input:	5 volts, 14mA (from camera)
Handbox Internal Power Input:	3 volts, 5mA-to-16mA max (2 AA Batteries)
Handbox External Power Input:	6-to-35 volts DC at 50mA or greater Connector: 2.1mm with center positive polarity
Battery Life:	Approximately 200 hours of operation (depending on LED intensity or type of battery)
Battery Saving Timeout:	User Programmable (1-120 minutes or Always On)
Low Battery Warning Threshold:	2.70 volts (for 2 batteries)
Auto Exposure Range – StellaCam II Mode:	0.017sec to 8.533 sec
Auto Exposure Range – StellaCam3 Mode:	0.0005sec to 90min
Gain Settings:	00 to 99 (8dB to 38db)
Gain Resolution:	0.3dB
Serial RS232 Com Port Parameters:	
Connector:	RJ-11 phone jack with 9-pin female D-Sub adapter
Baud Rate:	4800 bits per second
Data Bits:	8 bits
Parity:	None
Stop Bits:	1, 1.5 or 2
Flow Control:	None or Xon/Xoff
Terminal Emulation:	TTY or Auto Detect
Transmitter Handbox Weight:	6 ounces
Receiver Weight:	1 ounce
Transmitter Handbox Dimensions:	Approximately 5”H x 2.8”W x 1”D
Receiver Dimensions:	3.2”H x 1.3”W x 0.6”D (external antenna version) 1.9”H x 1.3”W x 0.75”D (internal antenna version) (Note: Range is decreased about 12% with internal antenna version)

VII. Warranty Statement

The manufacturer warrants the original purchaser of the STELLACAM WIRELESS CONTROLLER (SWC) that it shall be free of defects resulting from faulty manufacturer of the product or its components for a period of one year from the date of sale. Defects covered by this warranty shall, at the option of the manufacturer, be corrected either by repair or by replacement. The replaced components will be warranted for the remainder of the original one year period.

The sole obligation of the manufacturer under this warranty is limited to repair or replacement of products pertaining to the SWC only, which prove to be defective within one year of purchase. The manufacturer shall not, in any event, be liable for any consequential damages or loss of profits of any kind resulting from the use of the SWC or the technical information enclosed in this document.

Please fill out the Product Registration Form and fax or mail it to CosmoLogic Systems, Inc. This product must be registered within thirty (30) days from the date of purchase in order to activate your warranty coverage.

Product Registration Form

Please fill out the following information and send it to:

CosmoLogic Systems, Inc.
11112 204th Ave Ct. East
Bonney Lake, WA 98391
Fax: (253) 863-1689
Email: CosmoLogic@timemachine.org

By sending this form back to us, we can let you know of additional products and upgrades as they become available. This form is also used to activate your warranty coverage.

Name	Address	
Phone	City	
Camera Type	State	Zip
StellaCam Wireless Controller Serial Number	Email	
Purchased From	Date Purchased	