Outdoor Wireless Data Transmitter

• Function Features:

- 1. Range of In & outdoor temperature:-20 to +60 degree C
- 2. Optional temperature unit of ${}^{\circ}\!F$ and ${}^{\circ}\!C$
- 3. FCC formal wireless (RF) data transmit temperature

Reset Operation

After LCD in full screen display for 66 second, it will start to detect outdoor temperature and transmit data at once.

Operation Instructions

- A) Temperature detect and data transmit
 - Detecting time: <1seconds
 - 2. When transmitting data, it will display transmitting icon
- B) Slide Switch (UNIT) change the temperature displaying unit.
- C) Slide Switch (CHANNEL) change the displaying channels.

Battery of Installation

- Open the cover of the battery compartment at the back of the unit. Insert 3 x AAA new battery ensuring the polarities are correctly aligned. Close the battery compartment after installation.

Replace batteries ensuring proper polarity, with the correct battery type, and as a simultaneous set

Remove batteries if consumed or if product is to be left unused for a long time.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Federal Communications Commission (FCC) Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.