

• | •

 ϕ

0







remote control including 12V battery

INSTRUCTIONAL INFORMATION

Open the battery compartment on the back of the remote control. To do so, push the clip towards the battery compartment cover and pull it up at the same time.

Remove the empty batteries.

Insert a 12 V battery (type A23) in the battery compartment.
 Ensure the polarity is correct (+i-).
 Return the battery compartment cover to its previous position and push it down until it locks into place.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

On, temate On/Off switch. To operate the light manually, set the switch to the "On-position. To appare the light manually, set the switch to the "On-position." I you are using many uniters covering a rings area, when using the mode! PLI-IC-Remote handles are note device (purchased apparely), all the uniters tray not inon, in that case, simply move coser to the arthers that do not har not have a foreign the device "On' switch caser to the arthers that do not har not have a foreign the arther shaded on the manual pass the handless are manually as the switch as the position of the po

INSTRUCTIONAL INFORMATION

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

Detay Power: 3x AAA bottledes, not included. Note that when the Lamben Light is unused off, there is still a very sight datin on the battledes. It his because the signal receiving component in the light must be on in order to receive a signal from the transhed emnote device.
Septical Power: A comportment Cover: A Remove screw and side off. The cover will lock in place without peopleting the screw.
A lenger: Astrock/hong from the Internal metal cross bor [Figure 1] located at the top of your paper antena, this is the bar the paper (antena is usually hung, from. If for some receive the PLL.

12W-RC hanger cannol attach to your lantern as described, it can be attached by looping hing (figure 2) around the hanger portion and then secure to any upper support component of the ontern.

Aways use good quality Akarine Batheles and never mix used and new batheles when replacing Makes use batheles are inserted with the careat polarity and removed when completely exhausted. Be careful not to short circuit the supply terminas.

Notes for Battery Usage

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables

when connecting to computer or peripheral devices).

Make sure batteries are inserted with the correct polarity and removed when completely exhausted. Be careful not to short circuit the supply terminals.





0