



Doro PhoneEasy® 618

Quick Start Guide



DESIGN BY DORO OF SWEDEN

- | | |
|----------------------------|--|
| 1. Earpiece | 13. External display |
| 2. Left selection button | 14. LEDs (Red=Battery low/charging, Green=New message/missed call) |
| 3. Call button | 15. Camera flash/Flashlight |
| 4. Speed dials | 16. Emergency button |
| 5. Voice mail | 17. Volume control |
| 6. Silent/Input method | 18. Battery cover |
| 7. Microphone | 19. Headset socket |
| 8. Messages shortcut | 20. Charging socket |
| 9. Arrow buttons | 21. Loudspeaker |
| 10. End call/Power on/off | 22. Camera lens |
| 11. Right selection button | 23. Lanyard |
| 12. Camera shortcut | |



The complete User Guide can be downloaded at www.ConsumerCellular.com/support
OR
www.doro.com
You may also view helpful how-to videos at www.ConsumerCellular.com/support

Getting Started

Charging

Warning!

Only use batteries, charger and accessories that have been approved for use with this particular model. Connecting other accessories may be dangerous and may invalidate the phone's type approval and guarantee.

When the battery is running low, is displayed and a warning signal is heard. To charge the battery, connect the AC power adapter to a wall socket and to the charging socket on the phone.

Important!

Turn off the phone and disconnect the charger before removing the battery cover.

Installing the SIM card and battery


The SIM card and battery are normally pre-installed for you. Follow these instructions should you ever need to access them yourself.

1. Remove the battery cover and the battery if it is already installed.

2. Optional: Insert the memory card into the slot under the SIM card holder. Make sure that the memory card contacts are facing upwards and push the card in, until you hear a click. Take care not to scratch or bend the contacts on the card.

To remove or replace the card, push it in until you hear a click and then pull the card out.

3. Insert the SIM card by gently sliding it into the holder. Make sure that the SIM card's contacts are facing downwards and that the cut off corner is pointing inwards. Take care not to scratch or bend the contacts on the SIM card.
4. Insert the battery by sliding it into the battery compartment. Replace the battery cover.



Important!

Use only compatible memory cards for use with this device. Compatible card type: microSD, microSDHC. Incompatible cards may damage the card and the device and corrupt data stored on the card. Memory cards are sold separately.

1. Remove the battery cover and the battery if it is already installed.

Getting Started

Turning phone on & off

Press and hold the red button on the phone to turn it on/off. It takes several seconds so keep holding until you hear the sound.

Setting the language, time and date

These are all set for you. The default menu language is English. See the full manual if you would like to change this setting.

The date and time are automatically set to the local time for the area you are in when the phone is powered on.

Start-up wizard

When starting the telephone for the first time, you can use the Start-up wizard to set some basic settings.

When Run start-up wizard? is displayed, press **Yes** to change **Language**, **Time & date**, **Ring tone**, **Volume**, **Text size** or **Themes**. Press **No** if you don't want to change.

See *Settings/General/Start-up wizard* in the complete manual.

2. Remove the battery cover and the battery if it is already installed.

Making a call

1. Enter the phone number.
2. Press to start the call.
3. Press to end the call.

Note!

There is no dial tone. Simply have the phone turned on and it is ready for use.

Receiving a call

To answer an incoming call when the flip is closed, open the flip.

If the flip is already open, or if **Open to answer** is set to **Off**:

1. Press to answer, or press **Silent** to switch off the ring signal and then **Reject** to reject the call (busy signal).
Alternately, press to reject the call directly.
2. Press to end the call.

See *Settings/Calls/Answer mode* in the complete manual.

Volume control

Use the side buttons **+**/**-** to adjust the sound volume. The volume level is indicated on the display. When a call is in progress, the volume control adjusts the earpiece volume. When the phone is ringing, the volume control adjusts the ringer volume.

3. Remove the battery cover and the battery if it is already installed.

Making a call

1. Enter the phone number.
2. Press to start the call.
3. Press to end the call.

Note!

There is no dial tone. Simply have the phone turned on and it is ready for use.

Receiving a call

To answer an incoming call when the flip is closed, open the flip.

If the flip is already open, or if **Open to answer** is set to **Off**:

1. Press to answer, or press **Silent** to switch off the ring signal and then **Reject** to reject the call (busy signal).
Alternately, press to reject the call directly.
2. Press to end the call.

See *Settings/Calls/Answer mode* in the complete manual.

5. Select **Add** to add more recipients or select **Send** to send and then press **OK**.

6. You can also modify the recipients by selecting one and press **Options** to **Edit**, **Delete** or **Delete all**.

Messages

Creating and sending text messages

1. Press shortcut or press **Menu**, scroll to and press **OK**.

2. Select **Text message** and press **OK**.

3. Type your message, then press **To**.

4. Select a recipient from phonebook and press **OK**.

Alternatively, select **Enter number** and press **OK** to add recipients manually and press **Done**.

5. Select **Add** to add more recipients or select **Send** to send and then press **OK**.

6. You can also modify the recipients by selecting one and press **Options** to **Edit**, **Delete** or **Delete all**.

Messages

Note!

If you choose to add multiple recipients, you will be charged for each recipient (maximum 10).

Reading an incoming message

When you receive a message while your phone is on, the screen will display . Press **Read** to read the message.

Creating and sending picture messages

A picture message can contain text and media objects such as pictures, sound recordings and video. Both you and the recipient must have subscriptions that support picture messages.

1. Press shortcut or press **Menu**, scroll to and press **OK**.

2. Select **Picture message** and press **OK**.

3. Type your message, then press **Options**.

4. Add items to your message from the options **Add picture**, **Add sound**, **Add video** and **Add subject**.

5. Add recipients with **To** and **Send** when ready.

See *Messages* in the complete manual.

9. Remove the battery cover and the battery if it is already installed.

Custom Settings

Silent mode

Use **Silent** to silence your ring tones.

Press and hold to activate/deactivate **Silent**.

Tip:

Press and hold + or - to temporary switch off the ring signal without opening the flip.

Changing ring tones

You can select different ring tones. Follow this sequence to reach the customization.

→**Menu**→**Settings**→**Sound**

Tone setup→Ring tone

Use to scroll between options. When you pause on a melody, you will hear its sound.

Once you have found the ring tone you wish to use, press **OK** to select.

You can use this same process to customize the tones for your the **Alarm**, **Message tone**, **Opening tone**, **Closing tone**, **Keypad tone**, **Power on** and **Power off** in the same way.

Display background (wallpaper)

You can select different display backgrounds.

→**Menu**→**Settings**→**Display**→**Wallpaper**

11. Remove the battery cover and the battery if it is already installed.

Getting Started

Selection buttons

The selection buttons have multiple functions. The current button function is shown above the selection button on the display.

Call log

Received, missed, and dialled calls are saved in a combined call log. 20 calls of each type can be stored in the log. For multiple calls related to the same number, only the most recent call is saved.

Retrieving and dialling

1. Press .

2. Use to scroll through the call log

= Received call

= Dialled call

= Missed call

3. Press to dial the highlighted number.

13. Remove the battery cover and the battery if it is already installed.

Getting Started

Selection buttons

The selection buttons have multiple functions. The current button function is shown above the selection button on the display.

Call log

Received, missed, and dialled calls are saved in a combined call log. 20 calls of each type can be stored in the log. For multiple calls related to the same number, only the most recent call is saved.

Retrieving and dialling

1. Press .

2. Use to scroll through the call log

= Received call

= Dialled call

= Missed call

3. Press to dial the highlighted number.

15. Remove the battery cover and the battery if it is already installed.

Getting Started

Selection buttons

The selection buttons have multiple functions. The current button function is shown above the selection button on the display.

Call log

Received, missed, and dialled calls are saved in a combined call log. 20 calls of each type can be stored in the log. For multiple calls related to the same number, only the most recent call is saved.

Retrieving and dialling

1. Press .

2. Use to scroll through the call log

= Received call

= Dialled call

= Missed call

Disclaimer and Limitation Of Liability

Doro AB and its affiliates, licensees and retailers assume no responsibility for any damage or loss resulting from the use of this guide. Doro AB and its affiliates or licensees assume no responsibility for any loss or claims by third parties that may arise through the use of this software. Doro AB and its affiliates or licensees assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of all important data on other media to protect against data loss.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL DORO AB OR ANY OF ITS AFFILIATES, LICENSEES AND RETAILERS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED. THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS." EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY, OR CONTENTS OF THIS DOCUMENT. DORO AB RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

16.

FCC/Industry Canada notice

This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules/Canadian ICES-003. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The FCC or Industry Canada can require you to stop using your unit if such interference cannot be eliminated.

Doro has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment.

17.

FCC/Industry Canada notice

Cet appareil est conforme aux dispositions de la partie 15 des règles de la FCC et des normes CNR d'Industrie Canada sur les appareils radio exempts de licence. Son utilisation est assujettie aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférence nuisible; et (2) cet appareil doit accepter toute interférence reçue, y compris l'interférence qui pourrait causer un fonctionnement non désiré.

Cet équipement a été testé et jugé conforme aux limites d'un appareil numérique de la Classe B, en vertu de la partie 15 des règles de la FCC et de la NMB-003 canadienne. Ces limites sont conçues pour fournir une protection raisonnable contre l'interférence nuisible dans une installation résidentielle. Cet équipement génère, utilise et peut émettre de l'énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions, peut causer une interférence nuisible aux communications radio. Toutefois, il n'est pas garanti que l'interférence ne se produira pas dans une installation particulière. Si cet équipement cause une interférence nuisible à la réception radio ou de programmes de télévision, laquelle peut être déterminée en éteignant et en allumant l'équipement, l'usager est encouragé à essayer de corriger l'interférence par l'une ou plusieurs des mesures suivantes :

- Réorientez ou relocalisez l'antenne de réception.
- Augmentez la séparation entre l'équipement et le receveur.
- Connectez l'équipement à une prise sur un circuit différent de celui auquel le receveur est connecté.
- Consultez le vendeur ou un technicien radio/de télévision pour obtenir de l'aide.

La FCC ou Industrie Canada peut vous obliger à arrêter d'utiliser votre appareil si une telle interférence ne peut pas être éliminée.

Doro n'a pas approuvé les changements ou modifications apportés à cet appareil par l'usager. Tous les changements ou modifications apportés peuvent entraîner la révocation de l'autorisation d'utilisation de l'appareil.

18.

Safety Instructions

CAUTION

The unit and the accessories can contain small parts. Keep all of the equipment out of the reach of small children. The mains adapter is the disconnect device between the product and mains power. The mains socket outlet must be close to the equipment and easily accessible.

Network services and costs

Your device is approved for use on the WCDMA 850/1900 MHz, GSM 850/1800/1900 MHz networks. To use the device, you need a subscription with a service provider.

Using network services may result in traffic costs. Some product features require support from the network, and you may need to subscribe to them.

Operating environment

Follow the rules and laws that apply wherever you are, and always turn off the unit whenever its use is prohibited or can cause interference or hazards. Only use the unit in its normal user position.

This unit complies with guidelines for radiation when it is used either in a normal position against your ear, or when it is at least 0.6 in from your body. If the unit is carried close to your body in a case, belt holder or other holder, these holders should not contain any metal, and the product should be placed at the distance from your body specified above. Make sure that the distance instructions above are followed until the transfer is complete.

Parts of the unit are magnetic. The unit can attract metal objects. Do not keep credit cards or other magnetic media near the unit. There is a risk that information stored on them can be erased.

19.

Safety Instructions

Safety Instructions

Medical units

The use of equipment that transmits radio signals, for example, mobile phones, can interfere with insufficiently protected medical equipment. Consult a doctor or the manufacturer of the equipment to determine if it has adequate protection against external radio signals, or if you have any questions.

Comply with any notices at health care facilities instructing you to turn off the unit while you are there. Hospitals and other health care facilities sometimes use equipment that can be sensitive to external radio signals.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. Persons with pacemakers:

- Should always keep the phone more than 6 inches (15 cm) from their pacemaker when the phone is turned on.
- Should not carry the phone in a breast pocket.
- Should use the ear opposite the pacemaker to minimize the potential for interference.

If you have any reason to suspect that interference is taking place, turn the phone off immediately.

Areas with explosion risk

Always turn off the unit when you are in an area where there is a risk of explosion, typically these are areas where you normally requested to turn off your car engine. Follow all signs and instructions.

In these areas, sparks can cause explosion or fire that can lead to personal injury or even death.

20.

Turn off the unit at filling stations, and any other place that has gas pumps and auto repair facilities.

Follow the restrictions that apply to the use of radio equipment near places where fuel is stored and sold, chemical factories and places where blasting is in progress. Areas with risk for explosion are often – but not always – clearly marked. This also applies to below decks on ships; the transport or storage of chemicals; vehicles that use liquid fuel (such as propane or butane); areas where the air contains chemicals or particles, such as grain, dust or metal powder.

Protect your hearing

WARNING:

Excessive exposure to loud sounds can cause hearing damage. Exposure to loud sounds while driving may distract your attention and cause an accident.

Listen to a headset at a moderate level, and do not hold the device near your ear when the loudspeaker is in use.

Emergency calls

Important!

Mobile phones such as this unit use radio signals, the mobile phone network, the terrestrial network and user-programmed functions. This means that connection cannot be guaranteed in all circumstances. Therefore, you should never rely solely on a mobile phone for very important calls such as medical emergencies.

If you use this unit while driving or riding a bicycle, keep in mind the following guidelines:

• Give full attention to driving and to the road.

Using a mobile device while driving may be distracting. If you find it disruptive or distracting while operating any type of vehicle, riding a bicycle, or performing any activity that requires your full attention, pull off the road and park before making or answering a call.

• Get to know your phone and its features such as phone book, call memory, and speakerphone.

These features help you to place your call without taking your attention off the road. See the applicable portion of this user's guide for more information.

• Use a hands-free device.

Add an extra layer of convenience and safety to your unit with one of the many hands-free accessories available. Use of a headset or other hands-free device may be legally required. Several states have in recent years passed laws making it unlawful to operate a motor vehicle while talking on a wireless phone without use of a headset, speakerphone, or other hands-free device. County and municipal ordinances may also limit or ban wireless conversations for automobile drivers. Check the status of such laws in your area and in locations to which you travel by car. For SMS text messaging, it is a recommended safety practice that you never send or view received text messages while driving; in California, and likely other states in the future, SMS messaging by a driver is also a legal violation.

• Position phone within easy reach.

Keep your eyes on the road. If you get an incoming call at an inconvenient time, let your voice mail answer it for you.

23.

Warranty and technical data

This product is guaranteed for a period of 12 months from the date of purchase. In the unlikely event of a malfunction occurring during this period, please contact Consumer Cellular. Proof of purchase is required for any service or support needed during the guarantee period.

This guarantee will not apply to a malfunction caused by an accident or a similar incident or damage, liquid penetration, negligence, abnormal usage, non-maintenance or any other circumstances on the user's part. Furthermore, this guarantee will not apply to any malfunction caused by a thunderstorm or any other voltage fluctuations. As a matter of precaution, we recommend disconnecting the charger during a thunderstorm.

Batteries are consumables and are not included in any guarantee.

This guarantee does not apply if batteries other than DORO original batteries are used.

Note!

This guarantee does not affect your legal (statutory) rights under your applicable national laws relating to the sale of consumer products.

Support

For assistance, please contact:

Email: service@ConsumerCellular.com

Website: www.ConsumerCellular.com/support

Telephone: 1-888-345-5510

30.

Need to test your cell phone? At anytime you can place a mobile phone test call to our FREE test line by dialing 1-888-460-8781 from your cellular phone. If the call is completed correctly you will hear a recorded message telling you that your mobile phone is working.

Check your minutes or change your plan. With Consumer Cellular you are in control and can change your plan at any time. To check your usage and change your plan just go to My Account at www.ConsumerCellular.com Or call 1-888-373-1777 any time. The call is free.

Specifications

Network: 850/1800/1900 Triple Band

Dimensions: 4 in x 2.1 in x 0.9 in

Weight: 3.4 oz (including battery)

Battery: 3.7V/800 mAh Li-ion battery

© 2012 Doro AB. All rights reserved.

Bluetooth® is a registered trademark of Bluetooth SIG, inc. eZiType™ is a trademark of ZI Corporation.

vCard is a trademark of the Internet Mail Consortium.

FCC ID: WS5DOR0618

PhoneEasy 618 (2011)

English QSG

Version 1.0

www.doro.com



31.

24.

Safety Instructions

IC Radiation Exposure Statement

This EUT is compliant with SAR for general population/ uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528 and IEC 62209. This equipment should be installed and operated with minimum distance 1.5 cm between the radiator and your body. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet appareil est conforme aux limites d'exposition DAS incontrôlée pour la population générale de la norme CNR-102 d'Industrie Canada et a été testé en conformité avec les méthodes de mesure et procédures spécifiées dans IEEE 1528 et IEC 62209.

Cet appareil doit être installé et utilisé avec une distance minimale de 1,5 cm entre l'émetteur et votre corps. Cet appareil et sa ou ses antennes ne doivent pas être co-localisés ou fonctionner en conjonction avec tout autre antenne ou transmetteur.

Hearing aid compatibility

Note!

For hearing aid compatibility, you should turn off the Bluetooth connectivity.

Your mobile device model complies with FCC rules governing hearing aid compatibility. These rules require an M3 microphone or higher value. The M-value, shown on the device box, refers to lower radio frequency (RF) emissions. A higher M-value generally indicates that a device model has a lower RF emissions level, which may improve the likelihood that the device will operate with certain hearing aids. Some hearing aids are more immune than others are to interference. Please consult your hearing health

26.

Care and Maintenance

- Do not disassemble or open crush, bend or deform, puncture or shred.
 - Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
 - Only use the battery for the system for which it is specified.
 - Only use the battery with a charging system that has been qualified with the system per IEEE-Std- 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
 - Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
 - Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
 - Promptly dispose of used batteries in accordance with local regulations.
 - Battery usage by children should be supervised.
 - Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
 - Improper battery use may result in a fire, explosion or other hazard.
- For those host devices that utilize a USB port as a charging source, the host device's user manual shall include a statement that the device shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

28.

The advice above applies to the unit, battery, AC power adapter and other accessories. If the phone is not working as it should, please contact Consumer Cellular for service. Don't forget the receipt or a copy of the invoice.

Battery disposal and recycling information

When the battery in this unit has reached the end of its useful life, please dispose of it according to your local environmental laws and regulations. For information about recycling cell phone batteries, go to: <http://www.rbc.org>

 The symbol to the left means that according to local laws and regulations your product should be disposed of separately from household waste. When the battery in this unit has reached the end of its useful life, take it to a collection point designated by local authorities. Some collection points accept products for free. The separate collection and recycling of your unit will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

25.

- Protect the unit from moisture. Rain/snowfall, moisture and all types of liquid can contain substances that corrode the electronic circuits. If the unit gets wet, you should remove the battery and allow the unit to dry completely before you replace it.
- Do not use or keep the unit in dusty, dirty environments. The unit's moving parts and electronic components can be damaged.
- Do not keep the unit in warm places. High temperatures can reduce the lifespan for electronic equipment, damage batteries and distort or melt certain plastics.
- Do not keep the unit in cold places. When the unit warms up to normal temperature, condensation can form on the inside which can damage the electronic circuits.
- Do not try to open the unit in any other way than that which is indicated here.
- Do not drop the unit. Do not knock or shake it either. If it is treated roughly the circuits and precision mechanics can be broken.
- Do not use strong chemicals to clean the unit.

27.

</