

*Installation
and
Instruction Guide*

CSB200
Class B AIS Transponder



CSB200 Class B AIS

GENERAL WARNINGS	3
INTRODUCTION	6
AUTOMATIC IDENTIFICATION SYSTEM (AIS).....	6
INFORMATION TRANSMITTED AND RECEIVED	7
INSTALLING THE CSB200 UNIT	8
PACKING LIST.....	8
ELECTRICAL CONNECTIONS.....	8
GPS ANTENNA.....	9
VHF ANTENNA.....	9
DATA CONNECTION.....	11
PROGRAMMING THE CSB200	13
PROAIS PROGRAM	13
STATIC DATA.....	17
GPS STATUS	18
DIAGNOSTICS	19
SERIAL DATA.....	22
OTHER VESSELS	23
SAFETY MESSAGES	24
COMMANDS.....	25
USING THE CSB200.....	27
SWITCHING ON	27
WARNING AND FAULT STATES	27
LED INDICATORS.....	28
LED STATUS INDICATORS	30
TROUBLESHOOTING GUIDE	32
SERIAL DATA INTERFACE	35
SERIAL PORT INPUT/OUTPUT.....	35
NMEA MESSAGES.....	36
PRODUCT SPECIFICATION	41
GLOSSARY	44

GENERAL WARNINGS

All marine Automatic Identification System (AIS) units utilise a satellite based system such as the Global Positioning Satellite (GPS) network or the Global Navigation Satellite System (GLONASS) network to determine position. The accuracy of these networks is variable and is affected by factors such as the antenna positioning, how many satellites are used to determine a position and how long satellite information has been received for. It is desirable wherever possible therefore to verify both your vessels AIS derived position data and other vessels AIS derived position data with visual or radar based observations.

The proAIS software is intended for use as an installation and configuration tool. The application is not a navigation tool and should not be used as such.

LICENSING

IMPORTANT: In most countries the operation of an AIS unit is included under the vessels marine VHF licence provisions. The vessel on to which the AIS unit is to be installed must therefore possess a current VHF radiotelephone licence which lists the AIS system and the vessel Call Sign and MMSI number. Please contact the relevant authority in your country for more information. In accordance with a policy of continual development and product improvement the CSB200 hardware and software may be upgraded from time to time and future versions of the CSB200 may therefore not correspond exactly with this manual. When necessary upgrades to the product will be accompanied by updates or addenda to this manual. Please take time to read this manual carefully and to understand its contents fully so that you can install and operate your AIS system correctly.

Information contained in this manual is liable to change without notice. Comar Systems Ltd disclaims any liability for consequences arising from omissions or inaccuracies in this manual and any other documentation provided with this product.

DISCLAIMER

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This software uses components and source code developed by other companies or groups.

Microsoft .Net Framework V2.0:
Copyright © 2005 Microsoft Corporation

ZedGraph Graphing component dll (<http://zedgraph.org>):
Provided under the GNU Lesser General Public License

All trademarks mentioned in this document are the property of their respective owners.

LIMITED WARRANTY

Comar Systems Ltd warrants this product to be free from defects in materials and manufacture for one year from the date of purchase. Comar Systems Ltd will, at its sole option, repair or replace any components that fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts and labour. The customer is, however, responsible for any transportation costs incurred in returning the unit to Comar Systems Ltd. This warranty does not cover failures due to abuse, misuse, accident or unauthorized alteration or repairs. The above does not affect the statutory rights of the customer.

DECLARATION OF CONFORMITY

Hereby, Comar Systems Ltd of Medina Court, Arctic Road, Cowes, Isle of Wight, PO31 7XD, United Kingdom, declare that this CSB200 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. This product carries the CE mark, notified body number and alert symbol as required by the R&TTE directive.



This product is intended for sale in the following member states:

Intended Country of Use:									
<input type="checkbox"/>									
<input type="checkbox"/>									
<input type="checkbox"/>									
<input type="checkbox"/>									

FCC Compliance:

WARNING: It is a violation of the rules of the Federal Communications Commission to input an MMSI that has not been properly assigned to the end user, or to otherwise input any inaccurate data into this device. The MMSI and Static Data in this transponder must be configured by the vendor of the device or by an appropriately qualified person in the business of installing marine communications equipment on board vessels. In no event shall the entry of static data in to this Class B device be performed by the end user. Knowingly programming a Class B device with inaccurate static data, or causing a Class B AIS to be programmed with inaccurate static data, is prohibited.

INTRODUCTION**Automatic Identification System (AIS)****How AIS Works**

The marine Automatic Identification System (AIS) is a location and vessel information reporting system. It allows vessels equipped with AIS to automatically and dynamically share and regularly update their position, speed, course and other information such as vessel identity with similarly equipped craft. Position is derived from a Global Navigation Satellite System (GNSS) network and communication between vessels is by Very High Frequency (VHF) digital transmissions. A sophisticated and automatic method of time sharing the radio channel is used to ensure that even where a large number of vessels are in one location, blocking of individual transmissions is minimised, any degradation of the expected position reporting interval is indicated to the user and even if the unit suffers extreme channel overload conditions it will always recover to normal operation.

AIS Classes

There are two classes of AIS unit fitted to vessels, Class A and Class B. In addition AIS base stations may be employed by the Coastguard, port authorities and other authorised bodies. AIS units acting as aids to navigation (A to Ns) can also be fitted to fixed and floating navigation markers such as channel markers and buoys.

Class A units are a mandatory fit under the safety of life at sea (SOLAS) convention to vessels above 300 gross tons or which carry more than 11 passengers in International waters. Many other commercial vessels and some leisure craft also fit Class A units.

Class B units are currently not a mandatory fit but authorities in several parts of the world are considering this. Class B units are designed for fitting in vessels which do not fall into the mandatory Class A fit category.

The CSB200 is a Class B unit

CSB200 Class B AIS

Information Transmitted and Received

A **Class A** unit will transmit its IMO number (if known), MMSI, Call sign and Name, length and beam, ship type, time, course over ground (COG), speed over ground (SOG), heading, navigational status, rate of turn, draught, cargo type, destination and safety related messages via a short message service (SMS) facility. Message lengths are variable with static and voyage related information being transmitted less often.

Class A ship borne reporting intervals

Ships dynamic conditions	Rate
Ship at anchor or moored	3 min
Ship 0-14 Knots	10 sec
Ship 0-14 Knots and changing course	3.3 sec
Ship 14-23 Knots	6 sec
Ship 14-23 Knots and changing course	2 sec
Ship > 23 Knots	2 sec
Ship > 23 Knots and changing course	2 sec
Ships Static Information	6 min

A **Class B** unit will transmit its MMSI, Call Sign and Name, length and beam, ship type, time, course over ground (COG), speed over ground (SOG).

Class B ship borne reporting intervals

Ships dynamic conditions	Rate
Ship with Speed Over the Ground < 2 Knots	3 min
Ship with Speed Over the Ground > 2 Knots	30 sec
Ships Static Information	6 min

CSB200 Class B AIS

INSTALLING THE CSB200 UNIT

Packing List

- 1 x CSB200 Transponder unit
- 1 x Power Cable
- 1 x PC 9pin D Male to Female Programming cable
- 1 x 9pin D Male Plug with wire ends.
- 1 x CD
- 1 x Instruction Manual

WARNING: Do not connect the CSB200 unit to a mains (line) AC electrical supply, as an electric shock or fire hazard could result.

CAUTION: Do not connect the CSB200 unit to a DC supply exceeding 15.6 V or reverse the supply polarity. Damage to the unit may result.

CAUTION: The CSB200 unit is designed for operation in the temperature range -25 °C to +55 °C. Do not install (or use) the CSB200 unit in environments which exceed this range.

CAUTION: The CSB200 unit should be installed in a location where it is protected from water and spray.

Electrical Connections

Connect a 12V DC supply (9.6-15.6V) capable of supplying 2A peak to the DC power lead.

Positive = RED Negative = BLACK

The case of the unit is not isolated from the negative terminal of the supply and therefore it is recommended that the unit is not attached to metal parts of the vessel.

CSB200 Class B AIS

Connect a suitable GPS antenna to the TNC connector (inner of the two) at the rear of the CSB200

Connect a suitable VHF antenna to the BNC connector (outer of the two) at the rear of the CSB200

GPS Antenna

The GPS antenna used must be of the active type (i.e. it should incorporate an LNA) and must be suitable for marine shipboard applications (index of protection, ruggedness, means of mounting, etc.). An antenna should be selected with a gain (in dB) depending on the length of cable between the antenna and the AIS unit; after subtraction of cable and connector losses, a minimum total gain of 25 dB should be available at the CSB200 unit GPS antenna connector.

The GPS antenna to be used for AIS use must be a dedicated antenna, i.e. not shared with any other GPS receiver.

Installation of the GPS antenna is critical for the performance of the built in GPS receiver which is used for timing of the transmitted time slots and for the supply of navigational information should the main navigational GPS fail. We strongly recommend that:

1. The GPS antenna is mounted in an elevated position and free of shadow effect from the ship's superstructure
2. The GPS antenna has a free view through 360 degrees with a vertical angle of 5 to 90 degrees above the horizon.
3. As the received GPS signal is very sensitive to noise and interference generated by other onboard transmitters, ensure that the GNSS antenna is placed as far away as possible from radar, Inmarsat and Iridium transmitters and ensure the GPS antenna is free from direct view of the radar and the Inmarsat beam.
4. It is also important that the MF/HF and other VHF transmitter antennas are kept as far away as possible from the GNSS antenna. It is good practice never to install a GNSS antenna within a radius of 5 meters from these antennas.

VHF antenna

The VHF antenna employed for AIS use:

- Must be a dedicated antenna, i.e. not shared with any other VHF transmitter/receiver.

CSB200 Class B AIS

- Must be suitable for marine shipboard applications (index of protection, ruggedness, means of mounting, etc.)
- Should be omni-directional and vertically polarised with unity gain (0 dB) with a bandwidth sufficient to maintain VSWR <1.5 over the frequency range 156 – 163 MHz. As a minimum the 3dB bandwidth must cover the two AIS channels and the DSC Channel.
- Should be mounted with at least a two metre vertical separation distance from any other VHF antenna used for speech or DSC communication.

VHF Antenna Connection

Connecting a badly mismatched VHF antenna, leaving the VHF antenna port disconnected, or shorting the VHF antenna port will activate the VSWR alarm, cause the unit to stop sending position reports or cause damage to the transponder.

Radio Frequency Exposure

To meet the requirements for Radio Frequency Exposure it is necessary to install the VHF antenna correctly and operate the AIS equipment according to the instructions.

The VHF antenna must be mounted at a minimum distance (vertical separation) of 3 metres from the head of any person standing on deck in order to meet international safety directives on Maximum Permissible Exposure (MPE) / Specific Absorption Rate (SAR).

Where no suitable structure exists to achieve a 3 metre vertical separation then the antenna base must be mounted at least 1 metre above the head of any person within range, all persons should stay outside the 3-metre safety radius and if practical a grounded RF shield should be interposed between people and the antenna.

Failure to adhere to these limits could expose persons within the 3 metre radius to RF radiation in excess of the MPE / SAR limits.

Data Connection

If an external display unit is to be used to show other AIS units within range (such as a chart plotter, PC serial terminal or other display device) connect the user end of the data interface cable to the display device. Note that the software in the display device must be configured for AIS operation .

There is a 9-way D-type female connector mounted at the rear of the CSB200. The standard wire ended data cable assembly provided mates with this connector.

9 Pin D	Cable Colour	Signal Name
1	BROWN	-NMEA Output (RS422)
2	RED	+RS232 Output
3	ORANGE	+RS232 Input
4	YELLOW	+NMEA Output (RS422)
5	GREEN	Ground
6	BLUE	Configurable Switch +
7	VIOLET	Not Used
8	GREY	+NMEA Input (RS422)
9	BLACK	-NMEA Input (RS422)

Connections to a PC.

CSB200	PC 9 Pin Serial Port
2- Red -TX Data	2- RX Data
3- Orange- RX Data	3- Transmit Data
5 -Green-Ground	5 -Ground

Connections to a Plotter.

CSB200	Plotter/Radar
1 – Brown- NMEA Output B	NMEA Input B- Return
4 – Yellow NMEA Output A	NMEA Input A - Positive

Data

The default baud rate of the data link is 38.4kBaud with 8 data bits, one stop bit and no parity. No handshaking is used.

The data interface conforms to IEC 61162-1.

VDM, VDO, RMC, ACA, ACS, ALR, TXT and ACK messages conform to NMEA 0183. Please refer to the **SERIAL DATA INTERFACE** section of this manual for full details of these AIS messages.

PROGRAMMING THE CSB200

proAIS Program

Before the CSB200 can transmit it requires to be programmed with your own vessels information. Instructions for programming the CSB200 are provided to registered vendors and are not available to the end user.

WARNING:

The entry of static data into a Class B AIS device shall be performed by the vendor of the device or by an appropriately qualified person in the business of installing marine communication equipment on board vessels. In no event shall the entry of static data into a Class B AIS device be performed by the user of the device or the licensee of a ship station using the device. Knowingly programming a Class B AIS device with inaccurate static data , or causing a Class B AIS device to be programmed with inaccurate static data, is prohibited.

You will need to provide the vendor of the CSB200 with the following information:

- Your MMSI number
- Your Vessel name
- Your Radio Callsign
- Your Vessel dimensions
- The planned location of the AIS GPS antenna on your vessel.

Requirements

The proAIS application is designed to operate with Microsoft Windows 2000, XP and above. Recommended minimum system requirements are:

- Microsoft Windows XP SP2
- Display resolution of at least 1024 x 768
- At least one RS232 serial port (or USB to serial converter already installed*)

**If you are using a USB to serial converter please ensure this is fully*

installed before proceeding.

This software uses the Microsoft .Net Framework V2.0. The Framework will be automatically installed during setup if not already present on the system.

Setup

1. Insert the installation CD and locate the Setup.exe file.
2. Double click the Setup.exe file to begin the installation.
3. Follow on screen prompts to install the .Net Framework if required
4. When the security warning below is displayed, select 'Install'




5. The application will install and launch automatically
6. A Start Menu folder and shortcut will be created with the name 'proAIS'. This short cut should be used to re-launch the application as required

Removal

The proAIS application can be removed at any time via the Windows Control Panel 'Add or Remove Programs' tool.

AIS Connection


1. Launch the proAIS application by navigating to the 'proAIS' shortcut on the Start Menu.
2. The initial application screen will appear as shown below (exact screen display depends on version installed)



3. The application requires a serial connection to the CSB200. Connect the CSB200 transponder to an available serial port.
4. Select the serial port from the drop down menu, then click 'Connect':



5. Once a connection is established the application is ready to use. Connection status is indicated at the bottom left of the application window:



6. The functions of proAIS are arranged in a series of tabs. Each tab contains information relating to a particular aspect of the connected AIS transponder. Depending on the version of proAIS installed not all tabs shown below may be visible.



- Static data tab
 - Displays the 'Static data' for the connected AIS transponder. This includes the vessel's name, call sign, MMSI number and other fixed information
- GPS Status tab
 - Shows the status of the internal GPS receiver, including position fix data and satellite signal strength graph
- Diagnostics tab
 - Shows the status of key system diagnostics. Used to troubleshoot installation of the transponder and verify correct operation.
- Other Vessels tab
 - Shows information about other vessels in the area received from the AIS transponder
- Safety messages tab
 - Displays safety related messages received from other AIS equipped vessels.
- Commands tab
 - Provides access to software controlled features of the CSB200 AIS transponder.
- Serial Data tab
 - Shows the raw NMEA serial data being generated by the


CSB200 Class B AIS

transponder. Provides a facility to log this data to a file for later analysis.

- Allows NMEA commands to be sent to the transponder


Menu Bar

Under the 'Options' menu item checking 'Beep on AIS Transmission' will cause the PC to emit a sound every time the connected AIS unit transmits.



Static Data


This tab shows the current configuration of the AIS transponder. When an un-configured AIS transponder is connected for the first time the display will be similar to that shown below:



CSB200 Class B AIS

GPS Status

This tab shows the status of the internal GPS receiver. If the GPS receiver has position fix then the current position, speed and course are shown. A bar chart of satellite signal strength is also provided.




Satellite signal strength bars are shown in green for satellites that are currently being used for navigation. Blue signal strength bars are used to show satellites not currently being used for navigation. It is normal for the graph to display a combination of green and blue bars.

The information on this tab is intended for use during installation of the AIS transponder in order to verify connection of the GPS antenna.

Diagnostics

The diagnostics tab shows key status information from the AIS transponder. This information can be used to quickly verify that the transponder has been installed correctly and is operational.



AIS Transponder Status

- A tick next to the items in this area indicates correct operation.
- If a red cross is shown then some action may be required:
 - Transponder MMSI valid has a red cross - check the MMSI of the unit is configured by selecting the 'Static Data' tab and verifying that a valid MMSI has been entered. If the MMSI is 000000000 then it has not been programmed.

- GPS position fix has a red cross - the GPS has not acquired a position fix. Please allow up to 5 minutes for a fix to be acquired. If the red cross is still present check the GPS antenna is correctly connected and has a clear view of the sky.
- AIS has transmitted a position report has a red cross - the unit has not yet transmitted its position. Please allow up to 5 minutes after GPS fix has been acquired for the green tick to appear. If the red cross is still present after this time please refer to the active alarms section below. The AIS will not transmit unless it has acquired GPS fix and has a valid MMSI programmed
- AIS has received a position report has a red cross - a position report from another vessel has been received. If there is no other AIS equipped vessel in the area the red cross will remain against this item. If other AIS equipped vessels are present and the red cross remains please check the VHF antenna connections.

AIS Transponder Active Alarms

Any active alarm messages generated by the AIS unit are shown here

- Note that alarms may take up to 1 minute to clear from this display once their source has been corrected
- It is normal for GPS related alarms to be displayed when the AIS is first switched on. These alarms will clear once GPS position fix is acquired.
- Please refer to the troubleshooting section for a description of each alarm message

AIS Transponder Information

This section shows technical information about the connected AIS transponder including software and firmware version information. Depending on the AIS software version the ability to display the GPS firmware version may not be present. If shown, clicking the 'Get version' button will retrieve the GPS firmware version. Please note that this operation may result in a temporary loss of GPS fix.

LED Status

This section mirrors the LED display on the front of the AIS transponder and is useful when the unit is installed in a location where the physical LEDs are not easily visible.

Internal Data


This section provides internal diagnostics data from your AIS transponder. Your dealer may request this information if diagnosing any problems with your installation.

Statistics

This section shows the number of AIS messages received and transmitted on each of the AIS channels. You can use this information to verify that the transponder is successfully receiving and transmitting data when other AIS equipped vessels are in range

Serial Data

This tab shows the raw NMEA 0183 serial data being output by the AIS. A typical display is shown below:




- Serial data can be logged to a file by clicking the 'Log to file' button and entering a file name and location in the dialog box.
 - Logging to file will continue if other tabs are selected after logging has been started
 - Logging to file will cease when the 'Stop logging' button is clicked
- The serial data display can be paused by clicking the pause button at the bottom right hand side of the data window. Clicking the button a second time will resume output of the live serial data.
- Transmitted AIVDO messages are indented for easy identification
- NMEA command sentences can be sent to the unit by entering

CSB200 Class B AIS

them in the lower text box and clicking the 'Send' button. proAIS will calculate and append the NMEA checksum to the sentence if the "Add Checksum" check box is checked. In this case enter a NMEA sentence without including the asterisk that precedes the checksum.

Other Vessels



MMSI	Name	Call Sign	Speed (knots)	Course	Latitude	Longitude	Distance (nm)	Class
20084000	GAS LEGACY	C4EL2	0.1	158.3	50.85972	-1.12547	56.57	A
21039000			0	246	50.84167	-1.3325	50.26	A
219347000			0	0	50.71937	-1.3245	50.45	A
222727000	NORMANDIE	FNNO	0	0	50.71783	-1.05743	63.09	A
230001340			1.5	135	50.81133	-1.097	58.89	A
230002070			0	52	50.72407	-1.48471	49.93	A
230002143			10.6	202.3	50.83439	-1.32781	50.78	A
230002401	CITY OF CHICHESTER	MVGHQ	12.1	249	50.76446	-1.34449	52.51	A
23000401	RED JET 3	MYXV3	0	20.3	50.76312	-1.2969	54.05	A
23000592			6.7	127	50.73034	-1.06989	62.28	A
230613000	NEELLOYD HUDSON	M2ER8	12.9	139.8	50.91726	-1.29679	52.19	A
230613000			1.9	317.8	50.91726	-1.29679	48.13	A
23000598			10.9	341.2	50.76851	-1.10782	59.38	A
23000514	ST CLARE	ZHNR5	10.7	70	50.77367	-1.1145	50.46	A
23000303			12.0	142.2	50.03595	-1.31231	51.06	A
23000450			9.9	176	50.4611	-1.31333	65.82	A
23000450			12.4	138	50.80298	-1.30943	49.79	A
23000472	FREEDOM 90	MUJ48	0	98	50.788	-1	58.58	A
23000473	ISLAND EXPRESS	ZIRL9	0	47	50.73283	-1.1595	59.38	A
23001219			0.2	28.1	50.79132	-1.11433	59.92	A
23001241	TENAK	MPSF5	0.1	191.0	50.83453	-1.32342	50.70	A
23001617			0	0	50.78303	-1.17433	50.81	A
23001617	ST CECILIA	MFJ78	12.7	244	50.76667	-1.12347	57.98	A
23001622			25.8	221.7	50.76667	-1.12347	58.38	A
244210000			0	240	50.70710	-1.04522	63.02	A
247007000	COSTANZA WONSILD	ICWG	0	244.4	50.83772	-1.32837	50.52	A


This tab shows information received from other AIS equipped vessels in the area.

- The MMSI of each vessel is shown.
 - Vessels equipped with Class A AIS have the MMSI displayed in black text.
 - Vessels equipped with Class B AIS have the MMSI displayed in blue text
- The name and call sign of each vessel is shown
 - Due to the way AIS operates this information may take some time to appear

CSB200 Class B AIS

- The speed in knots, course in degrees, decimal latitude and longitude are shown for each vessel
- The approximate distance to each vessel is shown when the connected unit has a GPS fix. Please note that this is an **approximate** distance for indication only.
- The class of the AIS equipment on each vessel is displayed as A or B
- Columns can be sorted into ascending or descending order by clicking on the column heading.

Safety Messages



Time (UTC)	From MMSI	Message type	Message contents


This tab displays safety related messages received from other AIS equipped vessels in the area. The tab displays two message types:

CSB200 Class B AIS

- Addressed Safety Related Message (VDL Message #12)
- Broadcast Safety Related Message (VDL Message #14)

The UTC time the message was received, along with the MMSI of the sender will be displayed along with the text contents of each message.

Commands



The commands tab provides access to software controlled features of the CSB200 transponder. Depending on the AIS software version the following commands may be available:

- Configure baud rates
 - Baud rates for the RS232 and RS422 (NMEA 0183) communications ports can be set here. The default value is 38400 & should be used where possible. The 'Update' button should be clicked to send new settings to the AIS transponder.


CSB200 Class B AIS

- Alarm output options

By default the AIS transponder will output the status of all alarms every minute using AIALR sentences. The unit can be optionally configured to only output active alarms using the radio buttons. The 'Update' button should be clicked to send new settings to the AIS transponder.

USING THE CSB200

Switching on



When the 12VDC supply is switched on the green ON LED will light and the other six LED's visible on the front panel of the unit will illuminate twice for a period of one second on each illumination. The Status, TX Off and TX LEDs will then go out. The green RX LED will flash when it is receiving data from other AIS units.

When the internal GPS is locked the yellow LED will go out and the green Status Led will light; note that this process may take several minutes depending on the switch-on state of the GPS receiver. The red TX LED will flash momentarily every time the unit transmits.

NOTE If the unit has not been programmed with an MMSI number the green RX, yellow Timeout and red Error LED will remain on.

Warning and Fault States

If the unit has not been able to transmit a position report during the last expected two reporting intervals (i.e. the nominal reporting interval cannot be maintained for operational reasons such as a Message 23 quiet period, high channel load conditions, etc) the yellow LED will illuminate. This is a **warning condition only** and indicates that your vessels position is not currently being reported to other vessels. Reception of other vessel AIS information by the CSB200 is not affected. When the unit is able to commence reporting the yellow LED goes out.

If a fault occurs the red Error LED will illuminate. This may illuminate briefly if the power supply is interrupted or if the VHF antenna characteristics are briefly affected.

If the Red Error LED illuminates continuously the unit should be assumed to be faulty and should either be switched off (power removed) or if this is not practical any other vessel position information derived from the unit should not be used and it should also be assumed that the unit is not transmitting valid position information for your vessel.

The unit should be examined by an authorised service agent at the earliest opportunity.

LED Indicators

ON

This is a green LED which indicates, when lit, that power has been connected correctly to the transponder.

Status

This is a green LED which indicates, when lit, that the transponder hardware has been configured, that the operating software is present, that the CPU has booted up, the application software is running and everything is correct.

RX

This is a green LED which indicates when flashing that the CSB200 is receiving data from other AIS transponders and is outputting this data as VDM NMEA sentences on the output data ports. If the Green LED is on continuously the unit has not been programmed with its personalised data. It will still send received data to the output port, but will not transmit.

TX

This is a red LED which flashes momentarily when the CSB200 transmits its own AIS data.

Timeout

This is a yellow LED which indicates when lit that the transmitter is prevented from transmitting. Reasons for this include the following:

- The transponder's internal GPS receiver is not operating or is not yet ready.

CSB200 Class B AIS

- The transponder was unable to transmit an AIS message due to the channel being already occupied, e.g. by transmissions from other AIS transponders, or the TX Off function is in operation.

Error

This is a red LED which indicates, when lit, one of the following status conditions is possible:

- Transmitter lockout timer (1 second maximum) has operated
- GPS is unable to gain lock after 30 minutes
- VHF antenna VSWR is out of range
- Power Supply is out of range
- Background noise level is above the threshold level (-77dBm)

Transmit Off Facility.

The Blue LED can be configured to operate in 3 modes by the proAIS program:

- Switch has no function, default mode as supplied.
- Silent mode facility is provided in the event that you do not wish to disclose your position to other users or to conserve power when it is not necessary to transmit your position. The transmitter can be turned off by connecting a simple ON/OFF switch between the Blue cable on pin 6 and the Green cable on pin 5. Closing this switch will cause the Blue-TX off LED and the Yellow Timeout LED to light, the Green Status LED will extinguish. Opening the switch will resume transmissions. Reception of AIS data during this operation will not be affected.
- Send Safety Related Message will send a Type 14 message with your MMSI number and the words MAYDAY MAYDAY. The message can be turned on by connecting a momentary push on button between the Blue cable on pin 6 and the Green cable on pin 5. Holding the switch down for 3 seconds will activate the function and cause the blue LED to light, it will stay illuminated for 1 minute, further pushes of the switch, after the Blue LED extinguishes, will repeat the message.

CSB200 Class B AIS

LED Status Indicators

Power	Status	Timeout	Error	TX Off	TX	RX	Indicates
●	●	●	●	●	●	●	
✓	✓				Blinking	Blinking	Normal
✓		✓	✓				Fixed No MMSI
✓		✓					No GPS
✓		✓		✓			Blinking Tx off Switch
✓	✓			✓			SRM switch

The table above is a quick reference check on the operational status of the CSB200, for more detailed information it is recommended to view the Diagnostics page in the proAIS program.

Built in Integrity Test

The CSB200 is equipped with Built In Integrity Testing (BIIT). BIIT tests run continuously or at appropriate intervals simultaneously with the standard functions of the equipment. The BIIT detects any failure or malfunction that will significantly reduce integrity or stop operation of the CSB200 unit.

The tests include:

- AIS TX malfunction (synthesiser not locked and TX time-out not exceeded)
- Antenna VSWR exceeds limit

CSB200 Class B AIS

- Rx channel 1 malfunction (synthesiser not locked)
- Rx channel 2 malfunction (synthesiser not locked)
- Internal GNSS not in use
- No valid SOG information
- No valid COG information
- Background noise > -77dBm
- GPS failure
- VSWR exceeding the maximum allowed level
- The input voltage is out of the specified range

MAINTENANCE

WARNING: Unauthorized opening of the CSB200 unit will invalidate the warranty.

CAUTION: Avoid using chemical solvents to clean the CBS200, solvents may damage the case material.

NOTE: The CSB200 contains no serviceable parts. Contact your local Dealer if the unit fails to function correctly.

CSB200 Class B AIS

TROUBLESHOOTING GUIDE

Problem	Possible cause	Solution
General		
CSB200 is not detected on proAIS	<p>The AIS is not connected to the serial port selected from the drop down menu.</p> <p>The AIS is not powered.</p> <p>The serial cable is damaged or faulty.</p>	<p>Check the number of the serial port the AIS is connected to and retry.</p> <p>Check that the power supply is connected and switched on.</p> <p>Try an alternative serial cable.</p>
Static Data tab		
No static data is displayed	The unit has not yet been configured	Follow instructions in the Static data section to configure the unit
The MMSI can not be changed	The MMSI has already been programmed	The MMSI can only be programmed once. If it is incorrect please contact your dealer.
The static data is incorrect	Data was entered incorrectly	Re-enter the static data and save to the AIS. The MMSI cannot be updated.
GPS tab		
No GPS position information is displayed (or graph shows only blue bars)	The unit has not acquired GPS fix	Check the GPS antenna connections and power cycle the AIS unit.

CSB200 Class B AIS

Problem	Possible cause	Solution
	The GPS antenna is not correctly connected The GPS antenna does not have a clear view of the sky GPS antenna is unsuitable for use with AIS	Check the GPS antenna location and make sure it's view of the sky is not obstructed Check the AIS installation manual against the specification of your GPS antenna
Diagnostics tab		
Red cross against a status item	Unit configuration or antenna connections	See Diagnostics tab section of this user guide for advice on each item
Active alarm shown: Position sensor fault OR SOG data fault OR COG data fault	The unit has not acquired GPS fix	Wait at least five minutes for the unit to acquire GPS position fix Follow troubleshooting guide for GPS tab
Active alarm shown: VHF Antenna VSWR fault	The VHF antenna is not connected or is not suitable for use with the AIS	Check the VHF antenna connections. Check the AIS installation manual against the specification of your VHF antenna
Active alarm shown: 12V Power supply fault	The power supply to the AIS is outside the specified range.	Check the power supply voltage to the AIS against that specified in the installation manual.

CSB200 Class B AIS

Problem	Possible cause	Solution
Active alarm shown: Channel A Noise fault OR Channel B Noise fault	The AIS cannot transmit because the background noise level is too high	Check the VHF antenna connections. Check the AIS installation manual against the specification of your VHF antenna. In very busy shipping channels this alarm may appear temporarily. This is normal operation for Class B AIS.
Active alarm shown with message not listed here	The VHF antenna is not connected or is not suitable for use with the AIS.	Check the VHF antenna connections. Check the AIS installation manual against the specification of your VHF antenna.
	AIS is faulty.	Please contact your dealer.

SERIAL DATA INTERFACE

Serial Port Input/Output

There are two serial ports, one presenting NMEA (RS422) format and the other RS232 format. Data can be input from either or both ports.

The serial port interface(s) output:

- At power-up boot-loader and main application splash text screens including version numbers and memory status.
- As a VHF Data Link Message (VDM) all incoming VHF Data Link (VDL) data received by the CSB200.
- The VHF data link own vessel (VDO) messages sent by the CSB200 over the VHF Data Link.
- AIS regional channel assignment messages (ACA) received. These are derived from an incoming VHF Data Link message (message 22) or a DSC message.
- AIS channel management information source (ACS) messages.
- Alarm messages (ALR, TXT).

The data interface will accept

- Personality programming messages
- Alarm acknowledgement messages (ACK)

On power up the unit will report details of the firmware versions residing in the unit.

NMEA Messages

Receipt of a VHF transmission on either AIS radio channel causes a VDM message to be output via the data port.

VDM Message Format

!--VDM,x1,x2,x3,a,s--s,x*hh<CR><LF>

- x1 = Total number of sentences needed to transfer the message , 1 to 9
- x2 = Sentence number, 1 to 9
- x3 = Sequential message identifier, 0 to 9
- a = AIS Channel, "A" or "B"
- s -- s = Encapsulated ITU-R M.1371 radio message
- x = Number of fill-bits, 0 to 5

VDM Message Types

For example, the information contained in the s - - s portion of the VDM = Encapsulated ITU-R M.1371 radio message. Note that messages 5 and 19 may be sent as multi part messages using the x1, x2 and x3 parameters for message sequence control

VDL Message Number	VDM Message Description
AIS Target Display Information	
1, 2, 3, 9, 18, 21	position report
4	base station report
5	voyage related data
19	Class B – extended data
Safety message handling	
12	addressed safety related
14	broadcast safety related
External Application handling	
6	binary addressed

CSB200 Class B AIS

8	binary broadcast
System control	
7	binary acknowledge (INFO)
10	UTC and data inquiry (INFO)
11	UTC and data response (INFO)
13	safety related ack (INFO)
15	interrogation (INFO)
16	assignment mode command (INFO)
17	DGNSS corrections (INFO)
20	data link management (INFO)
22	channel management (INFO)

VDO Message Format

This sentence sends the own vessels details.

Message Format

!--VDO,x1,x2,x3,a,s--s,x*hh<CR><LF>

- x1 = Total number of sentences needed to transfer the message , 1 to 9
- x2 = Sentence number, 1 to 9
- x3 = Sequential message identifier, 0 to 9
- a = AIS Channel, "A" or "B"
- s - - s = Encapsulated ITU-R M.1371 radio message 4
- x = Number of fill-bits , 0 to 5

CSB200 Class B AIS

VDO Message Number	VDO Message Description
AIS Target Display Information	
13	Safety Related Acknowledgement
18	Standard Class B position report (Includes MMSI, SOG, position accuracy, lat, long, COG, true heading,)
24a	Class B "CS" Static data Part A (Includes MMSI and vessel name)
24b	Class B "CS" Static data Part B (Includes MMSI, ship type, cargo type, call sign, ship dimensions)

ACA Message Format

The CSB200 unit can receive regional channel management information (ACA) in two ways: ITU-R M.1371 message 22 or a DSC telecommand received on channel 70,

Message Format

!--ACA,x,|||I.II,a,yyyy.y.y,a,|||I.II,a1,y1y1y1y1.y1y1,a2,x1,x2x2x2x2,

x3,x4x4x4x4, x5,x6,x7,a3,x8,hmmss.ss*hh <CR><LF>

- x = Sequence Number , 0 to 9
- |||I.II, a = Region Northeast corner latitude – N/S
- yyyy.y.y,a1 = Region Northeast corner longitude – E/W
- |||I.II,a = Region Southwest corner latitude – N/S
- y1y1y1y1.y1y1,a2 = Region Southwest corner longitude – E/W
- x1 = Transition Zone Size
- x2x2x2x2 = Channel A
- x3 = Channel A bandwidth
- x4x4x4x4 = Channel B
- x5 = Channel B bandwidth
- x6 = Tx/Rx mode control

CSB200 Class B AIS

- x7 = Power level control
- a3 = Information source
- x8 = In-Use Flag
- hhmmss.ss = Time of "in-use" change

ACS Message Format

This sentence is used in conjunction with the ACA sentence and identifies the originator of an ACA message.

\$--ACS,x,xxxxxxxx, hhmmss.ss,xx,xx,xxxx*hh <CR><LF>

- x = Sequence Number , 0 to 9
- xxxxxxxx = MMSI of originator
- hhmmss.ss = UTC of receipt of channel management information
- xx = UTC Day, 01 -31
- xx = UTC Month, 01 -12
- xxxx = UTC Year

ALR Message Format

Alarm message

\$--ALR, hhmmss.ss,xxx,A,A,c--c*hh<CR><LF>

- hhmmss.ss = Time of alarm (UTC)
- xxx = Unique alarm number
- A = Alarm condition
- A = Alarm acknowledge state
- c--c = Alarm description, text

Alarms descriptions presented are:

- AIS: TX malfunction
- AIS: Antenna VSWR exceeds limit
- AIS: Rx channel 1 malfunction

CSB200 Class B AIS

- AIS: Rx channel 2 malfunction
- AIS: general failure
- AIS: no sensor position in use
- AIS: no valid SOG information
- AIS: no valid COG information
- AIS: 12V alarm
- AIS: 5V alarm
- AIS: Loss of serial interface integrity
- AIS: Background noise above -77dBm

ACK Message Format

Can be generated by a minimum keypad and display (MKD) unit, chart plotter or other display device connected to the CSB200 to acknowledge an alarm condition reported by the CSB200.

\$--ACK,xxx*hh <CR><LF>

- xxx = Unique alarm number

RMC Message Format

Own vessels GPS information

\$GPRMC, hhmmss.ss, A, llll.llll, a, yyyy.yyyy, a, x.x, x.x, xxxx, x.x, a, a*hh <CR><LF>

- hhmmss.ss = UTC of position fix
- A = Data Valid V = Navigation receiver warning
- llll.llll, a = Latitude, N/S
- yyyy.yyyy, a = Longitude, E/W
- x.x = Speed over ground, knots
- x.x = Course over ground, degrees True
- xxxx = Date, ddmmmy
- A = Mode indicator Autonomous

PRODUCT SPECIFICATION

Physical: Dimensions 190 x 128 x 50 mm (L x W x H)
Weight 600g

Power: DC (9.6-15.6V)
Average power consumption 4W
Peak current rating 2A

GPS Receiver:

IEC 61108-1 compliant

Electrical Interfaces:

RS232 38.4kBaud bi-directional
RS422 NMEA 38.4kBaud bi-directional

Connectors:

Power
VHF Antenna connector BNC
GPS Antenna connector TNC
Interface RS232/RS422

VHF Transceiver:

Transmitter x 1
Receiver x 2
(One receiver time shared between AIS and DSC)
Frequency: 156.025 to 162.025 MHz in 25 kHz steps

Output Power:

33dBm ± 1.5 dB

Channel Bandwidth:

25kHz

Modulation Modes:

25kHz GMSK (AIS, TX and RX)
25kHz AFSK (DSC, RX only)

Bit rate: 9600 b/s ± 50 ppm (GMSK)
1200 b/s ± 30 ppm (FSK)

VHF Receiver:

Sensitivity - 107dBm 25kHz (Message Error Rate 20%)
Co-Channel 10dB
Adjacent Channel 70dB
IMD 65dB
Blocking 84dB

Environmental

IEC 60945
Operating Temperature: -25°C to +55°C

Indicators

On, TX, RX, Status, TX timeout, Error, TX Off

Standards

This product complies with all the necessary standards under the European R&TTE directive for Article 3.1(a), 3.1(b), 3.2 and 3.3(e). The following standards have been followed in pursuance of this:

IEC62287-1: 2006-03 Maritime navigation and radio communication equipment and systems – Class B ship borne equipment of the automatic identification system (AIS) – Part 1: Carrier-sense time division multiple access (CSTDMA) techniques

IEC60945: 2002-08 Maritime navigation and radio communication equipment and systems – General requirements – Methods of testing and required test results

IEC61162-1: Maritime navigation and radio communication equipment and systems – Digital interfaces – Part 1: Single talker and multiple listeners

IEC61108-1: GLOBAL NAVIGATION SATELLITE SYSTEMS (GNSS) – Part 1: Global positioning system (GPS) -Receiver equipment - Performance standards, methods of testing and required test results

EN 301 843-1 v2.1: Electromagnetic compatibility and Radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for marine radio equipment and services; Part 1: Common technical requirements

EN 50383: 2002 Basic standard for calculation and measurement of electromagnetic field strength and SAR related to human exposure from radio base stations and fixed terminal stations for wireless telecommunications system (110MHz – 40GHz)

EN60950-1:2002 Information technology equipment – Safety – Part 1: General requirements

GLOSSARY

ACA	(AIS) Regional Assignment Channel Assignment Message
ACK	Acknowledgement
ACS	(AIS) Channel management information source messages
AFSK	Audio frequency-shift keying
ALR	(AIS) Alarm Message
A to N	Aid to Navigation
AIS	Automatic Identification System
BIIT	Built In Integrity Testing
BNC	Bayonet fitting type RF connector
COG	Course over Ground
CR	Carriage Return
CS	Carrier Sense
CSTDMA	Carrier Sense Time Division Multiple Access
DC	Direct Current
DGNSS	Differential Global Navigation Satellite System
DSC	Digital Selective Calling
GLONASS	Global Navigation Satellite System
GNSS	Global Navigation Satellite System
GMSK	Gaussian Minimum Shift Keying
GPS	Global Positioning Satellite / System
HF	High Frequency
IMO	International Maritime Organization
IEC	International Electro technical Commission
LED	Light Emitting Diode
LF	Line Feed
LNA	Low-noise Amplifier
MF	Medium Frequency
MKD	Minimum Keypad and Display

CSB200 Class B AIS

MMSI	Maritime Mobile Service Identity
MPE	Maximum Permissible Exposure
NMEA	National Marine Electronics Association
PC	Personal Computer
PI	Presentation Interface
RF	Radio Frequency
RTCM	Radio Technical Commission for Maritime Services Commission
RX	Receive or Receiver
RFI	Radio Frequency Interference
SAR	Specific Absorption Rate
SELV	Separated Extra Low Voltage
SMS	Short Message System
SOG	Speed over Ground
SRM	Safety Related Message
TDMA	Time-division Multiple Access
TNC	Threaded type RF connector
TX	Transmit or Transmitter
UTC	Universal Time Co-ordinated
VDM	(AIS) VHF Data Link Messages
VDO	(AIS) VHF data link own vessel messages
VHF	Very High Frequency
VSWR	Voltage Standing Wave Ratio

CSB200 Class B AIS

COMAR SYSTEMS LTD

Medina Court

Arctic Road

Cowes

Isle of Wight

PO31 7XD

United Kingdom

Telephone: +44 (0)1983 282400

Fax: +44 (0)1983 280402

E-Mail: techsupport@comarsystems.com

Internet: www.comarsystems.com

