

1:24 Scale

User Guide



XC5857

©2010 EB Excalibur, Inc.


Please read through this instruction manual carefully before starting to operate. Please be sure to remove all accessories and components from packaging.

BATTERY REQUIREMENTS Vehicle: 3 x AA (1.5V) size batteries Transmitter: 1 x 9V size battery


TRANSMITTER BATTERY INSTALLATION



Open the battery cover on controller in the direction as shown above.



Insert 1 x 9V battery following the marked polarities.



Replace battery cover

VEHICLE BATTERY INSTALLATION



Open battery cover located at the underside




Insert 3 x AA batteries following the marked polarities



Close battery cover

HOW TO PLAY

- 1) Turn Hummer's switch to ON position for power.
- 2) Turn Transmitter's switch to ON position for power. You are set to run!



TRIM SWITCH CONTROL

Trim switch is located on the underside of the vehicle, between the two front wheels and is used to align the wheels for consistent straight line driving.



WARNING!

- 1. Do not operate the car in the vicinity of another car using the same frequency.
 2. Otherwise, radio signals may interfere with each other and the model cars may become out of control, causing accidents
- 3. Use alkaline batteries and rechargeable batteries correctly.
 4. Always turn off power of the car and the remote controller in sequence after use.
- If this model is to be stored for a long time, all batteries in the car and the remote controller should be removed to avoid battery leakage.

MAINTENANCE AND CARE

- To avoid damage to the vehicle, never drive it on a wet surface, sand, mud, or snow.
- Do not expose the vehicle to extreme temperatures.
- · Be sure to remove the batteries from the transmitter when storing the product.
- · Periodically remove dust and debris from the vehicle's wheel mechanism using a small brush, toothpick, or tweezers.
- To clean vehicle, use a damp cloth then wipe dry. Do not use chemical cleaners.
- Keep this instruction manual for future use.
- Avoid holding the wheels when rotating as this may cause the electronic components to shortcircuit, overheat, or malfunction.
- Long periods of play time can generate a high heat level which causes wear and tear. To extend product life, allow 10 minutes to cool down before installing new batteries.

HELPFUL HINTS

- If vehicle does not respond to the transmitter, move closer to the vehicle.
- · If vehicle loses power or you experience a loss of performance, charge the battery. If problem persists, check wheel mechanism for debris. If there is no debris, replace the transmitter batteries.

 When the transmitter range decreases, replace the batteries.

 Occasionally, interference from other electronic devices may occur. If so, move the
- vehicle away from other electronic devices and resume play.



A CAUTION

- Do not expose vehicle or transmitter to electric shock.
- · Do not play in thunderstorms.
- To avoid injury, do not touch the wheels when the vehicle is turned on.
- Do not leave the vehicle or transmitter near sources of heat or direct sunlight for extended periods of time or damage to electronic components may occur.
 Do not operate the vehicle near small children
- Always select a safe place to play. Never drive your vehicle in the street.
- Only batteries of the same or equivalent type as recommended are to be used.
 Do not touch the motor after play as it may be hot.



• Non-rechargeable batteries are not to be recharged

- · Rechargeable batteries must be removed before recharging
- Rechargeable batteries should only be recharged under adult supervision
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries
- · Exhausted batteries are to be removed
- Do not mix old and new batteries
- · Do not dispose of batteries in fire; batteries may explode or leak
- Do not dispose of product in fire; batteries may explode or leak
 If this product will not be used for an extended period of time, remove the batteries from the product
- The supply terminals are not to be short-circuited
- Batteries are to be inserted with correct polarity. Failure to do so may short out the batteries and damage the transmitter.

 Clean the battery contacts and also those of the product prior to battery installation

 As always, dispose of batteries in an eco-friendly manner

TROUBLESHOOTING

Problem	Causes	Correction
Vehicle doesn't move	Power switch is turned OFF. Vehicle is too far away from transmitter. Check battery installation to ensure proper polarity.	Turn the power switch ON. Bring vehicle closer to the transmitter. Re-install batteries with correct polarity.
Loss of control	Another radio control vehicle using the same frequency is operating near your vehicle.	Race against other vehicles using a different frequency or channel.
Vehicle drives slowly	Weak charge in the vehicle.	Recharge the vehicle
Poor range control	Weak battery in the transmitter. Strong interference in the surrounding area.	Replace with new batteries Move vehicle away from other electronic devices.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



HUMMER, H2, all related Emblems, and the distinctive vehicle model body and grille designs are General Motors Trademarks used under license to Shantou City Chenghai Jingwei Industrial Co., LTD

EB Excalibur, Inc.,
Miami, Florida • www.EBExcalibur.com
service@EBExcalibur.com
© 2010 EB Excalibur, Inc.
Actual product may differ slightly from photograph.