


Instruction manual

Specification:

1. Dual Mode: Wired + 2.4G
2. 3370 Sensor
3. Main switch Kailh 80M (left and right)
4. Middle switch: shunyang 3M
5. DPI side switch HUANO 3M
6. Encoder: HUANO
7. PCB waterproof
8. with PTFE mouse feet
9. 1.8 m cable
10. 700mA battery
12. DPI 800-1200 (Default)-2400-3200-6400-19000-38000

Parts and Functions

1. left button 7. turns on power and light
2. Right button 8. Turns power on and light off
3. center key 9. power off
4. Forward key 10 . Return Rate
5. Back Button 11. Rate of Return Indicator
6. DPI button 12. Wired and Charging Type-C
13. USB Receiver



Quick Start Guide

Mouse Instructions:

1. Remove the USB receiver
2. Insert the receiver into your computer's USB port.
3. Turn on the power switch on the bottom of the mouse to power on the mouse.

4. Wait for your computer to finish installing the mouse.

DPI settings and indicators:

1. Default DPI level:

800-1200 (default) - 2400-3200-6400-19000-38000 DPI Levels

2. Press the DPI button on the top of the mouse to cycle through the DPI levels.

Note

1. The DPI level can be adjusted by the software. The maximum DPI is 38000 DPI.

2. The DPI LED effect can be adjusted or turned off by the software to save power.

3. The software supports Windows systems only.

Return rate: 125-250-500-1000Hz, can be set by software.

Return rate LED color:

125 Red, 250 Blue, 500 Green, 1000 Purple

Wired and Wireless Functions:

1. Wired and wireless modes switch automatically. Simply plug the USB receiver into your computer without a cable and the mouse will work in wireless mode.

2. If you connect the USB-C cable from your computer to the mouse, the mouse will automatically switch to wired gaming mode.

Low Battery and Charging Indicators

1. Low Battery Indicator: The mouse wheel will flash red to indicate that the battery is low (10%) and you should charge the mouse by connecting it to your computer via the charging cable. 2.

2. When charging, the scroll wheel LED will flash orange. When the battery is fully charged, the LED will turn solid green.

Pairing

1. If the mouse loses its wireless connection, you can re-pair the mouse with the receiver by following the steps below: Press and hold the Left + Center + Right buttons for 3 seconds until the scroll wheel flashes yellow. 2. Release all buttons and turn the mouse off.

2. Release all buttons, move the mouse closer to the receiver, then unplug the receiver and plug it back into the USB port. When pairing is complete, the LED will stop blinking.

Warnings and Safety Measures

1. Use the device only for its intended purpose. 2.
2. Do not use the device if it is wet. 3.
3. Do not bend, twist, stretch, or heat the power cord. 4.
4. Do not use harsh chemicals (alcohol, benzene, thinner, etc.) or cleaning agents to clean the device. Use a damp, soft cloth for cleaning.
5. Do not disassemble or modify the device as this may void the warranty and damage the device.
6. This device contains electrical and electronic components and rechargeable batteries. Do not dispose of them with household waste. At the end of its useful life and use, the device should be disposed of at an appropriate disposal point.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure requirement set forth for an uncontrolled environment.