

**DRAFT**

**User Manual**

# **Orion High Voltage Thermostat**

ASSA ABLOY Hospitality

**ASSA ABLOY**

The global leader in  
door opening solutions

# **Copyrights**

*The information in this document is subject to change at the sole discretion of ASSA ABLOY without notice.*

*Any use, operation or repair in contravention of this document is at your own risk. ASSA ABLOY does not assume any responsibility for incidental or consequential damages arising from the use of this manual.*

*All information and drawings in this document are the property of ASSA ABLOY. Unauthorized use and reproduction is prohibited.*

*VingCard and Elsafer are registered trademarks of ASSA ABLOY.*

# Table of contents

<b>FCC and ISED (IC) statements.....</b>	<b>5</b>
FCC statements .....	5
ISED (IC) statements .....	6
End product labeling .....	6
<b>1. Introduction.....</b>	<b>7</b>
1.1 Orion EMS devices .....	8
1.2 Terminology .....	9
1.3 General about Orion Service .....	11
1.4 General about alarms .....	11
1.5 Events and commands .....	12
1.5.1 Thermostat event report .....	13
1.6 Basic EMS logic .....	14
1.6.1 Room occupied .....	14
1.6.2 Room unoccupied .....	14
1.6.2.1 Door open in 'room unoccupied' mode.....	15
1.6.3 Room unsold .....	15
1.6.3.1 Door open in 'room unsold' mode.....	15
1.6.4 Staff entry .....	16
1.6.4.1 Door monitored by RF door switch.....	16
1.6.4.2 Door monitored by electronic lock.....	16
1.6.5 Operating states .....	16
1.6.5.1 One interior door.....	16
1.6.5.2 One exterior door.....	17
1.6.5.3 One exterior and one interior door.....	17
1.6.6 Thermostat control chart .....	18
1.7 Orion EMS parameters .....	19
1.8 Operator templates .....	23
1.8.1 Operator template X-reference .....	24
1.9 Setback override .....	25
<b>2. Thermostat buttons and display.....</b>	<b>27</b>
2.1 Thermostat buttons .....	27
2.2 Thermostat display .....	28
<b>3. Energy management summary and alarm list.....</b>	<b>29</b>
3.1 Energy management summary .....	29
3.2 Alarm list .....	31
<b>4. Real time room status.....</b>	<b>31</b>
<b>5. Thermostats list.....</b>	<b>32</b>

<b>6. Occupancy report.....</b>	<b>37</b>
<b>7. Energy statistics report.....</b>	<b>38</b>
<b>8. Tools/Options.....</b>	<b>39</b>
<b>8.1 General .....</b>	<b>39</b>
<b>8.2 Maintenance .....</b>	<b>40</b>
<b>8.3 Housekeeping .....</b>	<b>41</b>
<b>9. Orion EMS in SysMon.....</b>	<b>42</b>
<b>9.1 Thermostats .....</b>	<b>43</b>
<b>9.2 Online commands .....</b>	<b>44</b>
<b>9.3 Broadcasts .....</b>	<b>45</b>
<b>9.4 Room events .....</b>	<b>46</b>
<b>10. Maintenance.....</b>	<b>47</b>
<b>10.1 To disassemble a thermostat .....</b>	<b>47</b>
<b>10.2 To replace a fuse .....</b>	<b>48</b>
<b>Appendix A: Quick reference of technical data.....</b>	<b>49</b>
<b>Appendix B: Troubleshooting.....</b>	<b>51</b>
<b>A/C unit not blowing hot/cold air .....</b>	<b>51</b>
<b>Fan speed not working .....</b>	<b>51</b>
<b>Thermostat has no power .....</b>	<b>52</b>
<b>Room is not going into Occupied state .....</b>	<b>52</b>
<b>A/C unit cooling when calling for heat (and vice versa) .....</b>	<b>53</b>
<b>Fan continues to run even when the thermostat is turned off .....</b>	<b>53</b>
<b>Appendix C: Read more.....</b>	<b>54</b>
<b>Revision history.....</b>	<b>54</b>

# FCC and ISED (IC) statements

## **FCC (Federal Communications Commission) statements**

These devices comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) these devices may not cause harmful interference, and
- (2) these devices must accept any interference received, including interference that may cause undesired operation.

**Important note:** To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. Use only the supplied antenna.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

These transmitters must not be co-located or operating in conjunction with any other antennas or transmitters.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The concerned end product must be labeled to say 'Contains FCC ID: Y7V-683081118C1'.

The concerned end product must be labeled to say 'FCC ID: Y7V-TZENHV'.

## **ISED (IC) statements**

These devices comply with Industry Canada licence-exempt RSS standard CAN ICES-3 (B)/NMB-3(B) B. Operation is subject to the following two conditions:

- (1) these devices may not cause interference, and
- (2) these devices must accept any interference, including interference that may cause undesired operation of the devices.

Les présents appareils sont conformes aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) les appareils ne doivent pas produire de brouillage, et
- (2) l'utilisateur des appareils doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**Important note:** To comply with Industry Canada RF radiation exposure limits for general population, the antennas used for these transmitters must be installed such that a minimum separation distance of 20 cm is maintained between the radiator (antenna) and all persons at all times and must not be co-located or operating in conjunction with any other antenna or transmitter.

Under Industry Canada regulations, these radio transmitters may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

These radio transmitters IC9514A-683081118C1 and IC9514A-TZENHV have been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with these devices.

Name/Model	Gain	Impedance
Inverted F-antenna	3.0 dBi	50 ohm

The term "IC" before the equipment certification number only signifies that the Industry Canada technical specifications were met.

Le terme "IC" devant le numéro de certification signifie seulement que les spécifications techniques Industrie Canada ont été respectées.

## **End product labeling**

The radio module is labeled with its own IC Certification Number. If the IC Certification Number is not visible when a module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module. In that case, the final end product must be labeled in a visible area with the following:

'Contains IC: 9514A-683081118C1'

'IC: 9514A-TZENHV'

# 1. Introduction

Energy is a large cost for hotels, and an EMS (*Energy Management System*) is a way of achieving energy savings in guest rooms. With the Orion EMS software option to Visionline it is possible to

- view the Orion EMS status of different rooms
- modify the configurable parameters for a room (or group of rooms/ the entire property)
- provide alarm conditions
- provide energy savings reports
- provide preventative maintenance reports

**Note:** For mounting of Orion EMS devices, installation of the software option etc, see *Installation manual Orion High VoltageThermostat*.

**Note:** This thermostat is an independently mounted control for surface mounting.

A main task for Orion EMS is to determine whether or not a guest room is physically occupied. When a room is not occupied, Orion EMS controls the HVAC (*Heating Ventilation and Air Conditioning*) systems based on the configurable settings of the system.

**Note:** For information about what firmware to use in different Orion EMS configurations, see the document *Upgrading an RFID lock for an Orion EMS offline scenario*.

**Note:** The best conditions for Orion EMS are obtained if also the locks are online and commissioned to the same ZigBee network as the thermostat and the motion sensor.

Certain Orion EMS operations cause alarms; see chapter [Energy management summary and Alarm list](#) for details. Occupancy status is included in all alarms. This allows the staff to fix the problem that caused the alarm without bothering the guest.

## 1.1 Orion EMS devices

The devices used together with Orion EMS are:

- digital thermostat *Orion High Voltage Thermostat*; from now on in this document simply called 'thermostat'
  - **Note:** The thermostat has a built-in motion sensor, but in some cases (depending on the location of the thermostat in the room)  
it can be necessary to use an external motion sensor in addition.
- door monitoring device; lock, RF door switch
  - **Note:** It is also possible to use a wired door switch without radio, but this manual mainly describes the RF door switch. For more information about wired door switches, see *Installation manual Orion High Voltage Thermostat*.
- gateway (the same as is used for online doors; requires the *Online option*)
  - **Note:** The gateway is not used in offline scenarios.




Figure 1: Orion EMS example configuration

The thermostat has a built-in ZigBee router via which it communicates to the software and the devices within the room. The thermostat stores all parameters needed for Orion EMS; if the thermostat controller is used as well, the parameters (with a few exceptions; see *Installation manual Orion High Voltage Thermostat* for details) are instead stored in the thermostat controller. The parameters are either transferred online from the software or from the *Orion Service* software; see *Quick reference guide Orion Service* for more information about the latter.

**Note:** For each room number, it is possible to have either

- one wired thermostat
- up to five motion sensors
- up to five door switches

**OR**

- one thermostat controller
- up to five battery thermostats
- up to five motion sensors
- up to five door switches

## 1.2 Terminology

<i>Deadband</i>	The range the temperature is allowed to drift before heating or cooling is activated.
<i>Default setpoint</i>	<i>Default setpoint</i> is the temperature which the thermostat is set to until a guest changes the temperature. The thermostat will also return to the <i>default setpoint</i> after guest check-out.
<i>Dynamic setback</i>	The <i>dynamic setback</i> temperatures are configured as a set number of degrees above or below the guest setting. For example, if the guest setting is 68 °F (20 °C) and the unoccupied setback is configured to 7 °F (4 °C) above the guest setting, the system will allow the temperature to drift to 75 °F (24 °C) when the room is unoccupied.
<i>EMS</i>	Energy Management System
<i>Exterior door timeout</i>	The time that will pass before the HVAC is turned off after an exterior door is left open.
<i>FCU</i>	Fan Coil Unit
<i>Freeze guard</i>	If the temperature in any room with a thermostat goes below 39 °F (4 °C), there will be an alarm and the HVAC will start heating.
<i>HVAC</i>	Heating Ventilation and Air Conditioning
<i>Intelligent switch</i>	The intelligent switch is an output for lighting control which works according to the occupancy status. The available alternatives for intelligent switch are: <ul style="list-style-type: none"> <li>• disabled; default</li> <li>• use RV output</li> <li>• use G2 output</li> </ul> If intelligent switch is applicable, normally 'Use RV output' should be marked unless the air handler is a heat pump. In the latter case, mark 'Use G2 output' instead.
<i>Motion sensor</i>	A device that detects a person's movement in an area.
<i>Occupied</i>	Someone is physically in the room; see section <a href="#">Room occupied</a> for more information.
<i>Occupied limits</i>	Limits the <i>Set temperature</i> range, i.e. the temperature which the guest can set the thermostat to.
<i>PTAC</i> ( <i>Package Terminal Air Conditioner</i> )	A PTAC is a fully self contained system that is typically located on the exterior wall of a hotel room. These units come in standard control or heat pump models.
<i>Pre-condition time</i>  <b>Note:</b> This parameter requires that the Online option has been set in Visionline.	Number of hours the thermostat shall run at the <a href="#">default setpoint</a> after check-in. If no entry has been done when this time expires, the unoccupied setback will be assumed. The <i>pre-condition time</i> can be 1-12 hours or 'disabled'; default is 2 hours.

<i>Pulse length</i>	The <a href="#">welcome scene</a> can be set up to have a pulse length: <ul style="list-style-type: none"> <li>• 0 = welcome scene always off</li> <li>• chosen length in the interval 1-255 seconds</li> </ul>
<i>Refresh cycle</i>	The Orion EMS system can, in setback control, run the A/C unit every 25 minutes for a period of 2 minutes to re-circulate the air in the room; the optional function is only for cooling mode.
<i>Setback</i>	The temperature the room is allowed to drift to when the room is unoccupied. Also see <i>dynamic setback</i> and <i>static setback</i> .
<i>Setback override</i>	The Orion EMS features can be overridden until the room is unsold again, or until a certain time. If desired, the time can be set far ahead so that the setback override is in practice until further notice.
<i>Setpoint</i>	The temperature which the guest has set on the thermostat.
<i>Static setback</i>	The static setback temperatures are configured in the system and do not change based on the guest settings. For example, if the unoccupied upper setback temperature is 79 °F (26 °C), the system will allow the temperature to drift to 79 °F (26 °C) when the room is unoccupied regardless of the thermostat setting (this example assumes that it is summertime) when the room becomes unoccupied. As soon as the guest returns to the room, the temperature is returned to the guest setting.
<i>Unoccupied</i>	No one is physically in the room although the room may be currently rented; see section <a href="#">Room unoccupied</a> for more information.
<i>Unsold</i>	The room is not currently rented and no one is in the room. In this case, a deeper setback is implemented for greater energy savings. See section <a href="#">Room unsold</a> for more information.
<i>Welcome scene</i>	If desired, it is possible to have a welcome scene which it is activated when the occupancy state for a room changes from unsold to unoccupied. The available alternatives for welcome scene are (default is 'disabled'): <ul style="list-style-type: none"> <li>• disabled</li> <li>• use RV output</li> <li>• use G2 output</li> <li>• use solid state relay</li> </ul>
<i>Table 1</i>	

### **1.3 General about Orion Service**

A *service device* and the *Orion Service* software are used for:

- initializing thermostats (setting room number and loading configurable parameters)
- commissioning the thermostat and the motion sensor in the network so the messages are routed correctly
- retrieving and displaying the event log from the thermostat
- upgrading module firmware in thermostat and motion sensor
- performing diagnostic operations, e.g.
  - simulating inputs - e.g. door switch, motion/temperature
  - reading out status of thermostat (the status of the motion sensor is also shown)
  - showing the output to the HVAC
  - making a functionality test including fast clock mode; the thermostat will raise the time one minute per second to test e.g. the *room not occupied timer*

See *Quick reference guide Orion Service* for more information about how the above operations are performed.

### **1.4 General about alarms**

All Orion EMS alarms are shown in the dialog **Energy management summary**; see [chapter 3](#) for more information. In addition, they are shown in the alarm list. Unless Orion EMS is installed as a separate client, the alarm list will also show other types of alarms not related to Orion EMS, e.g. *housekeeping failed*.

If the *Communication option* is set in the software, notifications about Orion EMS alarms can be sent via e-mail or SMS and reports can be sent by e-mail. The reports that can be sent concern e.g.

- energy savings
- preventative maintenance schedules
- occupancy (the report shows the number of occupied rooms each night; a room is regarded as occupied for the night if it is physically occupied and there is at least four hours of occupancy between 8 PM and 6 AM)
- occupancy trend (the report is combined with the energy savings report and shows occupancy during each time of the day; it is also possible to make as an average for a longer period)
- battery warnings
- events for a selected room
- offline rooms

These reports are sent via e-mail at the selected period to users that have been set up in the user notification list of the software to receive the reports; see *Installation instruction Communication option* for further information.

## **1.5 Events and commands**

To the guest, the thermostat appears and operates as a standard digital thermostat; however, this device also receives entry and exit information from the door lock or switch as well as motion detected information from the motion sensor. This information is used to determine the occupancy status of the room and implement energy savings strategy based on this information.

In order for the locks to send door events to the thermostats, EMI events must be enabled. This is achieved by presenting an *Enable EMI events card* at each lock. The card is one of the ZigBee configuration cards that can be issued in Visionline; see *Installation manual Orion High Voltage Thermostat* for details. The following events are sent to the thermostat from the motion sensor:

- motion detected
- battery status

If the lock is online, the following events are sent to the thermostat from the lock:

- door open – staff card
- door open – guest card; includes check-out date/time, suite rooms and first time use
- door open from inside
- door closed
- deadbolt thrown/released

The thermostat stores the 75 latest events in a log.

**Note:** In addition to the relevant events from the lock to the thermostat, additional events are sent from the lock to the hotel system.

There are also commands sent from the thermostat to the lock (if online) and the motion sensor:

- to the lock: the optional auto-DND, which functions as privacy; no staff cards will be able to open the door (only guest cards and emergency cards will open)
- to the motion sensor: to turn off the motion sensor when the room is occupied and the door is closed, and to turn on the motion sensor again when the door is opened

**Note:** The commands from the thermostat to lock and motion sensor are not logged as events.

### 1.5.1 Thermostat event report

The thermostat event report shows all events that have been sent online from the thermostats or been transferred to the server via *Orion Service*; see *Quick reference guide Orion Service* for details. The housekeeping function keeps the list size limited by removing events that are older than a user defined number of days; default is 7 days. To look at a thermostat event report:



1. Double click on **Thermostat events** under the **Reports** tab in the navigation window.
2. Enter the applicable search filter(s) under the tabs *Events*, *Door* or *Miscellaneous* (see more information below) before pressing the **Enter** key or clicking **OK**.

**Note:** At least one of the following requirements must be met:

- a room is selected
- one or two event sub groups are selected

3. It is also possible to reload a previous search filter: click the **Load...** button in the **Events - Search filter** dialog, browse to the desired file, mark it and click **Open**. If you want to save a search filter for future searches: click the **Save...** button, browse to where you want to save the file, give it a name and click **Save**. If the filter should be shown under **Custom** in the **Reports** tab, it must be saved in any of the following locations:
  - the folder 'Custom Reports' in the software installation folder
  - the public documents folder
  - the documents folder

The search filters that can be applied on thermostat events are:

<p><b>Events</b> – with this filter you can pick out a specific event, or certain types of events. The main types are <i>Status Changed</i> and <i>Alert</i>. Within each main type, there are event sub groups which can be divided further into specific events. If needed, use the <b>Check all/Uncheck all</b> buttons at the bottom of the dialog.</p>	 <p>Figure 2</p>
<p><b>Door</b> – with this filter you can pick out events for a certain room. Click the plus sign to expand a door area and mark the applicable door.</p>	 <p>Figure 3</p>
<p><b>Miscellaneous</b> – with this filter you can pick out events from certain event dates.</p>	 <p>Figure 4</p>

## **1.6 Basic EMS logic**

The thermostat along with the motion sensor, lock and/or RF door switches, monitors the occupancy state of the room and operates based on this information. When the room is occupied, the guest is given control and can set the desired temperature. The thermostat will then heat or cool the room as necessary to meet the guest setting. When the room is not occupied, the thermostat will operate based on the configurable parameters of the system. The three occupancy states are *occupied*, *unoccupied* and *unsold*. The following events are considered as in-room events:

- motion
- deadbolt engaged
- thermostat key pressed

### **1.6.1 Room occupied**

When the room is occupied, control of the HVAC system is given to the guest. The guest sets the desired temperature and the HVAC system will control the room based on this setting. The Orion thermostat will enter the occupied state only when the door is closed and in-room events are detected (motion, deadbolt engaged, thermostat key pressed). At this point, the guest has full control of the room temperature.

**Note:** 'Occupied limits' may be used to restrict the guest setting limits.

### **1.6.2 Room unoccupied**

When the room is not occupied, the energy management logic takes control of the room based on the configurable parameters of the system. The system will set back the temperature to the unoccupied setting. The system has both an *upper setback* and a *lower setback*. The unoccupied setbacks may be *static* or *dynamic*; for unsold rooms, only a static setback is used. See section [Terminology](#) for more information about static and dynamic setback.

The thermostat will enter the unoccupied state upon the door opening or closing. If no in-room event such as motion is detected, the thermostat will remain in the unoccupied mode. The thermostat will continue to operate at the guest setting for the duration of the configurable 'Room not occupied' timer, at which point it maintains the room temperature based on the unoccupied setback temperatures.

#### 1.6.2.1 Door open in 'room unoccupied' mode

If the door is left open, the occupancy state will remain as unoccupied regardless of whether or not motion or another in-room event is detected. There is however also a run state in the thermostat which is based on the set-point/guest setting. The run state works differently depending on whether the open door is interior or exterior, see details below.

If the open door is configured as an *interior door* (i.e., opens to another air conditioned space), the thermostat will operate based on the guest setting as long as motion or another in-room event is detected. Each time an in-room event is detected, the 'Room not occupied' timer will restart. If the 'Room not occupied' timer elapses without motion or another in-room event being detected, the thermostat will maintain the room temperature based on the unoccupied setback temperatures.

If the open door is an *exterior door* (i.e., opens to a non-climate controlled space), the thermostat will turn off after the 'Room not occupied' timer expires regardless of whether or not motion is detected.

**Note:** If the exterior door timeout is set to 'Short', the thermostat will turn off the air handler after 20 seconds. See *chapter 4 Thermostat profiles list*, section *Under the Timeout tab*, for details about setting the exterior door timeout.

#### 1.6.3 Room unsold

To achieve more energy savings when the room is not rented, the setback is deeper than when the room is rented but unoccupied. The system will enter the unsold setting when the room has been unoccupied for the duration of the configurable 'Room not sold' timer. In the unsold mode, the temperature is based on the unsold setback temperatures.

**Note:** If using an online system, the room will immediately enter the unsold mode upon receiving a check-out command from the property management system (PMS) or at guest card expiration.

**Note:** The unsold mode gives the greatest potential for energy savings. For this reason, the online system allows for maximum energy savings as the room does not need to wait until the 'Room not sold' timer elapses to enter the deep setback mode.

#### 1.6.3.1 Door open in 'room unsold' mode

Similar to the door open condition in the unoccupied state, the thermostat will control the temperature based on the guest setting when an *interior door* is open and motion (or any other in-room event) is detected for a period of time equal to the 'Room not occupied' timer. If the timer elapses with no further detection of in-room events, the thermostat will revert to maintaining the room temperature at the unsold setback. If an *exterior door* is left open, the thermostat will turn the air handler off.

## 1.6.4 Staff entry

In order to maximize energy savings, certain considerations must be taken into account when staff members enter the room.

### 1.6.4.1 Door monitored by RF door switch

If the position of the door is monitored by an RF door switch, the staff member must leave the door open to avoid interrupting the 'Room not sold' timer. If the staff member allows the door to close, the room will enter the occupied state upon motion detection. As long as the door is left open, the 'Room not sold' timer will not be reset.

### 1.6.4.2 Door monitored by electronic lock

If the door position is monitored by the electronic lock and a staff key unlocks the door, the room will not enter the occupied state even if motion is detected while the door is closed. However, if a thermostat key is pressed or the deadbolt is engaged while the door is closed, the room will enter the occupied state.

**Note:** If a staff member lets a guest into a room with the door position monitored by an electronic lock, the room will remain unoccupied until the deadbolt is engaged or a button on the thermostat is pressed.

## 1.6.5 Operating states

The following series of tables shows the operation of the system in various scenarios.

**Note:** The scenarios consider that the unoccupied (or *exterior door open*) timers have expired if applicable.

### 1.6.5.1 One interior door

Door	In-room Event (Motion/ Thermostat Key Pressed/ Deadbolt Engaged)	HVAC	State
Closed	Yes	Per guest setting	Occupied
Open	Yes	Per guest setting if opened by guest. Setback if opened by staff. If no lock interface, per guest setting.	Unoccupied or Unsold
Closed	No	Setback	Unoccupied or Unsold
Open	No	Setback	Unoccupied or Unsold
<i>Table 2</i>			

#### 1.6.5.2 One exterior door

<b>Door</b>	<b>In-room Event (Motion/ Thermostat Key Pressed/ Deadbolt Engaged)</b>	<b>HVAC</b>	<b>State</b>
Closed	Yes	Per guest setting	Occupied
Open	Yes	OFF (20 seconds or standard unoccupied time)	Unoccupied or Unsold
Closed	No	Setback	Unoccupied or Unsold
Open	No	OFF (20 seconds or standard unoccupied time)	Unoccupied or Unsold
<i>Table 3</i>			

#### 1.6.5.3 One exterior and one interior door

<b>Interior Door</b>	<b>Exterior Door</b>	<b>Motion</b>	<b>HVAC</b>	<b>State</b>
Closed	Closed	Yes	Per guest setting	Occupied
Open	Closed	Yes	Per guest setting	Unoccupied or Unsold
Closed	Open	Yes	OFF	Unoccupied or unsold
Open	Open	Yes	OFF	Unoccupied or Unsold
Closed	Closed	No	Setback	Unoccupied or Unsold
Open	Closed	No	Setback	Unoccupied or Unsold
Closed	Open	No	OFF	Unoccupied or Unsold
Open	Open	No	OFF	Unoccupied or Unsold
<i>Table 4</i>				

### 1.6.6 Thermostat control chart




Figure 5

The thermostat control can be illustrated in a control chart, see example above.

- If the temperature drifts above the setpoint or setback (depending on occupancy mode), the HVAC starts in cooling mode.
- The thermostat deadband is in this case 2 °F, so when the temperature is within 2 °F from the setpoint the HVAC is off (from 0 to 2 in the picture).
- If the temperature continues to rise, the thermostat output for 'Fan 1/Low' is triggered, then the output for 'Fan 2/Medium' and finally the output for 'Fan 3/High'.
- If the temperature starts dropping, the HVAC then switches to heating mode. There is however a heat/cool switch deadband which in this example is 3 °F, so the temperature is allowed to drift 3 °F from the setpoint before the HVAC switches from cooling mode to heating mode. From 0 to -3 in the picture the HVAC is off; the output for 'Fan 1/Low' is therefore not triggered, since this would have been at -2.
- If the temperature continues to drop, first the output for 'Fan 2/Medium' is triggered and then the output for 'Fan 3/High'.

The Orion EMS devices strive towards different temperatures depending on if the room is occupied, unoccupied or unsold.

- For 'occupied mode' the goal is the setpoint, i.e. the temperature which the guest has set on the thermostat.
- For 'unoccupied mode' the temperature drifts to the unoccupied setback, which can be static or dynamic.
- For 'unsold mode' the temperature drifts to the unsold setback.

## 1.7 Orion EMS parameters

There are a number of Orion EMS parameters whose values can be modified in the software. Different operator templates can be given different authorities to modify the parameters. Some parameters are considered as basic and some as advanced.

**Note:** In the parameter column below, it is also stated in what software dialog the parameter is found.

**Note:** The parameter *dwell-off time* is a setting that will guard against short-cycling and its value is 5 minutes. The parameter is not visible in the software and cannot be changed, not even by the distributor. Default is that the dwell-off time is off; it is only applicable when 'heat pump' is chosen as HVAC type. In the 'heat pump' case, the thermostat will automatically force the dwell-off time to be on.

Parameter	Description	Available choices	Default setting
<ul style="list-style-type: none"> <li>Default set point (<b>Thermostat profile details</b> dialog, <b>Misc</b> tab)</li> </ul>	The temperature which the thermostat is set to until a guest changes it. The thermostat will also return to the <b>Default set point</b> after check-out.	<ul style="list-style-type: none"> <li>64-75 °F</li> </ul>	70 °F
<ul style="list-style-type: none"> <li>Enable lights during pre-condition time (<b>Thermostat profile details</b> dialog, <b>Misc</b> tab)</li> </ul> <p><b>Note:</b> This parameter requires that the <i>Online</i> option has been set in Visionline.</p>	The lights are enabled according to the chosen intelligent switch setting during the pre-condition time.	<ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	Enabled
<ul style="list-style-type: none"> <li>Exterior door timeout (<b>Thermostat profile details</b> dialog, <b>Timeout</b> tab)</li> </ul>	If the exterior door is open and the default 'Normal' is used, the HVAC will - regardless of room occupancy status - turn off after the number of minutes entered at 'Room not occupied'. Default is 8 minutes; see <i>Room not occupied timer</i> in Table 6. If the exterior door is open and 'Short' is used, the HVAC will turn off after 20 seconds.	Normal/short	Normal
<ul style="list-style-type: none"> <li>Exterior input behaves as window (<b>Thermostat profile details</b> dialog, <b>Misc</b> tab)</li> </ul>	The HVAC will be shut off after a configured time ( <i>short</i> or <i>normal</i> ), but the thermostat does not change the occupancy status. The exterior door timeout is triggered by the wired input for exterior door open (EX1) on the thermostat.	<ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	Disabled
<ul style="list-style-type: none"> <li>Fan control (<b>Thermostat profile details</b> dialog, <b>Fan</b> tab)</li> </ul>	The thermostat has a button which allows the user to select from up to three fan speeds, or to choose 'Automatic' (AUTO) if the thermostat	<ul style="list-style-type: none"> <li>Auto/manual</li> <li>Max fan cool (low, mid, high)</li> </ul>	<ul style="list-style-type: none"> <li>Manual</li> <li>High</li> <li>High</li> </ul>

	<p>should determine the appropriate fan setting.</p> <p><b>Note:</b> The ability to control fan speeds depends on the capability of the air handler, as some systems do not have three fan speeds.</p>	<ul style="list-style-type: none"> <li>Max fan heat (low, mid, high)</li> </ul>	
<ul style="list-style-type: none"> <li>Fan on when satisfied (<b>Thermostat profile details</b> dialog, <b>Fan</b> tab)</li> </ul>	When enabled, the low fan speed will continue to run even when the setpoint has been reached. This only applies to an occupied room.	<ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	Disabled
<ul style="list-style-type: none"> <li>Freeze guard (<b>Thermostat profile details</b> dialog, <b>Misc</b> tab)</li> </ul>	There will be an alarm and the HVAC will start heating if the temperature in any room with thermostat goes below 39 °F (4 °C).	<ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	Enabled
<ul style="list-style-type: none"> <li>Heat/cool switch deadband (<b>Thermostat profile details</b> dialog, <b>Deadband</b> tab)</li> </ul>	<p>This parameter is only applicable if <i>auto switching</i> mode has been chosen under the <b>HVAC</b> tab in the <b>Thermostat profile details</b> dialog.</p> <p>The heat/cool switch deadband is the range the temperature is allowed to drift before switching from heat to cool or cool to heat.</p>	2-4 °F	3 °F
<ul style="list-style-type: none"> <li>Humidity control (<b>Thermostat profile details</b> dialog, <b>Misc</b> tab)</li> </ul>	<p>When the humidity control option is checked, the thermostat will implement control measures if the humidity in the room gets too high.</p> <p><b>Note:</b> The control measures will only be implemented when the room is unoccupied or unsold.</p>	<ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	Disabled
<ul style="list-style-type: none"> <li>HVAC control (<b>Thermostat profile details</b> dialog, <b>HVAC</b> tab)</li> </ul>	<p>See available choices to the right.</p> <p>'Heat pump reversed valve (Type B)' means that the reversing valve output is on when heating.</p> <p>'Heat pump reversed valve (Type O)' means that the reversing valve output is off when heating.</p>	<p>For 'HVAC heating' and 'HVAC cooling':</p> <ul style="list-style-type: none"> <li>n/a</li> <li>4-pipe fan coil</li> <li>2-pipe fan coil</li> <li>2-pipe fan coil with automatic switching</li> <li>Proportional</li> <li>Floating valve</li> </ul> <p>For 'HVAC heating' only:</p> <ul style="list-style-type: none"> <li>Heat pump reversed valve (Type B)</li> </ul> <p>For 'HVAC cooling' only:</p> <ul style="list-style-type: none"> <li>Heat pump reversed valve (Type O)</li> </ul>	n/a
<ul style="list-style-type: none"> <li>Intelligent switch (<b>Thermostat profile details</b> dialog, <b>Misc</b> tab)</li> </ul>	The intelligent switch is an output for lighting control which works according to the occupancy status. The intelligent switch is an output for lighting control which works according to the occupancy status.	<ul style="list-style-type: none"> <li>Disabled</li> <li>Use RV output</li> <li>Use G2 output</li> </ul>	Disabled

<ul style="list-style-type: none"> <li>Maintenance intervals  <b>(Tools/Options dialog, expand Energy management and choose Maintenance)</b></li> </ul>	<ul style="list-style-type: none"> <li>Number of hours before the three different maintenance alarms should be triggered.           <ul style="list-style-type: none"> <li>Maintenance counter 1 is for fan time/total HVAC time</li> <li>Maintenance counter 2 is for 'cooling'</li> <li>Maintenance counter 3 is for 'cooling or heating'</li> </ul> </li> <li>Names for the three maintenance alarms.</li> </ul>	<i>Maintenance 1:</i> 0-65535 hours  <i>Maintenance 2:</i> 0-65535 hours  <i>Maintenance 3:</i> 0-65535 hours	<i>Maintenance 1:</i> 0 hours  <i>Maintenance 2:</i> 0 hours  <i>Maintenance 3:</i> 0 hours
<ul style="list-style-type: none"> <li>Max HVAC runtime  <b>(Tools/Options dialog, expand Energy management and choose General)</b></li> </ul>	An alarm is triggered if a HVAC runs this long without turning off.	30-300 minutes	120 minutes
<ul style="list-style-type: none"> <li>Max setback override  <b>(Tools/Options dialog, expand Energy management and choose General)</b></li> </ul>	<p>The Orion EMS features may be overridden when needed, e.g. for VIP guests where no setbacks should apply; click <a href="#">here</a> for details.</p> <p>If a number of hours is entered at 'Max setback override', an alarm will be triggered if the setback override exceeds this number of hours. If the default 0 hours is used, no alarm will be triggered.</p>	0-99 hours	0 hours
<ul style="list-style-type: none"> <li>Occupied limits  <b>(Thermostat profile details dialog, Limits tab)</b></li> </ul>	With this parameter, it is possible to limit the allowed temperature range when the room is occupied. If this is the case, mark the checkbox 'Use occupied limits' and enter the values for upper limit and lower limit.	<ul style="list-style-type: none"> <li>On/off</li> <li>Upper limit (75-90 °F)</li> <li>Lower limit (62-72 °F)</li> </ul>	<ul style="list-style-type: none"> <li>Off</li> <li>84 °F</li> <li>68 °F</li> </ul>
<ul style="list-style-type: none"> <li>On exterior open, keep lights on  <b>(Thermostat profile details dialog, Misc tab)</b></li> </ul>	<p>The lights will be left on if the exterior door timeout has been triggered by</p> <ul style="list-style-type: none"> <li>- the wired input for exterior door open on the thermostat <b>OR</b></li> <li>- a non-wired door switch configured as exterior</li> </ul>	<ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	Disabled
Pre-condition time  <b>(Thermostat profile details dialog, Misc tab)</b>  <b>Note:</b> This parameter requires that the <i>Online</i> option has been set in Visionline.	Number of hours the thermostat shall run at the default setpoint after check-in. If no entry has been done when this time expires, the unoccupied setback will be assumed.	<ul style="list-style-type: none"> <li>Disabled</li> <li>1-12 hours</li> </ul>	2 hours
Pulse length  <b>(Thermostat profile details dialog, Misc tab)</b>	The welcome scene can be set up to have a pulse length.	<ul style="list-style-type: none"> <li>0 = welcome scene always off</li> <li>chosen length in the interval 1-255 seconds</li> </ul>	0 seconds

<ul style="list-style-type: none"> <li>Refresh cycle  <b>(Thermostat profile details dialog, Misc tab)</b></li> </ul>	The Orion EMS system can in setback control run the A/C unit every 25 minutes for a period of 2 minutes to re-circulate the air in the room; this optional function is only for cooling mode.	Enable/disable	Disable
<ul style="list-style-type: none"> <li>Room not occupied timer  <b>(Thermostat profile details dialog, Timeout tab)</b></li> </ul>	This is the amount of time the thermostat maintains the guest setting after the room has entered the unoccupied state.	1-120 minutes	8 minutes
<ul style="list-style-type: none"> <li>Room not sold timer  <b>(Thermostat profile details dialog, Timeout tab)</b></li> </ul>	When the room has been unoccupied for this number of hours, it will enter unsold mode.	12-24 hours	16 hours
<ul style="list-style-type: none"> <li>Set door state to closed when ajar alarm received  <b>(Thermostat profile details dialog, Misc tab)</b></li> </ul>	If the checkbox <b>Set door state to closed when door ajar alarm received</b> is marked, the door state is set to closed once the door ajar timeout has been triggered. This allows the thermostat to go to occupied state even if the door is not physically closed. <b>Note:</b> This checkbox is applicable if you have a malfunctioning door switch.	<ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	Disabled
<ul style="list-style-type: none"> <li>Temperature display  <b>(Thermostat profile details dialog, Misc tab)</b></li> </ul>	The thermostat will show either the room temperature or the temperature that has been set by the guest.	Room temperature/ set temperature	Room temperature
<ul style="list-style-type: none"> <li>Thermostat deadband  <b>(Thermostat profile details dialog, Deadband tab)</b></li> </ul>	The range the temperature is allowed to drift from the setpoint before the heat or air conditioner is turned on	1-3 °F	2 °F
<ul style="list-style-type: none"> <li>Unoccupied setbacks  <b>(Thermostat profile details dialog, Limits tab)</b></li> </ul>	The applicable number of degrees as upper limit and lower limit for setback if a room is unoccupied.	<ul style="list-style-type: none"> <li>Static/dynamic</li> <li>Static upper (72-90 °F)</li> <li>Static lower (55-70 °F)</li> <li>Dynamic upper (2-8 °F offset)</li> <li>Dynamic lower (2-8 °F offset)</li> </ul>	Static: <ul style="list-style-type: none"> <li>78 °F</li> <li>68 °F</li> </ul> Dynamic: <ul style="list-style-type: none"> <li>4 °F</li> <li>4 °F</li> </ul>
<ul style="list-style-type: none"> <li>Unsold setback  <b>(Thermostat profile details dialog, Limits tab)</b></li> </ul>	The applicable number of degrees as upper limit and lower limit for setback if a room is unsold.	<ul style="list-style-type: none"> <li>Summer (74-90 °F)</li> <li>Winter (55-70 °F)</li> </ul>	<ul style="list-style-type: none"> <li>84 °F</li> <li>64 °F</li> </ul>
<ul style="list-style-type: none"> <li>Welcome scene  <b>(Thermostat profile details dialog, Misc tab)</b></li> </ul>	If desired, it is possible to have a welcome scene which it is activated when the occupancy state for a room changes from unsold to unoccupied.	<ul style="list-style-type: none"> <li>Disabled</li> <li>Use RV output</li> <li>Use G2 output</li> <li>Use solid state relay</li> </ul>	Disabled
<i>Table 5</i>			

## 1.8 Operator templates

The operator templates decide the level of authority for different Orion EMS operations. To change the authority for handling thermostat parameters:

1. Double click on **Operator templates** under the **Lists** tab in the navigation window.
2. In the **Operator templates** dialog, mark the applicable operator template and click **Properties**; or click **Add** if a new operator template should be added.
3. In the **Operator template details** dialog, choose the tab **Energy management** in the left part of the dialog. Make the desired changes regarding
  - changing basic parameters
  - changing advanced parameters
  - [setting the room temperature](#)
  - [overriding setback mode](#)**Note:** By default, all four items above are marked for system manager but unmarked for other operator templates.
4. If a new operator template was added, go through the other tabs in the left part of the **Operator template details** dialog and fill in the applicable information; see *Setup manual Visionline* for detailed information.
5. Click **Update** (or **Save** if a new operator template was added) and **Close**.




Figure 6




Figure 7

### 1.8.1 Operator template X-reference

At **Tools/Operator template X-reference**, it is possible to change the operator template authorities for thermostat events, thermostats, thermostat profiles and EMS summary. By default, all default operators (*manager*, *system manager*, *user* and *user advanced*) can view the concerned dialogs. *System manager* can by default also add, update and remove thermostats and thermostat profiles. To change the authority for system manager, a distributor must be logged on. New operator templates (e.g. *Test Template* in the example screenshots below) will by default neither be able to view the concerned dialogs, nor add, update or remove items in the dialogs where this is applicable. To modify the authorities:

1. Go to **Tools/Operator template X-reference**.




Figure 8

2. Under the **Database** alternative in the drop-down-menu, click the plus sign in front of the concerned item. For the items *Thermostat events* and *EMS summary*, the only available alternative is **View** (see Figure 8). For the items *Thermostats* and *Thermostat profiles*, the alternatives **View**, **Add**, **Update** and **Remove** are available; see examples in the screenshots to the right. Mark the applicable alternative to the left and unmark/mark the concerned operator template(s) in the right part of the dialog.




Figure 9

3. Under the **Energy management** alternative in the drop-down-menu, mark the applicable choice in the left part of the dialog. The checkboxes to the right will reflect anything that has been saved in the **Operator template details** dialog; see section [Operator templates](#) for details. In the right part of the dialog, mark/unmark the applicable operator template(s).
4. If applicable, repeat step 3 with other alternatives in the left part of the dialog.
5. When all applicable changes according to steps 2-4 above have been performed, click **OK**.




Figure 10

## 1.9 Setback override

The Orion EMS features may be overridden when needed, e.g. for VIP guests where no setbacks should apply. Setback override may be enabled until the room is unsold or until a certain time; if desired, until further notice.

**Note:** Override mode can also be set from *Orion Service*; see *Quick reference guide Orion Service* for details. If the override mode has been set from *Orion Service*, it must also be cleared from *Orion Service*. If the override mode has been set from the **Change thermostat settings** dialog as below in this section, it can however be cleared either from *Orion Service* or from the **Change thermostat settings** dialog.



<ol style="list-style-type: none"><li>1. Double click on <b>Thermostats</b> under the <b>Lists</b> tab in the navigation window.</li><li>2. Mark the applicable thermostat and click <b>Status</b>.</li></ol>	 <p>The screenshot shows the 'Thermostats' dialog box. At the top, there are search fields for 'Search in' and 'Search for' with a dropdown menu set to 'Door'. Below the table, there are buttons for 'Add...', 'Remove', 'Properties', and 'Status'. At the bottom, there are 'Refresh', 'Print', and 'Close' buttons.</p> <table border="1"><thead><tr><th>Door</th><th>Door area</th><th>Profile</th><th>Room temperature</th><th>Set temperature</th></tr></thead><tbody><tr><td>101</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>102</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>103</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>104</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>105</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>106</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>107</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>108</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>109</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr><tr><td>110</td><td>Floor 1</td><td>Default profile</td><td>n/a</td><td>n/a</td></tr></tbody></table>	Door	Door area	Profile	Room temperature	Set temperature	101	Floor 1	Default profile	n/a	n/a	102	Floor 1	Default profile	n/a	n/a	103	Floor 1	Default profile	n/a	n/a	104	Floor 1	Default profile	n/a	n/a	105	Floor 1	Default profile	n/a	n/a	106	Floor 1	Default profile	n/a	n/a	107	Floor 1	Default profile	n/a	n/a	108	Floor 1	Default profile	n/a	n/a	109	Floor 1	Default profile	n/a	n/a	110	Floor 1	Default profile	n/a	n/a
Door	Door area	Profile	Room temperature	Set temperature																																																				
101	Floor 1	Default profile	n/a	n/a																																																				
102	Floor 1	Default profile	n/a	n/a																																																				
103	Floor 1	Default profile	n/a	n/a																																																				
104	Floor 1	Default profile	n/a	n/a																																																				
105	Floor 1	Default profile	n/a	n/a																																																				
106	Floor 1	Default profile	n/a	n/a																																																				
107	Floor 1	Default profile	n/a	n/a																																																				
108	Floor 1	Default profile	n/a	n/a																																																				
109	Floor 1	Default profile	n/a	n/a																																																				
110	Floor 1	Default profile	n/a	n/a																																																				
3. In the <b>Thermostat status</b> dialog, click the <b>Set</b> button.	 <p>The screenshot shows the 'Thermostat status - 101' dialog box. On the left, there is a tree view with 'Alarm status' (selected), 'Maintenance status', and 'Current run status'. On the right, there is a list of status items. Some items are highlighted in yellow, indicating active alarms or set points. At the bottom, there is a note: 'NO answer from thermostat' and 'Showing last known status.'.</p> <table border="1"><thead><tr><th>Alarm status</th></tr></thead><tbody><tr><td>Freeze guard active: No</td></tr><tr><td>Cooling on highest fan speed – temperature rising: No</td></tr><tr><td>Heating on highest fan speed – temperature dropping: No</td></tr><tr><td>No motion detected for 24 hours in spite of door activity: No</td></tr><tr><td><b>HVAC running for two hours without reaching set point: Yes</b></td></tr><tr><td>Maintenance interval 1 reached: No</td></tr><tr><td>Maintenance interval 2 reached: No</td></tr><tr><td>Maintenance interval 3 reached: No</td></tr><tr><td>Battery alarm (motion sensor): No</td></tr><tr><td>Battery alarm (thermostat): No</td></tr><tr><td>Door left open: No</td></tr><tr><td>Motion sensor: online</td></tr><tr><td><b>Lock: offline</b></td></tr><tr><td>Thermostat: online</td></tr><tr><td>Excessive occupancy (48 hours without state change): No</td></tr><tr><td>Temperature sensor is failing: No</td></tr><tr><td>The manual setback override has triggered an alarm: No</td></tr></tbody></table>	Alarm status	Freeze guard active: No	Cooling on highest fan speed – temperature rising: No	Heating on highest fan speed – temperature dropping: No	No motion detected for 24 hours in spite of door activity: No	<b>HVAC running for two hours without reaching set point: Yes</b>	Maintenance interval 1 reached: No	Maintenance interval 2 reached: No	Maintenance interval 3 reached: No	Battery alarm (motion sensor): No	Battery alarm (thermostat): No	Door left open: No	Motion sensor: online	<b>Lock: offline</b>	Thermostat: online	Excessive occupancy (48 hours without state change): No	Temperature sensor is failing: No	The manual setback override has triggered an alarm: No																																					
Alarm status																																																								
Freeze guard active: No																																																								
Cooling on highest fan speed – temperature rising: No																																																								
Heating on highest fan speed – temperature dropping: No																																																								
No motion detected for 24 hours in spite of door activity: No																																																								
<b>HVAC running for two hours without reaching set point: Yes</b>																																																								
Maintenance interval 1 reached: No																																																								
Maintenance interval 2 reached: No																																																								
Maintenance interval 3 reached: No																																																								
Battery alarm (motion sensor): No																																																								
Battery alarm (thermostat): No																																																								
Door left open: No																																																								
Motion sensor: online																																																								
<b>Lock: offline</b>																																																								
Thermostat: online																																																								
Excessive occupancy (48 hours without state change): No																																																								
Temperature sensor is failing: No																																																								
The manual setback override has triggered an alarm: No																																																								

Figure 11

Figure 12

4. In the **Change thermostat settings** dialog, change the **Override mode** to the applicable one of 'Manual (until unsold)' or 'Manual (until time)'. If the latter is chosen, enter the applicable **Time**.  
**Note:** If 'Manual (until time)' is chosen, the time is limited by the parameter 'Max setback override'; see section [General](#) for details. If 'Max setback override' is 0 (default), there is however no limitation in time and the Orion EMS features can be overridden until further notice.
5. Click the **Set** button next to the **Override mode** drop-down menu. The information will be transferred online to the thermostat.
6. Click **Close**.




Figure 13

To set the room temperature:

1. Enter the desired temperature at **Set temperature** in the **Change thermostat settings** dialog, and click the **Set** button next to that field. The information will be transferred online to the thermostat.

## 2. Thermostat buttons and display

### 2.1 Thermostat buttons

The hotel guest controls the thermostat using the five buttons shown on the right side of the unit in Figure 14.




Figure 14

Button	Description
1	On/Off
2	°C/°F
3	Fan control
4	Increase temperature
5	Decrease temperature

Table 6

## 2.2 Thermostat display

The thermostat displays settings and operation details to the guest, e.g. room temperature and heat/cool indications.



Figure 15

**Note:** After some seconds of inactivity of the thermostat buttons, the display will shut down. The first key press of any button will activate the display again, and then the buttons work as normal until the next inactivity timeout occurs.

**Note:** Some of the indicators are not yet implemented in the thermostat firmware and therefore not described in the below table.

Display indicator	Description	
1	Temperature	The temperature display area shows the actual room temperature or the setpoint temperature as well as the indication of Fahrenheit or Celsius. What to display is configured when setting up the thermostat profile for the concerned thermostat; choose 'Set temperature' or 'Room temperature' under the <b>Misc</b> alternative in the <b>Thermostat profile details</b> dialog of Visionline, see <a href="#">Figure 16</a> . If 'Room temperature' is chosen, the thermostat will still display the <i>set temperature</i> for a few seconds when the guest uses the <a href="#">Increase/Decrease temperature buttons</a> . The thermostat will then revert to show the <i>room temperature</i> again. When the displayed temperature is the guest setting and not the actual room temperature, the <b>SET</b> indicator is also displayed.
2	Heat/Cool	The thermostat displays universal icons for heating and cooling. The snow star is the symbol to indicate the unit is in cooling mode and the sun is the symbol to indicate heating mode.
3	Fan	The <i>Fan</i> indicator shows the fan speed of the unit. As the fan speed increases, additional segments of the indicator are displayed. When in AUTO fan mode, the word <i>AUTO</i> will appear at the <i>Miscellaneous</i> indicator, see below.
4	Miscellaneous	The <i>Miscellaneous</i> indicator is a multi-purpose indicator; it e.g. displays the word <i>AUTO</i> when the automatic fan mode is enabled.
5	Wrench	The <i>Wrench</i> indicator is displayed when maintenance is required on any of the Orion EMS devices in the room or on the HVAC unit. This icon is only displayed to hotel staff. To get the details of the maintenance needed, connect the service cable to the thermostat and choose the <b>Status</b> alternative in <i>Orion Service</i> .
6	Battery	The <i>Battery</i> indicator is displayed to hotel staff when the batteries are low (on battery powered units) and in need of replacement. <b>Note:</b> This is a low indicator only, not a segmented icon that displays the battery level. As soon as this indicator is displayed, the batteries need to be replaced. <b>Note:</b> If the lock is not used to monitor the door status, the service indicators will only be displayed when the service cable is connected to the thermostat and <i>Orion Service</i> is used.
Table 7		




Figure 16

### 3. Energy management summary and alarm list

An EMS overview is shown in the dialog **Energy management summary**. The dialog shows **Occupancy Status** and **HVAC Run Status** in circle diagrams, and **Runtime %**, **Maintenance** and **Current Alarms** in xy diagrams. The current alarms are also shown in the **Alarms** dialog, see [section 3.2](#).

**Note:** It is also possible to get reports for occupancy (see [chapter 6](#) for details) and for energy statistics (see [chapter 7](#) for details).

#### 3.1 Energy management summary

1. Double click on **EMS summary** in the **Lists** navigation window. A dialog as in the example below is shown.




Figure 17

By clicking the arrow to the left of the heading 'Runtime % - Savings and occupancy', it is possible to choose that the diagram should instead show 'Lighting and Room control (kWh)'.




Figure 18

**Note:** By clicking on any of the pie charts **Occupancy Status** or **HVAC Run Status**, the corresponding **Real time room status** dialog will be shown. By clicking on any of the bars in the **Maintenance** or **Current Alarms** bar chart, more information about the alarms will be shown.

The **Occupancy Status** diagram shows how large share of the total number of guest rooms that are:

- occupied
- unoccupied
- unsold

See section [Basic EMS logic](#) for more information about the different states above.

The **HVAC Run Status** diagram shows how large share of the HVAC systems that are:

- cooling
- heating
- off

The **Runtime %** diagram shows:

- actual energy consumption in runtime
- energy consumption if no EMS had been used
- savings in energy consumption when EMS is used; **Actual** curve minus no **EMS** curve
- occupancy

The **Maintenance** diagram shows the number of:

- preventative maintenance schedules; maintenance intervals 1-3
- battery alarms from motion sensor
- offline rooms (motion sensor/lock offline; thermostat offline)

The **Current Alarms** diagram shows the number of alarms related to:

- security; door left open
- HVAC
  - thermostat cooling on highest fan speed – temperature rising
  - thermostat heating on highest fan speed – temperature dropping
  - HVAC running longer than maximum runtime (default 120 minutes) without reaching setpoint
  - too long duration of setback override
- device; no motion detected for 24 hours in spite of door activity
- freeze; the temperature in a room goes below 39 °F = 4 °C
- excessive occupancy; if a room has had occupancy without door movement for 48 hours

**Note:** When any of the alarms for maintenance 1-3 has been taken care of, the concerned maintenance counter must be reset from *Orion Service*; see section about configuring thermostat in *Quick reference guide Orion Service*.

### 3.2 Alarm list

The bar charts **Maintenance** and **Current Alarms** which are shown in the [\*\*Energy management summary\*\*](#) dialog are also shown in the **Alarms** dialog. The dialog contains two modes:

- 'Runtime' with callback data
- 'Filtered' with historical data

When an alarm is triggered, it first appears in a popup window down to the right on the screen. See *User manual Visionline* for details about the different modes, e.g. more about alarm popups for the runtime mode and what filters that can be applied in the 'Filtered' mode.

To open the **Alarms** dialog:

1. Double click on **Alarms** under the **Lists** tab in the navigation window.

By default, the 'Runtime' mode of the **Alarms** dialog will be shown. By clicking on any of the alarm bars 'Preventative' etc in the bar chart, all non-completed alarms in the clicked alarm category will be shown in the alarm list.

**Note:** The **Alarms** dialog will also show alarms that are not related to Orion EMS; except for in the separate Orion EMS client, where only Orion EMS alarms are shown.

## 4. Real time room status

The dialog **Real time room status** shows occupancy status, HVAC status and temperature for Orion EMS rooms in real time.



**Note:** It is also possible to get reports for occupancy (see [chapter 6](#) for details) and for energy statistics (see [chapter 7](#) for details).

To open the **Real time room status** dialog:

1. Double click on **Room status** in the **Lists** navigation window (or click on any of the circle diagrams in the **EMS summary** dialog, which is found by double clicking on **EMS summary** under the **Lists** tab).
2. The size of the squares can be changed in the combobox to the right; default is 12 pixels.

By hovering with the cursor over a room in any **Real time room status** graph, the tooltip will show:

- occupancy status; unsold/unoccupied/occupied
- HVAC status; not running/cooling/heating
- room temperature
- triggered Orion EMS alarms, if any

		
Figure 19	Figure 20	Figure 21

If **Occupancy status** is chosen (default) in the drop-down menu in the upper left corner of the dialog, a screenshot as in the example to the right is shown.

If **HVAC status** is chosen in the drop-down-menu in the upper left corner of the dialog, a screenshot as in the example to the right is shown.

If **Temperature** is chosen in the drop-down menu in the upper left corner of the dialog, a screenshot as in the example to the right is shown.

## 5. Thermostats list

All digital thermostats are set up in the **Thermostats** list. When one or more new thermostat has been added, or if the properties of an existing thermostat has been modified, a \* is shown in the **Thermostats** dialog caption.

**Note:** Some thermostat parameters are considered as basic and some as advanced; it is possible to set up in the operator template if operators belonging to the template should be able to change basic or advanced parameters, or both.

**Note:** Different operator templates have got different authorities to handle thermostat parameters; see section [Operator templates](#) for more information.

**Note:** When an online thermostat is moved from one thermostat profile to another, parameters for the new profile are automatically sent to the thermostat. When one or more parameters of a thermostat profile are updated, these new parameters are automatically sent to all concerned thermostat.

**Note:** If several thermostats should be moved from one thermostat profile to another, mark the concerned thermostats in the **Thermostats** dialog and click **Properties**.

Choose the applicable thermostat profile and click **Update**.

**Note:** If the room to which a thermostat belongs is removed from the system, the thermostat is automatically also removed from the system.

To add/modify a thermostat:

1. Double click on **Thermostats** under the **Lists** tab in the navigation window.
2. Click **Add** to add a new thermostat, or **Properties** to modify an existing thermostat.
3. At **Door**, enter the number of the guest room where the thermostat is located. If the same thermostat properties should be valid for thermostats in several rooms, add all concerned room numbers (e.g. 101-103). If the concerned rooms are not in sequence, separate them with commas (e.g. 101-103, 105, 108-109).
4. At **Profile**, choose the applicable thermostat profile in the combobox. If no applicable profile is available, click the  button to create a new one.
5. Click **Save** and **Close**, or **New** if the **Door** field should be emptied and a new thermostat be added.




Figure 22

To check the status of a thermostat:

1. Double click on **Thermostats** under the **Lists** tab in the navigation window.
2. Mark the applicable thermostat and click **Status**.

Thermostats *				
Door	Door area	Profile	Room temperature	Set temperature
101	Floor 1	Default profile	n/a	n/a
102	Floor 1	Default profile	n/a	n/a
103	Floor 1	Default profile	n/a	n/a
104	Floor 1	Default profile	n/a	n/a
105	Floor 1	Default profile	n/a	n/a
106	Floor 1	Default profile	n/a	n/a
107	Floor 1	Default profile	n/a	n/a
108	Floor 1	Default profile	n/a	n/a
109	Floor 1	Default profile	n/a	n/a
110	Floor 1	Default profile	n/a	n/a

Figure 23

**Under the **Alarm status** tab:**

3. Any alarms that have been triggered for the concerned thermostat are marked with yellow.

**Note:** If the thermostat has not answered with its current alarm status, the last known status will be shown instead (if there is one).




Figure 24

**Under the **Maintenance status** tab:**

4. At **Battery status**, the battery status of thermostat (if battery operated) and motion sensor is shown.
5. At **Maintenance counters**, the time left for maintenance counter 1, 2 and 3 respectively are shown.

**Note:** The total numbers of hours before the three different maintenance alarms should be triggered are specified at **Tools/Options/Energy management/Maintenance**.




Figure 25

Under the **Current run status** tab:

6. At **Room temperature**, the current room temperature is shown.
7. At **Set temperature**, the temperature which the guest has set on the thermostat is shown.
8. At **Fan control**, it is shown whether the fan control is 'auto only' or 'manual'.
9. At **Fan speed**, the current fan speed (low, mid, high) is shown.
10. At **Occupancy**, the occupancy status is shown.
11. At **HVAC**, it is shown whether the HVAC is 'not running', 'cooling' or 'heating'.
12. At **Override mode**, it is shown whether the thermostat parameters are overridden.




Figure 26

To notify users about room status:

If the *Communication option* is used, one or more users can be notified by e-mail and/or SMS when the status of a room switches to occupied, unoccupied or unsold.

1. Double click on **Thermostats** under the **Lists** tab in the navigation window.
2. Right click on one or more rooms in the thermostats list and choose the applicable one of
  - notify when room status switches to occupied
  - notify when room status switches to unoccupied
  - notify when room status switches to unsold




Figure 27


3. In the **Users <Thermostats>** dialog that is shown, mark a user and click **Select**. Only users which have been set up with e-mail address and/or cell phone number in the **User details** dialog will be shown in the **Users <Thermostats>** dialog. If the chosen user has been set up with both e-mail address and cell phone number, you will get a question about what media that should be used; e-mail, SMS or both.
4. If more users should be notified about the same room, repeat steps 2-3 for the room.

See *Installation instruction Communication option* for more information about the option.

## 6. Occupancy report

The **Occupancy** report shows the number of rooms that are rented per day; as a number and also as a percentage of the total number of rooms.

1. Double click on **Occupancy** under the **Reports** tab in the navigation window.



The screenshot shows a window titled 'Occupancy' with a table of room occupancy data. The table has two columns: 'Date' and 'Occupancy'. The data is as follows:

Date	Occupancy
2014-06-27 18:00	48 (96%)
2014-06-26 18:00	42 (84%)

At the bottom of the window are two buttons: 'Print >>' and 'Close'.


Figure 28

## 7. Energy statistics report

The **Calculated HVAC** column shows how much the HVAC units would run if the *Orion EMS* option had not been used, i.e. if *Orion EMS* had not saved energy when the rooms are unoccupied. The **Calculated HVAC** is continuously calculated every hour as the total runtime for all HVAC units in occupied rooms divided by the total time these rooms have been occupied.

The **# rooms updated** column shows how many rooms that have reported that they run HVAC, i.e. events with runtime are sent from the room.

1. Double click on **Energy statistics** under the **Reports** tab in the navigation window.



Date	Actual HVAC	Calculated HVAC	Savings	Occupancy	# rooms updated
2014-06-27	58%	98%	40%	52%	2
2014-06-26	54%	91%	37%	52%	6
2014-06-25	49%	93%	44%	43%	6

[Print »](#) [Close](#)

Figure 29

## 8. Tools/Options

At **Tools/Options**, there is a tab for **Energy management**, in turn containing the tabs **General**, **Maintenance** and **Housekeeping**.

### 8.1 General

At **Tools/Options/Energy management/General**, the below parameters can be modified; enter the applicable value(s) and click **OK**:




Figure 30

1. *Enable energy management*: This checkbox is automatically marked when the Orion EMS option is set in the Visionline software. If the Orion EMS option should temporarily be turned off, unmark 'Enable energy management' and click **OK**.
2. *Staff entry allow room occupancy change*: If this checkbox is marked, the room will go to occupied state when motion is triggered if staff is in the room, i.e. when a staff card has opened the room.
3. *Max HVAC runtime*: An alarm is triggered if a HVAC runs this long without reaching the set temperature, i.e. the temperature which the guest has set on the thermostat. Default is 120 minutes; the valid range is 30-300 minutes.
4. *Max setback override*: The [setback override](#) cannot exceed the number of hours specified here; the valid range for 'Max setback override' is 0-99 hours. If the

default 0 hours is used, there is no limitation in time for the setback override and it can be set until further notice.

5. *Unit*: The temperature unit (Fahrenheit/Celsius).

**Note:** Changes to the temperature unit will be broadcasted to all thermostats.

## 8.2 Maintenance

At **Tools/Options/Energy management/Maintenance**, it is possible to specify three different thermostat maintenance intervals in hours; 0-65535 hours. This is the number of hours of runtime that should pass before an alarm is triggered. It is also possible to rename the three maintenance intervals.

- *Maintenance counter 1* is for fan time/total HVAC time
- *Maintenance counter 2* is for 'cooling'
- *Maintenance counter 3* is for 'cooling or heating'




Figure 31

1. Enter the applicable maintenance value(s) in hours.
2. If applicable, rename the three maintenance counters to your needs.
3. Click **OK**.

### 8.3 Housekeeping

At **Tools/Options/Energy management/Housekeeping**, it is possible to change the default values for

- number of days to keep events in the database (default 7; valid range 1-9999)
- number of days to keep runtime data in the database (default 365; valid range 1-9999)
- number of days to keep occupancy data in the database (default 365; valid range 1-9999)

**Note:** Events use a considerable amount of disk space, so the number of days to keep events should be kept low.

**Note:** In the separate Orion EMS client, the housekeeping items are found at **Tools/Options/System/Housekeeping**.




Figure 32

1. Enter the applicable values and click **OK**.

## 9. Orion EMS in SysMon

The maintenance software SysMon (*System Monitor*) is found in the Visionline installation folder and also in the installation folder for the separate Orion EMS, if the latter is applicable. It contains several dialogs, of which the ones below are applicable for Orion EMS:

- thermostats
- online commands
- broadcasts
- room events

To open SysMon:

1. Double click on **SysMon.exe** in the installation folder. **Tip:** Make a shortcut to SysMon since this will be extensively used. **Note:** The Broadcasted commands dialog is not automatically updated; press **F5** to refresh it manually.

## 9.1 Thermostats

The **Thermostats** dialog of SysMon gives a good overview of all thermostats; if there are any alarms, if any thermostats have been overridden etc.

### 1. Go to **View/Thermostats**.

Room	Last Contact	Status	Temp	Set point	Occupancy	HVAC	Alarm	Ovr setback
101	9/30/2009 8:03:00 AM	Online	72	72	Occupied	Off	No	No
102	9/30/2009 8:04:00 AM	Online	72	72	Occupied	Off	No	No
103	9/30/2009 8:02:00 AM	Online	72	72	Occupied	Off	No	No
104	9/30/2009 8:04:00 AM	Online	72	72	Occupied	Off	No	No
105	9/30/2009 8:04:00 AM	Online	71	72	Occupied	Heating	No	No
106	9/30/2009 8:04:00 AM	Online	72	72	Occupied	Off	No	No
107	9/30/2009 8:07:00 AM	Online	71	72	Occupied	Heating	No	No
108	9/30/2009 8:04:00 AM	Online	72	72	Occupied	Off	No	No
109	9/30/2009 8:01:00 AM	Online	72	72	Occupied	Off	No	No
110	9/30/2009 8:01:00 AM	Online	71	72	Occupied	Heating	No	No
111	9/30/2009 8:01:00 AM	Online	71	72	Occupied	Heating	No	No
112	9/30/2009 8:05:00 AM	Online	71	72	Occupied	Heating	No	No
113	9/30/2009 8:01:00 AM	Online	72	72	Occupied	Off	No	No
114	9/30/2009 8:44:00 AM	Online	ca	72	Unoccupied	off	No	No

Figure 33


Column	Description
Room	Room number
Last contact	Time when last telegram was sent from the thermostat
Status	Online/Offline
Temp	Room temperature
Setpoint	The temperature which the guest has set on the thermostat
Occupancy	Unsold/Unoccupied/Occupied
HVAC	Off/Cooling/Heating
Alarm	Yes/No
Ovr setback	This column shows if the thermostat in the concerned room has been overridden; Yes/No

Table 8

## 9.2 Online commands

The **Online Command Log** dialog of SysMon shows commands that have been sent to the thermostats. The online commands are listed in reverse chronological order.

1. Go to **View/Online Commands**.



The screenshot shows a Windows dialog box titled "Online Command Log". The table has four columns: "Room", "Command", "Time", and "Status". There is one entry: Room 107 (Tstat), Command Get tstat status, Time 2010-02-26 12:56:00, and Status OK.

Room	Command	Time	Status
107 (Tstat)	Get tstat status	2010-02-26 12:56:00	OK

Figure 34

### 9.3 Broadcasts

The **Broadcasted commands** dialog shows all commands that have been broadcasted to the thermostats. The broadcast commands are listed in reverse chronological order.

**Note:** The **Broadcasted commands** dialog is not automatically updated; press **F5** to refresh it manually.

#### 1. Go to **View/Broadcasts**.




Figure 35

2. To see details for a certain command, mark it in the list and click **Details**.
3. A **Broadcast Answers** dialog will be shown, with the concerned thermostats or locks (depending on command) and their answer time.


Column	Description
Registration Number	Uniquely identifies the broadcasted command. The registration number will be shown in the events the command generates.
Command	
# Answers	The number of locks that have answered the command
Last Transmission	Timestamp when the command was last broadcasted; originally or due to a retry.
Succeeded	Yes if all locks answered
Cancelled	Yes if the command was cancelled by another broadcast; e.g. a new <i>Set-Time command</i> cancels any previous <i>Set-Time command</i> .
Buffered	Yes if the command has timed out. It has then been buffered as a single-cast command for all locks that have not answered.

Table 9

## 9.4 Room events

The **Room Event list** dialog shows events related to the lock or to the in-room devices such as thermostat or motion sensor.

### 1. Go to **View/Room events**.



Room	Registration Number	Time	Event	Card Name	User Group	SeqNum
2001	0	2010-03-17 10:49:00	One or more events may have been lost (128)	Online Command	Online	7
2001	0	2010-03-17 10:49:00	One or more events may have been lost (128)	Online Command	Online	6
1001	0	2010-03-17 12:59:00	Error, Smart Card reading (1173)	Door Unit Internal	n/a	7
1001	0	2010-03-17 12:59:00	A readout has been done (83)	Online Command	Online	6
1001	0	2010-03-17 12:56:00	Error, Smart Card reading (1173)	Door Unit Internal	n/a	5
1001	100153	2010-03-17 12:56:00	Error, Card has expired (322)	Guest (MC)	Guest	4
2001	0	2010-03-17 12:58:00	A readout has been done (83)	Online Command	Online	3
1001 (Tstat)	0	2010-03-17 12:57:00	Parameters changed (2112)	n/a	n/a	33
1001 (Tstat)	0	2010-03-17 12:57:00	After setting time (2073)	n/a	n/a	32
1001 (Tstat)	0	2010-03-17 13:10:00	Before setting time (2072)	n/a	n/a	31
1001 (Tstat)	0	2010-03-17 13:10:00	HVAC turned on. Cooling (2120)	n/a	n/a	30
1001	0	2010-03-17 12:56:00	Error, Smart Card reading (1173)	Door Unit Internal	n/a	5

Figure 36

2. If large amounts of events are continuously presented, there is a possibility to "freeze" the presentation of events to be able to look closer at a certain event. In this case, click the **Hold** button.

To filter the room events:

1. Click the **Filter** button in the **Room Event List** dialog; the dialog to the right will be shown.
2. Enter the applicable filtering information and click **OK**. The result is presented in a room event list.




Figure 37

# 10. Maintenance

## 10.1 To disassemble a thermostat

**1.** Use a flathead screw driver to loosen the thermostat; bend the locking arms and in the same time pull carefully.




Figure 38

**2.** Use the flathead screw driver to bend the locking arm at the bottom of the thermostat; at the same time pull carefully.





Figure 39

## 10.2 To replace a fuse

The thermostat has two fuses which are located as in *Figure 40*.

**Note:** To replace a fuse, the thermostat must be disconnected from the wall plate.



*Figure 40*

		<b>How do I know if the fuse has blown?</b>	<b>What does the fuse protect?</b>
<b>Upper fuse</b>	<ul style="list-style-type: none"><li>• 5x20mm</li><li>• 2.0AF</li></ul>	The thermostat appears to be dead.	<ul style="list-style-type: none"><li>• Reversing valve output</li><li>• Cool output</li><li>• Heat output</li><li>• Internal power supply of the thermostat</li></ul>
<b>Lower fuse</b>	<ul style="list-style-type: none"><li>• 5x20mm</li><li>• 6.3AT</li></ul>	The fan outputs stop working.	The fan outputs
<hr/>			
<i>Table 10</i>			

## Appendix A: Quick reference of technical data

**Note:** If external motion sensor is applicable, see *Installation manual Orion High Voltage Thermostat* for technical data and information about installation.

Dimensions (WxHxD)	112 x 117 x 35 mm (4 13/32" x 4 19/32" x 1 3/8")
Mains voltage input	Universal voltage input 100VAC-277VAC; 50/60Hz; rated impulse voltage: 4kV
Switch input	Door switch - 1 exterior/1 interior
Multifunction input	Motion sensor/card switch/pipe temp sensor
High voltage outputs	<ul style="list-style-type: none"> <li>- G1 (Fan 1): Type 1.B action. Max load 3A (3FLA/18LRA)</li> <li>- G2 (Fan 2): Type 1.B action. Max load 3A (3FLA/18LRA)</li> <li>- G3 (Fan 3): Type 1.B action. Max load 3A (3FLA/18LRA)</li> <li>- RV (reversing valve): Type 1 action. Max load 0.5A</li> <li>- Y (cooling/compressor): Type 1 action. Max load 0.5A</li> <li>- W (heating): Type 1 action. Max load 0.5A</li> </ul>
Low voltage outputs	<ul style="list-style-type: none"> <li>- Proportional 0-10V; heating</li> <li>- Proportional 0-10V; cooling</li> <li>- Switch output (max 24V AC/DC, SELV, max 0.1A)</li> </ul>
Temperature sensor	Integrated in thermostat
Temperature display	Configurable: <i>room temperature</i> (default) or <i>guest setting</i>
Temperature display range	2-digit display
Adjustable setpoint temperature range	17°C - 32°C / 62F - 90F
Environment	Normal indoor environment - Pollution degree 2 Operating temperature range 0°C - 55°C / 32F -130F
Temperature sensor	Integrated in thermostat
Service device	<i>Orion Service</i> software and service cable RJ12 to 3.5mm stereo jack
Radio (RF) signals	<p>ZigBee 2006</p> <p><b>Lock to thermostat:</b> Door open - staff card Door open - guest card Door open from inside Door closed Deadbolt thrown/released</p> <p><b>Thermostat to lock:</b> Room occupied</p> <p><b>Motion sensor to thermostat:</b> Motion detected Battery status</p> <p><b>Thermostat to motion sensor:</b> Turn off when the room is occupied and door is closed Turn on when the door is opened again</p>

## Appendix A: Quick reference of technical data

Thermostat deadband	Configurable 1-3 °F; default is 2 °F
Heat/cool switching deadband	Configurable 2-4 °F; default is 3 °F
Freeze guard	39 °F / 4 °C
Refresh cycle	Optional
Humidity	Optional
Intelligent switch	Configurable: Disabled/use RV output/use G2 output; default is disabled
Room not occupied timer	Configurable 1-120 minutes; default is 8 minutes
Room not sold timer	Configurable 12-24 hours; default is 16 hours
Compressor delay (dwell-off time)	Default is that the dwell-off time is off; it is only applicable when 'heat pump' is chosen as HVAC type. In the 'heat pump' case, the thermostat will automatically force the dwell-off time to be on - it is then 5 minutes and cannot be changed. The dwell-off time prevents short-cycling of the compressor.
Required <i>Visionline</i> version	1.15.0 or higher for full functionality of thermostat profiles
Required <i>Orion Service</i> version	1.3.0 or higher

Table A1

## Appendix B: Troubleshooting

FCU = *fan coil unit*

PTAC = *Package Terminal Air Conditioner*

A/C Unit not blowing hot/cold air

### ***A/C unit not blowing hot/cold air***

1. Confirm at the thermostat that the heat or cool symbol is displayed.
  - a. *If the symbol is on*, the call has been sent from the thermostat to the FCU/PTAC.
  - b. *If the symbol is not on*, change the *set temperature* to be more than 2 degrees different from the actual temperature to engage the heat/cool call.  
**Note:** For cool, there is a 5 minute compressor delay after the unit is turned on, to prevent short-cycling.
2. Confirm that voltage is applied at the HVAC unit heat/cool inputs.
  - a. If accurate voltage is applied to the correct inputs and outputs, additional troubleshooting must be done at the FCU/PTAC.
  - b. If no voltage is applied to the correct inputs, a voltage drop has occurred between the thermostat and the FCU/PTAC. Check the wiring.

**Note:** See *Installation manual Orion High Voltage Thermostat* for information about the heat/cool relays used.

### ***Fan speed not working***

1. Confirm the configuration of the thermostat profile with fan speeds. Make sure that the wiring is in accordance with these settings. Change from *Auto* and test the individual fan speeds.
  - a. If one of the fan speeds is not working, confirm that voltage is applied at the FCU/PTAC for that fan speed. If voltage is applied to the correct fan speed, additional troubleshooting must be done at the FCU/PTAC.

## Appendix B: Troubleshooting

### ***Thermostat has no power***

1. Confirm that the thermostat has power applied to the correct wires. If the correct power is applied, make sure that the thermostat is connected correctly. If the thermostat is plugged in incorrectly, it can be damaged and needs replacement.

### ***Room is not going into Occupied state***

1. Was a staff card used to open the door (for systems with locks monitoring the door)? If so, the room will not enter *occupied state* on motion. Press a key on the thermostat and check the occupied status again.
2. Check the online status of the lock and the motion sensor.
  - a. If the door lock or the motion sensor is offline, use an *Orphan Join card* for the lock and recycle the power for the motion sensor.
  - b. If the door is still offline, follow the necessary steps to discover the lock back to the thermostat.
  - c. If the motion sensor is still offline, replace the batteries.
  - d. If the motion sensor is still offline after this, follow the necessary steps to discover the motion sensor back to the thermostat.
3. If the RF door switch is applicable, confirm that *door open* and *door closed* events are logged at the thermostat. Also use the **Diagnostics** feature in *Orion Service* to confirm that the door position is shown correctly; *Open* and *Closed*.
4. Make sure that the configuration settings at the thermostat are accurate, including correct relay configuration for *internal door switch* and *external door switch*. If neither is used, make sure that *Normally Closed* is selected.

## Appendix B: Troubleshooting

### ***A/C unit cooling when calling for heat (and vice versa)***

1. *If the unit is a heat pump*, make sure that the thermostat is properly configured to control the heat pump. See *Daily use manual Orion High Voltage Thermostat* for proper configuration of a heat pump.
2. *If the unit is not a heat pump*, or if the thermostat is correctly configured, check the outputs of the thermostat to ensure that it is calling for heat or cool properly.
  - a. First check the outputs at the thermostat.
    - i. If OK, check the outputs of the thermostat at the connection to the HVAC unit. It is possible that the wiring is crossed or somehow incorrect.
    - ii. If all is OK, the property needs to have their HVAC technician check the unit.
  - b. If the thermostat outputs are incorrect:
    - i. First check the configuration of the thermostat by using *Orion Service* to read out the parameters of the thermostat; do not just rely on looking at the parameters in the Visionline or Orion EMS software. If the parameters are incorrect, make the necessary changes.
    - ii. Connect a new thermostat to see if the problem disappears. If it does, replace the thermostat. If the problem stays, there is a problem with the wiring or parameters that must be fixed.

### ***Fan continues to run even when the thermostat is turned off***

1. First, wait a couple of minutes to see if the fan does eventually turn off. Some air handlers have a built-in function that keeps the fan running for a time after the heating or cooling function is turned off.
2. Secondly, use *Orion Service* to check the parameters of the thermostat – ensure that the 'Fan on when satisfied' function is set to 'no'.
3. Finally, test the outputs of the thermostat to see which ones that are on. If a fan output is active and the thermostat is not calling for fan (use the **Diagnostics** feature of *Orion Service* to confirm that the thermostat is not calling for fan), change the thermostat as it has a stuck relay. If no fan output is active, check all other outputs to find out if any are active. It is possibly a crossed or shorted wire.

## Appendix C: Read more

<b>Document name:</b>	<b>Document number:</b>
Installation instruction Communication option	66 5013 026
Installation manual Orion High Voltage Thermostat	66 8003 016

## Revision history

<b>Date</b>	<b>Change</b>	<b>By</b>
November 7, 2014	First release	KG
January 11, 2016	Updated layout	KG
October 12, 2016	Modified maximum value for 'room not occupied timer' to 120 minutes	KG

**ASSA ABLOY Hospitality APAC**

E-mail: [apac.hospitality@assaabloy.com](mailto:apac.hospitality@assaabloy.com)

Phone: +65 6305 7670

**ASSA ABLOY Hospitality EMEA**

E-mail: [emea.hospitality@assaabloy.com](mailto:emea.hospitality@assaabloy.com)

Phone: +47 69 24 50 00

**ASSA ABLOY Hospitality North America**

E-mail: [northam.hospitality@assaabloy.com](mailto:northam.hospitality@assaabloy.com)

Phone: +1 972 907 2273

**ASSA ABLOY Hospitality Latin America**

E-mail: [lam.hospitality@assaabloy.com](mailto:lam.hospitality@assaabloy.com)

Phone: +52 55 36 40 12 00

**[www.assaabloyhospitality.com](http://www.assaabloyhospitality.com)**