


Hytera Communications Corporation Limited


Hytera Tower, Hi-Tech Industrial Park North, 9108# Beihuan Road, Nanshan District, Shenzhen, People's Republic of China


1. Product Overview



2. Before Use

2.1 Installing the SIM Card and SD Card

1. Slide the battery latch to  and remove the battery cover.
2. Remove the battery.
3. Open the card slot cover.
4. Put the card into corresponding slot.




2.2 Attaching the Battery

Caution

- Use the approved battery to avoid the risk of explosion.
- Dispose of the used battery according to “Precautions for Disposal” in the Safety Information Booklet.

Attach the battery as shown below, then press the cover into place and slide the battery latch to the lock position.



2.3 Charging the Battery

Caution

- Use the approved charger to charge the battery.
 - Read the *Safety Information Booklet* before charging.
 - The remaining lithium-ion battery power is limited to 30% pursuant to the new lithium battery shipment regulation approved by International Air Transport Association (IATA).
-


To charge the battery, connect the terminal to the power adapter, power bank, or computer with the USB cable.

To determine the charging status, check the battery icon or percentage shown on the LCD display.

To ensure optimum waterproof and dustproof performance, close the USB port cover after charging the terminal.

2.4 Attaching the Belt Clip


Attach the belt clip as shown below.



2.5 Attaching the Audio Accessory


Open the cover of the audio accessory connector and insert the audio accessory into the connector.


To ensure optimum waterproof and dustproof performance, close the cover after removing the audio accessory.



3. Operation

3.1 Powering the Terminal On or Off

To power on the terminal, press and hold the  key.

To power off the terminal, press and hold the  key, and select **Power Off**.

3.2 Adjusting the Volume

To increase the volume, press + key.


To decrease the volume, press – key.

3.3 Turning the Screen On or Off


To turn off the screen when it is on, press the **SK** key.

To turn on the screen when it is off, press the **SK** key, **Emergency Alarm** key or any key on the keypad.

3.4 Using Flashlight

To turn the flashlight on or off when the screen is on, press and hold the  key.

3.5 Setting the Shortcut Key


SK key is the programmable key of the terminal. For enhanced convenience, you can go to  to select **Programmable key** to set the key as the shortcut of certain functions.

3.6 Connecting to the Internet

You can connect to the Internet by using the cellular network or WLAN network.


To connect to the cellular network, install the SIM card and activate the cellular data service.

To connect to the WLAN network, do as follows:

1. Go to  to select WLAN to enable the WLAN network.
2. Choose one of the listed networks.

If a password is required, enter the password and select **Connect**.

3.7 Checking the Device Information

To check information such as device status, model and version, go to  to select “About phone”.

4. PoC Service

Push-to-talk over Cellular (PoC) provides direct one-to-one and one-to-many voice communication services over the cellular network.



Note

This service is available only when you have installed the PoC application on the terminal.


You can access PoC menu to initiate a call.

1. Go to Home > PoC, and then press OK/Menu key.
2. Select the required contact.
3. Press and hold the PTT key and speak.

You can listen to a call without any operation.



To avoid possible hearing damage,
do not listen at high audio volume
for long periods of time



AT	BE	CY	CZ	DK
EE	FI	FR	DE	EL
HU	IE	IT	LV	LT
LU	MT	NL	PL	PT
SK	SI	ES	SE	UK
BG	RO	HR		

In all EU member states, operation of 5150-5250MHz
is restricted to indoor use only

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output. Before a new model device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each device are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 0 cm from the body.

For face - up, 25 mm was used for test, this equipment should be installed and operated with minimum distance 25mm.
Non - compliance with the above restrictions may result in violation of RF exposure guidelines.

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR de l'innovation, la science et le développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tous les changements ou modifications non expressément approuvés par le responsable de la conformité pourraient invalider l'autorisation de l'utilisateur à exploiter l'équipement.

SAR tests are conducted using standard operating positions accepted by the ISED with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the ISED. Tests for each device are performed in positions and locations (e.g. at the face and worn on the body) as required by the ISED.

For body worn operation, this model device has been tested and meets the ISED RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 0 cm from the body.

For face-up, 25 mm was used for test, this equipment should be installed and operated with minimum distance 25mm.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

Les tests SAR sont effectués en utilisant des positions de fonctionnement standard acceptées par l'ISED avec l'appareil transmettant à son niveau de puissance certifié le plus élevé dans toutes les bandes de fréquences testées, bien que le SAR soit déterminé au niveau de puissance certifié le plus élevé, le niveau SAR réel du téléphone pendant son fonctionnement peut être bien en dessous de la valeur maximale, en général, plus vous êtes proche d'une antenne de station de base sans fil, plus la puissance de sortie est faible.

Avant qu'un nouveau modèle de téléphone ne soit disponible à la vente au public, il doit être testé et certifié par la FCC qu'il ne dépasse pas la limite d'exposition établie par l'ISED. Les tests pour chaque téléphone sont effectués dans des positions et des emplacements (par exemple au visage et porté sur le corps) tel que requis par l'ISED.

Pour un fonctionnement porté sur le corps, ce modèle de téléphone a été testé et répond aux directives d'exposition ISED RF lorsqu'il est utilisé avec un accessoire de signal pour ce produit ou lorsqu'il est utilisé avec un accessoire qui ne contient pas de métal et qui positionne le combiné à au moins 0 cm du corps.

Pour la face visible, 25 mm ont été utilisés pour le test, cet équipement doit être installé et utilisé avec une distance minimale de 25 mm. Le non-respect des restrictions ci-dessus peut entraîner une violation des directives d'exposition aux RF.