



DECT 6.0 Multi-Handset Cordless Phone Answering System User's Guide



Please read this manual before operating product for the first time.

Visit the RCA web site at www.rca4phones.com

Model 2162/2162-2/2162-3/2162-4

Equipment Approval Information

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1. Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, a product identifier in the format US:AAAEQ##TXXXX and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5.

To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notes

• This equipment may not be used on coin service provided by the telephone company.

• Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

• Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

• If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

**US Number is located on the cabinet bottom.
REN Number is located on the cabinet bottom.**

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary disconnection of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary disconnection, the telephone company must: (1) promptly notify you of such temporary disconnection; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations. The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

• Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.

• Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

• Do not use the telephone to report a gas leak in the vicinity of the leak.

• Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS



Interference Information

This device complies with Part 15 of the FCC Rules and the Industry

Canada licence-exempt RSS standards. Operation is subject to

the following two conditions: (1) This device may not cause harmful

interference; and (2) This device must accept any interference received,

including interference that may cause undesired operation.

Visit the RCA web site at www.rca4phones.com

Please do not send any products to the Indianapolis address listed in this manual or on the carton. This will only add delays in service for your product.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Privacy of Communications may not be ensured when using this product. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).

• Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.

• Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Hearing Aid Compatibility (HAC)

This telephone system meets FCC standards for Hearing Aid Compatibility.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The base unit should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Information for DECT Product

This telephone is compliant with the DECT 6.0 standard which operates in the 1.92GHz to 1.93GHz frequency range. Installation of this equipment is subject to notification and coordination with UATM. Any relocation of this equipment must be coordinated through and approved by UATM. UATM may be contacted at 1-800-429-8826.



The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5.

To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notes

• This equipment may not be used on coin service provided by the telephone company.

• Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

• Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

• If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

• Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.

• Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

• Do not use the telephone to report a gas leak in the vicinity of the leak.

• Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

Notes

• This equipment may not be used on coin service provided by the telephone company.

• Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

• Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

• If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

**US Number is located on the cabinet bottom.
REN Number is located on the cabinet bottom.**

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary disconnection of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary disconnection, the telephone company must: (1) promptly notify you of such temporary disconnection; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations. The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

• Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.

• Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

• Do not use the telephone to report a gas leak in the vicinity of the leak.

• Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

Notes

• This equipment may not be used on coin service provided by the telephone company.

• Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

• Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

• If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

**US Number is located on the cabinet bottom.
REN Number is located on the cabinet bottom.**

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary disconnection of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary disconnection, the telephone company must: (1) promptly notify you of such temporary disconnection; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations. The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

• Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.

• Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

• Do not use the telephone to report a gas leak in the vicinity of the leak.

• Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

Notes

• This equipment may not be used on coin service provided by the telephone company.

• Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

• Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

• If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

**US Number is located on the cabinet bottom.
REN Number is located on the cabinet bottom.**

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary disconnection of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary disconnection, the telephone company must: (1) promptly notify you of such temporary disconnection; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations. The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

• Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.

• Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

• Do not use the telephone to report a gas leak in the vicinity of the leak.

• Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

Notes

• This equipment may not be used on coin service provided by the telephone company.

• Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

• Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

• If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

**US Number is located on the cabinet bottom.
REN Number is located on the cabinet bottom.**

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary disconnection of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary disconnection, the telephone company must: (1) promptly notify you of such temporary disconnection; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations. The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to

incoming ringing, but if the master PIN has been changed, it will answer after 14 rings to allow remote access.

Set the Answer Mode

1. Press the **Menu** button to enter menu selection.
2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.
3. Press the **▲** or **▼** buttons to select **ANSWER MODE** and then press the **OK** button to select.
4. Press the **▲** or **▼** buttons to select **ANSWER ONLY** or **ANSW.&RECORD** and then press the **OK** button to confirm.

Record a Personalized Outgoing Message

1. Press the **Menu** button to enter menu selection.
2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.
3. Press the **▲** or **▼** buttons to select **RECORD OGM** and then press the **OK** button to select.
4. Press the **▲** or **▼** buttons to select **ANSWER ONLY** or **ANSW.&RECORD** and then press the **OK** button to confirm.
5. Press the **▲** or **▼** buttons to select **RECORD OGM**.
6. Press the **OK** button to start recording your new outgoing message.
7. Press the **OK** button again to end the recording.

Playback and delete messages

The last recorded message is played first. Old messages cannot be played again until after all new messages have been played.

You can choose to replace the predefined OGM with your own prerecorded personalised messages.

- The maximum length of an outgoing message is 2 minutes.. To hear your outgoing message, select **PLAY** at step 5.
- To delete a personalised outgoing message and return to the predefined one, select **DELETE** at step 5.

Playback recorded messages

1. Press the **Menu** button to enter menu selection.
2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **PLAY** and then press the **OK** button to confirm.

Using the intercom, call transfer and conference are only possible with at least 2 handsets registered to the same base unit. It allows you to make free internal calls, transfer external calls from one handset to another, and set up a 3-way conference with two handsets and an external call.

If you try to make a call while another handset is already on an external call, you'll hear a busy tone for a few seconds before the display returns to idle.

Intercom another Handset (for Duo/Tri version only)

1. Press the **Int** button in idle mode.
2. Intercom is established immediately if there are only 2 registered handsets.

3. If there are more than 2 registered handsets, the handset numbers which are available for intercom, and a **“*”** will be displayed. Press the specific handset number you wish to call, or press the button to ring all handsets, to start intercom.

Transfer an External Call to another Handset

1. During the call, press the **Int** button to put the external call on hold, the caller can no longer hear you.
2. Intercom is established immediately if there are only 2 registered handsets.

3. If there are more than 2 registered handsets, the handset numbers which are available for intercom, and a **“*”** will be displayed. Press the specific handset number you wish to call, or press the button to ring all handsets, to start intercom.

4. Press the **Int** button on the called handset to answer the internal call, where both internal callers can talk. Intercom is established.

5. Press the **Int** button on the first handset to transfer the external call to the called handset. The external call is transferred.

If there is no answer from the called handset, press the **Int** button to resume the external call.

Answer on External Call during Intercom

1. During intercom, a new call tone is emitted when there is an incoming external call. Press the **Int** to answer the external call and end the intercom.
2. Connection with the external call is established.

Switch between an internal and external call

During the call, press the **Int** button to switch between an internal or external call.

Establish a Three-party Conference Call

1. The conference call feature allows one external call to be shared with two handsets (in intercom). The three parties can share the conversation and no additional network subscription is required.

2. During an external call, press the **Int** button to put the external call on hold (the caller can no longer hear you).

3. If there are more than 2 registered handsets, the handset numbers which are available for intercom will be displayed. Press the specific handset number you wish to call to start intercom. Press the **Int** on the called handset to answer the internal call, where both internal callers can talk. Intercom is established.

4. Press **OK** button for 2 seconds on the first handset to start the three-party conference.

5. **CONFERENCE** will be displayed on the screen once the conference call is established.

To put the internal call on hold and answer the incoming external call, press the **Int** button.

Phone Settings (Handset Tone)

Set the Ring Volume

There are 5 ringer volume options (**LEVEL 1**, **LEVEL 2**, **LEVEL 3**, **LEVEL 4** and **LEVEL 5**). The default level is **LEVEL 3**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **PERSONAL SET** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **HANDSET TONE** and then press the **OK** button to select and show **RING VOLUME**. Press the **OK** button again to select.

4. Press the **▲** or **▼** buttons to your desired volume level and then press the **OK** button to confirm. The unit will make an audible tone to confirm.

Set the Ring Melody

There are 10 ring melodies available on your handset.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **PERSONAL SET** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **HANDSET TONE** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **RING TONES** and then press the **OK** button to select.

5. Press the **▲** or **▼** buttons to your desired melody and then press the **OK** button to confirm. The unit will make an audible tone to confirm.

Activate/Deactivate Key Tone

A single tone is emitted when a key is pressed. You can enable or disable the key tone. By default, the key tone is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **ANSWER MODE** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ANSWER ONLY** or **ANSW.&RECORD** and then press the **OK** button to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **PERSONAL SET** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **HANDSET TONE** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **KEY BEEP** and then press the **OK** button to select.

5. Press the **▲** or **▼** buttons to select **ON** or **OFF** and then press the **OK** button to confirm. The unit will make an audible tone to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **ANSWER MODE** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ANSWER ONLY** or **ANSW.&RECORD** and then press the **OK** button to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **PERSONAL SET** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **AUTO HANG-UP** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ON** or **OFF** and then press the **OK** button to confirm. The unit will make an audible tone to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **ANSWER MODE** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ANSWER ONLY** or **ANSW.&RECORD** and then press the **OK** button to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **PERSONAL SET** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **AUTO HANG-UP** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ON** or **OFF** and then press the **OK** button to confirm. The unit will make an audible tone to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **ANSWER MODE** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ANSWER ONLY** or **ANSW.&RECORD** and then press the **OK** button to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **PERSONAL SET** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **AUTO HANG-UP** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ON** or **OFF** and then press the **OK** button to confirm. The unit will make an audible tone to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **ANSWER MODE** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ANSWER ONLY** or **ANSW.&RECORD** and then press the **OK** button to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **PERSONAL SET** and then press the **OK** button to select.

3. Press the **▲** or **▼** buttons to select **AUTO HANG-UP** and then press the **OK** button to select.

4. Press the **▲** or **▼** buttons to select **ON** or **OFF** and then press the **OK** button to confirm. The unit will make an audible tone to confirm.

This function enables you to end a call automatically by simply placing the handset on the base unit. By default, the Auto Hang up feature is **ON**.

1. Press the **Menu** button to enter menu selection.

2. Press the **▲** or **▼** buttons to select **ANSW MACHINE** and then press the **OK** button to select.