WX-Bell1-Core



- BellRFID base module with 1 admin and 5 user RFID cards
- Interchangeable bell button sets (not included)
- Integrated RFID technology for keyless entry • Available colors: white, silver, dark gray, black, amber
- Usable with/without function button for mailbox control
- Up to 60 hrs backup power supply using DoorMaster (accessory)

Bell Button Module with RFID Technology for up to Five Parties



Module for MOBOTIX IP Video Door Station, keyless entry and mailbox control, can be combined with the different bell button sets MX-Bell1-Button-F1/F2/F3/F4/05/XL1

Free-of-charge printing service on www.mobotix.com > Support

(for all color variants)

Available Bell Button Sets








MX-Bell1-Button-F2 2 medium-size bell buttons with function button



MX-Bell1-Button-F3 1 large, 2 small bell buttons with function button



MX-Bell1-Button-F4 4 small bell buttons with function button



MX-Bell1-Button-05 5 small bell buttons (no function button)



31.578_EN_V1_07/2013


MX-Bell1-Button-XL1 XL bell button (no function button)

You can use the blue function button at the door station to listen to new mailbox messages, record new announcements and activate/deactivate the mailbox. Visitors can leave a message even without the function button. The remaining mailbox features are easily controlled using the remote station of the door station (i.e., MOBOTIX App).

Each button set contains 6 RFID cards (1 admin, 5 user cards) and pre-cut name plates made of UV-resistant paper. If required, you can replace the button sets later on – in the same base module! In order to configure the system using BellRFID, the bell buttons are replaced by a keypad insert, which is delivered with the base module.

Use our free-of-charge printing service on www.mobotix.com, Support section!

Standard Connection: IP Video Door Station with BellRFID, InfoModule and DoorMaster



For additional information on the other connection variants and for installing, see the T24 System Manual Part 1 on www.mobotix.com > Support > Manuals





same manner as the KeypadRFID module. Make sure that you follow the steps for the different hardware scenarios of the IP Video Door Station (with/without DoorMaster) as described in the T24 System Manual Part 1 for the KeypadRFID (see below).

The BellRFID module is installed in the exactly

Note: BellRFID and KeypadRFID can only be used on one MxBus with a later software version of the camera.

Before starting the installation and initial operation, you should download part 1 and 2 of the T24 System Manual from the MOBOTIX website (www.mobotix.com > Support > Manuals). If the installation of the IP Video Door Station with BellRFID is not followed by the initial operation right away, MOBOTIX recommends to remove the keypad

Installation and Initial Operation of the BellRFID

insert and to insert the button set before starting the installation. This way, the soft rubber surface of the BellRFID base module is well protected until the module is brought into service (bell buttons are then replaced by the keypad insert). Note that the base module is weatherproof even without the bell When replacing the button set or exchanging name plates, you need to remove the module from the frame of the IP Video Door Station. Use the

blue MOBOTIX key for unlocking the module. Make sure that you are activating the mechanical theft protection with the red turning knob in the door station frame only after you have finished the initial operation (see the Section «Mechanical Anti-Theft Protection Lock» in the

In order to avoid having to remove the module and install it again, you should insert the proper name plates before starting the initial operation. Use our free-of-charge printing service on www.mobotix.com in the Support section! Or use the supplied name plates made from sturdy specialty paper and write the names using a UV-resistant marker.

1. Insert the Name Plate(s) Remove the silicon insert from the button. Recommendation: Take a suitable


T24 System Manual Part 1).


tool without a sharp blade, cautiously insert it into the slot, gently press inward and lift the tool as shown.



are pointing upwards later on).

Insert the labeled or printed name plate as shown (the arrows at the side







You can use the BellRFID module as an alternative to the KeypadRFID (but not yet side-by-side) in the frame of an IP Video Door Station. For installing and wiring the module, follow the same steps as for the KeypadRFID.

Follow the description in the Section «Installing the T24-KeypadRFID» of the

T24 System Manual Part 1. Likewise, the other connection variants listed in the Section «Overview: Connection and Wiring Diagrams» (e.g., connecting an electrical door opener in a system without DoorMaster). Finish the installation of the BellRFID module by following the steps listed

in the Section «Finishing the Installation» of the T24 System Manual Part 1. Similar to the KeypadRFID, the blue and the green status LEDs are flashing (power supply OK, ready for auto configuration).

When installing the module, insert it first on the right-hand

side. Then use two fingers and press on the left-hand edge until the module clicks into the frame. Caution: Only press at the edge, never at the center of the module! Make sure that the cabling is not pinched and damaged

when installing the module.

3. Execute Auto Configuration

(push it into the frame at the top, then push the bottom into the module).

Place the supplied keypad insert into the base module





the T24 System Manual Part 2 (connect all devices, establish the power supply and press the bell button of the camera module immediately after the light and bell buttons are lighting up).



• The blue and the green status LEDs are flashing. • The LED of the keypad behind the top right key (OK) is red.

camera illumination is on and the BellRFID shows the following status:



Finish the auto configuration by executing the steps listed in the Section

«Functional Test Part 1» of the T24 System Manual Part 2.

4. Enter Super PIN and Confirm

The **Super PIN** is used to protect the system against misuse and also replaces the factory default password ("meinsm") as the new admin password. The password is also used when adding the door station to the MOBOTIX App or MxEasy, for example (user name is admin, new password is the <Super PIN>). Select a Super PIN that has a minimum of 8 and a maximum of 16 digits (more and different digits make it more secure). For additional information on the Super PIN, see the T24 System Manual Part 2.

Copyright © MOBOTIX AG



Installation and Initial Operation of the BellRFID (contd.)

Enter your personal Super PIN on the keypad insert, then press the $\bf OK$ key. This key is now highlighted yellow.

Enter the Super PIN again, then confirm by pressing the **OK** key. If the two PINs are identical, the LEDs in the center are flashing repeatedly in a sequence from top to bottom. Next, the top right key (**OK**) lights up green and the key at the center (**Letter**) lights up red.



Remove the keypad insert and continue with the next step.

Mad

If you entered different Super PINs or more than 60 seconds passed between entering the PIN and confirming, the module emits a warning sound and returns to the state after finishing the auto configuration. In such a case, you need to start again with step 4.

5. Set the Bell Button Set to be Installed

Depending to the bell button set, you need to select one of the six possible button layouts. To select a button layout, press any one of the button contacts in the center. The module shows the current button layout by flashing the LEDs in a specific manner (see table below). The configuration starts with pattern \mathbf{a} ; pressing any button switches to the next pattern in ascending order. After the last pattern, the module returns to pattern \mathbf{a} .



	a 🛦	MX-Bell1-Button-F1	LED 1 permanently blue, 2 to 5 flashing white
	b	MX-Bell1-Button-F2	LED 1 permanently blue, 2+3, 4+5 sequence white
	С	MX-Bell1-Button-F3	LED 1 permanently blue, 2, 3, 4+5 sequence white
Г	d	MX-Bell1-Button-F4	LED 1 permanently blue, 2, 3, 4, 5 sequence white
Г	е	MX-Bell1-Button-05	LEDs 1, 2, 3, 4, 5 sequence white
,	f f	MX-Bell1-Button-XL1	LEDs 1 to 5 flashing white simultaneously
Once you have found the proper pattern, keep any one of the buttons at			

the center pressed until the LEDs are flashing repeatedly in a sequence.

Next, the top center and right buttons (**OK** and **Letter**) light up green and the button at the top left (**ESC**) lights up red.

• • • • • • • • •



been inserted and the admin card has been trained.

6. Insert the Function/Bell Buttons
In order to insert the function or bell buttons, you need to remove the BellRFID module from the frame of the door station (if you have not already done so). Use the blue MOBOTIX key for unlocking

Insert the function and bell buttons in the proper order by inserting the elements from the bottom (e.g., the blue function button first). In order to avoid damaging the buttons, press the elements into the module using two thumbs as shown.



Click the BellRFID module with the buttons into the IP Video Door Station as described in step 2.

7. Train the Admin CardNow that you have entered the Super PIN and inserted the buttons, you

need to train the Admin card. This card is used as the "master key" for authentication purposes and is required for training and deleting user cards, for example. For every-day use, however (opening doors, mailbox features), you only need the blue user cards. Note that you should always keep the admin card together with the **Product Pass** of the IP Video Door Station in a safe place.

Hold the admin card in front of the BelIRFID module for 5 seconds until

the sound stops. The LEDs light up in a sequence to confirm that the card has been trained.

All three LEDs at the top are now green to show that the initial operation

has been completed successfully. The button contacts are now unlocked.



Manual Part 2.

8. Add User Cards (Any Time Later on)This step is not part of the initial operation of the system and can be

performed at any time later on. You can skip this step if you do not intend to use the features described here.

The blue user cards are used by the inhabitants to open the door without using

a key and to listen to mailbox messages directly at the IP Video Door Station. If the blue function button at the top has not been installed, make sure that you pay attention to the corresponding key position for the LED patterns described in the following.

Hold the trained admin card in front of the BellRFID module. The **OK/MENU**

key at the top right position lights up red.

If you want to use the keyless entry features and listen to mailbox messages

at the door, press the bell button of the party to which you want to assign the user card. The selected button lights up white. If you want to use this card only for opening the door (i.e., for the nursing service) make sure that you do **not** press any button now.

Hold the user card in front of the BellRFID module for 5 seconds until the

module plays a sound. The LEDs light up in a sequence to confirm that the card has been trained.

If you want to train additional cards, repeat the steps listed in this section

Test the trained cards by holding them in front of the BellRFID module one by one. The electrical door opener should open the door with each card.

In Case of Loss/Theft: Delete All Cards! In case a user card is lost, you need to delete this card in order to prevent unauthorized access to the door. The easiest method is to delete all cards

for each card.

(user **and** admin) and to train the remaining cards again later on.

In order to delete all cards, hold the red admin card in front of the BellRFID module until the **OK/MENU** key lights up red. Then briefly remove the admin

card and hold it in front of the module again (the **ESC/ALARM** key flashes red).

Now press and hold any bell button until the three LEDs at the top start flashing red. Confirm the deletion by again pressing and holding the same bell button. The LEDs light up in a sequence to confirm that all cards have been deleted. The right status LED of the module briefly lights up green.

If you want to train the cards again, execute the instructions of **steps 7 and 8**. **Note:** It is also possible to delete only specific user cards or a lost admin card. For additional information on how to do this, see the *T24 System Manual*

Operation: Buttons and Signaling | Recording New Mailbox Messages*

Ring the Bell for One PartyBriefly press the bell button of the desired party. The LED of the button briefly lights up.

the module.

Leave a Message (BellRFID with Function Button)

After pressing a bell button and announcement: Keep the blue letter

Without having pressed a bell button: Briefly press the blue letter key
and then the bell button of the party for which you want to leave the
message. As soon as the mailbox announcement stops, you can start
talking. Keep the blue letter key pressed the entire time.

After pressing a bell button and announcement: Keep the same bell button pressed while leaving the message.

Leave a Message (BellRFID without Function Button)

key pressed while leaving the message.

- Without having pressed a bell button: Not possible.
- Open door with blue user card
 Hold the blue user card in front of the BellRFID module. If the module

Hold the blue user card in front of the BellRFID module. If the module denies access (e.g., card has been deleted, is not trained), the red status

 $oldsymbol{
abla}$

connection variants.

Only for cards with activated mailbox feature – see T24 System Manual Part 2, «Adding User Cards»

LED (above the ESC/ALARM key) lights up.

Upon Power Failure (Red LED Is Flashing)

Press and hold the ESC/ALARM key until the button illumination lights up.

You can now open the door with your user card during the next 10 seconds.

This feature is only available if the IP Video Door Station is equipped with a DoorMaster.

Play Back New Message*
If you are opening the door with a user card and the blue letter key is flashing
(5 seconds), there is at least one unflagged message in the corresponding

Press the flashing key to play back the message. Press again

mailbox. You can now use one of the following functions:

to repeat the message

ESC ALARM	riag ine message, i.e., the message cannot be played back at the door, but only at a remote station (e.g., MOBOTIX App, MxEasy).
WENU	Play back next message.
	oses automatically 15 seconds after the last user action/ ou press the ESC/ALARM button.

Notes

 Please follow the notes on installing and operating the device in the T24 System Manual (www.mobotix.com in the Support > Manuals section). This document contains the wiring diagrams for the different

ains the

- The BellRFID module is only to be used in the original frame of the MOBOTIX IP Video Door Station.
 Before installing, make sure that the seal on the back of the BellRFID module has been properly attached.
 When inserting the module into the frame, only press at the edge, never
- at the center of the module.

 Make sure the device is not operated outside of its operating temperature
- range of -30 to +60°C/-22 to +140°F.
 BellRFID and KeypadRFID can only be used on one MxBus with a later software version of the camera.
- LED Patterns

 MOBOTIX BelirFID

Order no.: MX-Bell1-Core

Right LED (blue)

– Bell buttons

You can either use one of the system's predefined announcements or record custom announcements. These announcements will be played back

if the mailbox is activated and the ringing has not been answered. A new custom announcement always replaces the last announcement that had been used. You can set the current announcement using a remote station (e.g., MOBOTIX App, MxEasy).

Press your bell button and hold the blue user card in front of the module (bell sound is played back, green LED (mailbox activated) or red LED (mailbox

deactivated) lights up). Press the bell button again and keep it pressed as long as you record the announcement. The red status LED is flashing while recording.

Additional BellRFID Features (see T24 System Manual)

Activating/Deactivating the Mailbox*

Checking the Mailbox without Opening the Door* Keep the blue letter key pressed until it starts flashing, then hold the blue

user card in front of the module. The first new message is played back.

Press the blue letter key to play back the messages again. To delete the messages, keep the ESC/ALARM pressed until you hear a sound. If there are no new messages (any more), the system will make a corresponding announcement.

Deleting User/Admin Cards and Transponders

Card held in front of the module

All cards assigned to one bell buttonLost admin card

 Specific user card or transponder (e.g., KeyRFID) using the assigned transponder number

Changing the Super PIN

Interface

Changing the Bell Button Set

2 galvanically separated inputs (AC/DC, selfpowered, up to 50 V) 1 isolated relay output (AC/DC, up to Outputs 50 V/60 W/2 A) Protection class IP65 (DIN EN 60529) Operating temperature -30 to +60°C/-22 to +140°F (DIN EN 50125) **Power Supply** Typical 1 W Power consumption RFID cards: Type/Encryption MIFARE DESFire EV1 3K3DES/AES **Dimensions** 99 mm/3.9 in

Technical Specifications

MxBus

99 mm/3.9 in





Cindy Jones Thomas Jones

The Jones Family

Dr. Jones, MD

HiRes Video Innovations – Made in Germany

Left LED (green/ red, Status LED)

Normal status

Device error

Status LED

• Flashing Power failure

On

On

The German company MOBOTIX AG is known as the leading pioneer in network camera technology and its decentralized concept has made high-resolution video systems cost-efficient.