

cnPilot E501S 90/120° Sector

802.11ac Outdoor WLAN Access Point with Integrated 90°/120° Antenna & IP67 Industrial Grade Gigabit WiFi

Quick Start Guide

Introduction

This guide provides quick installation steps for cnPilot E501S Access Points (APs).

Package Contents

Tools Required

- Phillips screwdriver (Wall Mounting)
- Flat head screwdriver (Pole Mounting)
- 12 mm wrench

STEP 1 (Pole Mount)


Assemble the radio holder to the pole mounting bracket and secure it with M8 nuts by applying 3.0 Nm torque.


STEP 2 (Pole Mount)


Insert hose clamps through pole mounting bracket and clamp to pole by applying 3.0 Nm torque.

STEP 3 (Pole Mount)


Align the radio chassis with the guide rails of radio holder and slide it downwards until it clicks into place.

STEP 4
Cable gland components

Cable gland assembly sequence

STEP 5 (Pole Mount)


Insert RJ45 to radio housing and the lock cable gland to radio housing with 1.5Nm to 2Nm torque.

STEP 6 (Radio alignment)

 Align Radio to required angle by tilting up and down. The maximum radio tilting angle is $\pm 40^\circ$, with an incremental of 10° .

Wall Mounting

 Drill 4 holes of $\varnothing 6\text{mm}$ ($\varnothing 0.25\text{"Inch}$) on wall. Press fit plastic anchor and assembly fastener. Leave 5mm to 6mm gap between wall and fastener head.

Use the four mounting slots given on the back of the radio to mount to the wall.


JOIN THE CONVERSATION
community.cambiumnetworks.com

Powering Up

1. Connect the Ethernet cable from ETH/PoE-IN of E501S to the PoE port of Gigabit Data + Power



2. Connect an Ethernet cable from your LAN or Computer to the Gigabit Data port of the PoE adapter.



3. Connect the Power Cord to the adapter, and then plug the Power Cord into a power outlet.



Once powered ON – Power LED should illuminate continuously on PoE Adapter.

**Shielded Category 5 (or above) cabling should be used for all outdoor wired Ethernet connections and should be grounded through the AC ground of the PoE.

Configure Management PC

1. Select Properties for the Ethernet port. In Windows it is found in Control Panel > Network and Internet > Network Connections > Local Area Connection.



2. IP Address Configuration
Default IP address received via DHCP.
In Pilot E501S will use a default static IP address of 192.168.0.1, if there is no DHCP server.



3. Default Login information
- Username: admin
- Password: admin
Management Protocols enabled by default -http or https (webpage management interface access), SSH (CLI management interface access).

Quick Link Setup

1. Using a web browser, navigate to 169.254.1 and login with username: admin and password: admin

2. Navigate to the Quick Start menu and click the 'Go To Next Page'.

3. Configure your Region and Country of operation. Click the 'Go To Next Page'.


4. Configure the Carrier Frequency. Click the 'Go To Next Page'.

5. Select the Synchronization source. Click the 'Go To Next Page'.


6. Configuration - IP Address, a Subnet Mask, and a Gateway IP Address OR DHCP state to Enabled to have the IP address, subnet mask, and gateway IP address automatically configured by a DHCP server. Click the 'Go To Next Page'.

7. Click the 'Save Changes' button. Click the 'Reboot' button.

Hardware Overview



Hardware Overview



Secondary Port

The Secondary port is a Gigabit Ethernet port used for bridging.

Reset

The Reset button serves two functions for E501S:

- To restart, press and release the Reset button quickly.
- To restore to factory default settings, press and hold the Reset button for more than 10 seconds.

Main Port

The Main port is a Gigabit Ethernet port used to connect the power and should be connected to the LAN and DHCP server.

Specifications

E501S	
Product Dimension	1300 x 204 x 70 (mm) 11.8" x 8.03 x 2.75" (inch)
Weight	1.9 Kg (4.2 lbs)
With Mounting Kit	1.6 Kg (3.6 lbs)
Networking Interface	10/100/1000 Ether ports (Two RJ45)
Operating Frequency	2.4 GHz 5.8 GHz 5.9 GHz
Antenna Gain	15.0dBi
2.4 GHz	11.00dBi
5.8 GHz	11.00dBi
Azimuth	90° (3dB) x 120° (6dB)
Max. Power Consumption	0.95W, 26.85W with Aux device powered
Power Supply	56V/30W Gigabit PoE Adapter (comes with a 100-240V AC power adapter)
Antenna	Dual Band Sector 90 (3 dB) or 120 (6 dB)
WPA Standards	802.11 a/b/g/n/ac
WPA Security	WPA2-PSK, WPA2-Enterprise
Operating Modes	Client WiFi access and Mesh
Mounting	Wall/Pole (RMs included)
Supported Pole Size	Ø1.5" to Ø3.0" (inch)
IP Rating	IP55 (fully protected from dust and can also withstand being submerged in 1m (about 3.3 feet) of static water for up to 30 mins.)
Operating Temperature	-30°C to 50°C (24°C to 140°F)
Operating Humidity	5% to 95% Noncondensing
Certification	CE, FCC, IC

Safety Notice

Warning:

To prevent loss of life or physical injury, observe the following safety guidelines. In no event shall the user be allowed to use the equipment or system unless it is used during the lifetime of the E501S platform. Ensure that only qualified personnel install, maintain, and use attachments/accesories specified by the manufacturer.

Electrical Safety Information

- Compliance with manufacturers label for voltage, frequency, and current requirements. Connecting to a different power source than those specified may result in improper operation, damage to equipment or pose a fire hazard if the instructions are not followed.
- There are no serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
- This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
- Do not substitute the power cord with one that is not the provided equipment. If the power cord is damaged, do not attempt to repair it to a 2-wire outlet as this will defeat the continuity of the grounding wire.
- The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in personal injury or death.
- Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
- Protective bonding is required to be provided by FCC to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited.
- Antenna Information: Dual-Band Dual-polarized antenna
- For product available in the USA/Canada market, only channel 1-11 can be operated.
- Selection of other channels is not possible.
- Professional installation is required.

FCC Compliance

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be caused by other devices.

For more information, contact the manufacturer.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

For more information, contact the manufacturer.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

For more information, contact the manufacturer.

RoHS/WEEE Compliance

Caring for the Environment: RoHS/WEEE

European Directive 2002/96/EC requires that the equipment bearing this symbol on the product or its packaging must be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by your local authority. Proper disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.



CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.

Alert Sign (i) Follows CE Marking

Alert sign must be indicated if a restriction on use applied to the product and it must follow the CE marking.



Online Resources

User Guide and software downloads:
<https://support.cambiumnetworks.com/files/e500/>

Support:
<http://www.cambiumnetworks.com/support/>

Contact Us:
<http://www.cambiumnetworks.com/support/contact-support/>

IC Compliance

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent équipement est conforme aux limites d'interférence indiquées dans les documents d'exploitation établis par Industry Canada. L'exploitation est autorisée dans les conditions suivantes : (1) l'équipement ne doit pas causer d'interférence et (2) l'équipement doit accepter toute interférence, y compris les interférences qui peuvent entraîner un fonctionnement indésirable de l'équipement.

For product available in the USA/Canada market, only channel 1-11 can be operated.

Le produit destiné au marché USA/Canada peut être utilisé sur les canaux 1 à 11.

For more information, contact the manufacturer.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the IC regulations.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

For more information, contact the manufacturer.