The Wrist Transmitter (WTRP)

Easy & Exchangeable Belt / Neck Cord styles

Long battery life

Waterproof

Active Button

- Pressing the Active Button for more than 1 sec will activate the Main Unit, causing it to dial emergency call or alarm.
- When the Main Unit receives the alarm signal and is being activated, you can stop the activity if desired by pressing this button for more than 8 sec. This function is not available for CTC-1032, CTC-1039, CTC-1041, CTC-1052 and CS-6000.



Learn In WTRP

Every Wrist Transmitter has a unique numeric code called "ID code". The ID code enables the Main Unit to identify the signal is transmitted from the Wrist Transmitter.

At the same time, it also prevents interference from outside sources.

- Step 1. Put the Control Panel into "Device +/-" menu and then select "Add Device" menu (or "Learning" Mode).
- Step 2. Press the Button on the WTRP, a radio signal will be transmitted to the control panel.
- Step 3. Please refer to the operation manual of your control panel under the section of "**Device** +/-" to complete the process.

Battery Life

The Wrist Transmitter uses one CR2032 3V Lithium battery as its power source.

The battery can last for more than 6 years.

If the battery voltage is low, a Low Battery signal will be send to the control panel to notify the user.

Change Between Wrist Band/Neck Cord

- Step 1. Take off the Wrist Band on the WTRP.
- Step 2. Clip the hook onto WTRP.
- Step 3. Make the Neck cord go through the hook.



Auto Low Battery Detection & Supervision

The Wrist Transmitter features Auto Low Battery detection and Supervision.

- Press and hold the Active Button for 15 seconds to activate this function (ignoring the 1st and 2nd set of LED flashes at one and eight seconds). The LED will flash three times to confirm.
- The Wrist Transmitter will automatically transmit an Low Battery detection & Supervisory code to detect Low Battery every 20 hours. If the Main Unit has not received the Low Battery detection & Supervisory code, it will then notify the user accordingly (depend on the Main Unit setting).

<NOTE>

- If Auto Low Battery detection & Supervision functions are not activated, the WTRP will not automatically check battery status.
- Auto Low Battery Detection & Supervision functions can only be activated as a pair.
- Once Auto Low Battery Detection & Supervision functions are activated, they cannot be deactivated later in any circumstances.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).