




UG	In the box	Location of controls	Setup	Mounting Instructions	Optional micro SD backup	Indicator light
Wireless smart camera H.265 & HD1080P D308 	    	 1 Beam sensor 2 LED indicator 3 Microphone 4 SD card slot 5 Speaker 6 Reset		 Hanging on the wall	Your SmartCam supports up to 64GB of local micro SD storage. Official Kingston 32GB SD card is recommended	

Install the app	Binding device	Binding device	Pairing device	FAQs	FAQs	FCC Warning:
 Three ways to download Miisafe app: 1. Scan the above QR code 2. Search Miisafe™ in Apple store or Google Play 3. Visit our website www.miisafe.com to download the app.	 Connect the power supply. Wait about 20 seconds until the indicator light flashes green light and there is voice prompts "SmartCam is ready to bind".  TP-LINK_0F8 5G WiFi master is not supported currently. You can change it if it's not the network you need. <input type="text"/> WiFi password Note that both fields are case-sensitive. <input type="button"/> Connect	 Please place the camera close to the WiFi router.  Please be patient 119 s	 You can know if pairing is finished by the LED indicator on top of the camera.  Camera is power on, but not yet connected to WiFi. Connect the camera to WiFi. • Blue light is on/WiFi connected and Paired • Blue light is off/WiFi not connected • Blue light is flashing/Someone is viewing your camera on the mobile device.	Q: Why can't I connect the camera? A: 1. Make sure Miisafe APP is the latest version, and your phone version is Android 4.2 or later and iOS 7.0 or later. 2. Make sure your WiFi is 2.4GHz not 5GHz and WiFi 5GHz unplug/replug after 10s reset the camera and connect again. Q: What should I do when the camera shows "off" on the app but the camera is connected? (The blue light is on) A: If the camera shows off, please touch app screen and pull to refresh the camera page and wait two seconds. Please do not pull the panel to refresh the camera page. Q: Why doesn't my SD card record video? A: Please make sure SD card is not "exFAT" format, If SD card is "exFAT" please format other.	 1. The first one is "multi-users" icon, from there you can invite members to view your video at the same time. 2. The second icon is playback button that show your recording details from SD card in your camera. 3. The third icon is a button to edit the camera settings. 4. The right one is a button to delete the camera from your app.	This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The following are not FCC ID or IC numbers: • Camera Any changes or modifications to this device not explicitly approved by manufacturer void your authority to operate this device. • This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The following are not FCC ID or IC numbers: • Camera Any changes or modifications to this device not explicitly approved by manufacturer void your authority to operate this device.