

CHAIRMAN



Copyright information

Copyright © 2011 UNCells Ltd. All rights reserved.

UN Cells, the UN Cells logo and the Chairman logo are the trademarks and/or registered trademarks of UN Cells Ltd.

Ulysse Nardin, the Ulysse Nardin logo are the trademarks and/or registered trademarks of Ulysse Nardin SA.

Bluetooth is a registered trademark of Bluetooth SIG Inc.

Other company and product names may be trademarks, registered trademarks or service marks of their respective owners.

UN Cells operates a policy of continuous development and reserves the right to change or improve the products described herein and to modify the contents of this document without prior notice. Under no circumstances shall UN Cells Ltd be liable for any loss of data or income, or any special, incidental, indirect or consequential damages resulting from the information provided in this document, howsoever caused.

Reproduction, transfer, duplication or distribution of all or part of this document without prior written permission of UN Cells Ltd is prohibited.

For more information about your Chairman mobile phone, visit www.uncells.com.

Welcome

Congratulations on becoming the proud owner of a Chairman mobile phone.

Chairman represents a remarkable integration of over 150 years of Swiss watch-making tradition with five years of cutting-edge research and development. The choice of materials and finish for each model, and our insistence on painstaking attention to detail, underpins our commitment to the traditions and DNA of the Ulysse Nardin brand.

We are proud and delighted that our company, UN Cells Ltd, has been granted license by the Ulysse Nardin group of companies to be linked with the Ulysse Nardin name.

We are as passionate about this truly unique and innovative product as we are about Ulysse Nardin's unique portfolio of fine time-pieces, and we sincerely hope that you, as our discerning customer, derive as much pleasure from its use as we have in bringing it to you.

Thank you for your considered purchase.

Morten Nielsen
Co-Founder and Chairman

Bobby Yampolsky
Co-Founder and Chairman

Contents

Welcome	3
About the Quick Guide	1
Important health information and safety precautions	1
Operating safety	1
Battery and charging safety	5
Specific Absorption Rate (SAR) information	7
Introducing your Chairman phone	9
Docking station	11
Product registration	12
Chairman overview	13
Preparing your phone for first use	14
Inserting the SIM card	14
Removing the battery cover	15
Inserting the battery	16
Replacing the battery cover	17
Charging your Chairman phone	17
Switching your phone on and off	18
The Home screen	20
Customising the Home screen	21
Making and receiving calls	21
Making calls	22
Making handsfree calls	23
Answering calls	24
Messaging	24
Composing messages	25
Receiving messages	26
Deleting messages	27

Working with applications	28
Using your docking station	29
Connecting the power supply.....	29
Inserting the phone.....	30
Limited Warranty	31
Learning more	36

About the Quick Guide

This short guide gives you some important safety information, and details of the limited warranty and care guidelines for your Chairman phone and docking station. It also contains a brief introduction to using your Chairman phone.

The software on your phone contains comprehensive help, and a more detailed User Guide is provided on the enclosed CD-ROM and on the website at www.uncells.com.

Important health information and safety precautions

When using your Chairman phone and accessories, the safety precautions below must be taken to avoid possible legal liabilities and damages.

Retain and follow all safety and operating instructions, and observe all warnings in the *User Guide*.

Operating safety

To reduce the risk of bodily injury, electric shock, fire and damage to the equipment, observe the following precautions.

Traffic safety

In some countries it is prohibited to use a handheld device such as a mobile phone while driving, even with a hands-free accessory. Always ensure that you adhere to the relevant legislation.

Do not use a hand-held phone while driving a vehicle. If using a hand-held phone, park the vehicle safely before using the phone in any way.

Do not place the phone on the passenger seat or where it can break loose in a collision or sudden stop.

Operating environment

Remember to follow any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that no part of the human body be allowed to come too close to the antenna during operation of the equipment.

Use only the supplied or approved parts. Unauthorised antennas, modifications or attachments could damage the phone and may violate regulations governing radio devices.

Electronic devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your phone.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm (6 inches) be maintained between a hand-held wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

If you have been fitted with a pacemaker:

- Always keep the phone more than 15 cm (6 inches) from your pacemaker when the phone is switched on.
- Do not carry the phone in a breast pocket.
- Use the ear opposite the pacemaker to minimise the potential for interference.
- If you have any reason to suspect that interference is taking place, switch off your phone immediately.

Hearing aids

Some wireless phones may interfere with some hearing aids. In the event of such interference, consult your service provider.

Other medical devices

Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices.

Switch off your phone in health care facilities when any regulations posted in these areas instruct you to do so.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles (e.g. electronic fuel injection systems, electronic anti-skid (anti-lock) braking systems, electronic speed control systems, air bag systems).

Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.

For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area.

Aircraft

Switch off your phone before boarding an aircraft. The use of wireless telephones in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network and may be illegal. In the United States, FCC regulations currently prohibit using your Chairman phone while in the air.

Failure to observe these instructions may lead to suspension or denial of telephone services to the offender, or legal action, or both.

Potentially explosive atmospheres

Switch off your phone when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

You are advised to switch off the phone when at a refuelling point or service station. Observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include (but are not limited to) below deck on boats; chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles, such as grain, dust

or metal powders; and any other area where you would normally be advised to turn off your vehicle engine.

Protect from direct sunlight

Do not leave your phone and its battery in places where the temperature may exceed 50°C (100°F), such as in a vehicle, on a window sill or behind glass that is exposed to direct sunlight or strong ultraviolet light for extended periods of time, as this may cause damage to the product, overheat the battery or pose a risk to the vehicle.

Battery and charging safety

Your Chairman phone is supplied with a Lithium ion (Li-ion) battery and a micro-USB to USB cable, which can be used with the charger provided and connected to an appropriate power source or to the USB port in a computer or similar device.

Caution: *Ensure that you adhere to the following safety points. Failure to do so may result in permanent damage to the battery, phone or charger, and may cause injury or damage to people and property.*

- Only use an approved battery and charging device. Using an unapproved battery or unapproved charging device may cause damage to the battery, phone or charger and may cause injury to people or property.
- The charger supplied is for indoor use only.
- Do not attempt to remove the battery from the phone while it is charging.
- To reduce the risk of fire or burns do not attempt to open, disassemble or service the battery.

- Dispose of batteries carefully. Do not dispose of the battery in fire or water, but follow local regulations regarding disposal or recycling.
- Do not crush or puncture.
- Do not short external contacts.
- Do not expose the phone, battery or charger to temperatures above 50°C (100°F).
- Replace only with a battery designated for this product.
- Connecting your phone to equipment, such as a laptop or desktop computer, that is inadequately grounded can result in an electric shock.
- When connecting your phone to an electrical device, always ensure that the device is adequately grounded to earth before connecting your phone. See the device's user guide for details.
- Keep the battery and device dry and away from water or any liquid as it may cause a short circuit.
- Keep metal objects away from the battery and its external contacts, to avoid causing a short circuit.
- Do not use a battery that appears damaged, deformed or discoloured, or appears to have rust on its casing.
- Do not use a battery that overheats or emits an unpleasant smell.
- Keep the battery out of reach of babies and small children.

If the battery leaks:

- Do not allow any leaking fluid to come into contact with skin or clothing. If contact occurs, flush the area immediately with clean water and seek medical advice.
- Do not allow leaking fluid in contact with eyes. If contact occurs, do not rub eyes but flush with clean water immediately and seek medical advice.
- Take extra care to avoid a leaking battery coming in contact with fire as there is a danger of ignition or explosion.

Specific Absorbtion Rate (SAR) information

Your Chairman phone contains radio transmitters and receivers, and meets independent guidelines for exposure to radio waves. It has been designed to be within limits for exposure to radio waves as recommended by international guidelines, and is within safety margins appropriate to all persons regardless of age, gender or health.

The unit of measurement when examining exposure for mobile devices is the Specific Absorption Rate (SAR). The SAR limit is defined by several bodies in different countries.

The SAR limit defined by the Council of the European Union is 2.0 W/kg averaged over 10 grammes of tissue. The Chairman device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. The highest SAR value reported under this standard during product certification for use at the ear is 0.071W/kg and when properly worn on the body is 0.080 W/kg.

The SAR limit defined by the FCC is 1.6 W/kg averaged over one gramme of tissue. The Chairman device (FCC ID: ZTBCHMN-01) was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. The highest SAR value reported under this standard during product certification for use at the ear is 0.207 W/kg and when properly worn on the body is 0.441W/kg.

To maintain compliance with RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with RF exposure requirements, and should be avoided.


Note that using the device with accessories and enhancements may alter the SAR value of the device, and that SAR values may vary depending on the network band and differing national requirements for reporting and testing. For any updates to product information relating to SAR values, see www.uncells.com.

Warning! *Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to use the equipment.*

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Introducing your Chairman phone




1	Chairman phone	7	Battery cover release tool
2	Accessories travel bag	8	Lithium battery
3	Micro USB to USB cable	9	32GB USB memory stick
4	Universal charger body	10	Leather case
5	UK, EU and US socket adaptors	11	Documentation pack*
6	Leather cable tie		

* The documentation pack includes the Certificate of Authenticity, Warranty Card, this Quick Guide, and a CD which contains the full *User Guide* and supporting material.

Before using your Chairman phone the battery and SIM card must be installed, and the battery must be charged. For details, see *Inserting the battery* on page 16 and *Inserting the SIM card* on page 14. You should also remove any protective film from the phone's surfaces.

Docking station

The docking station is supplied separately from the box that contains your Chairman phone. For information see *Charging your phone using the docking station* on page 1 and the User Guide.



1	Phone cradle	5	Speaker (present on both sides)
2	Micro USB connector	6	Bluetooth pairing button
3	Handsfree microphone	7	USB port
4	Accessories compartment	8	Charger connector socket

When you have unpacked the sales package, you can store the charger, USB memory stick, battery cover release tool, cables and documentation in the accessories compartment for ease of access.


For information on caring for your docking station, see the *User Guide*.

Product registration

It is our aim to provide you with the highest level of after-sales support and service. Registration validates your warranty, so that in the unlikely event that your phone needs to be repaired, your request can be processed quickly. Please register your Chairman phone by calling the UN Cells Customer Service Department. For details on how to contact the UN Cells Customer Service Department see

www.uncells.com.

Chairman overview



1	POWER/END key	10	Winding crown
2	#/BACK key	11	Camera flash
3	*/MENU key	12	Camera lens
4	SEND key	13	Ulysse Nardin rotor
5	Fingerprint reader	14	Limited Edition plate
6	Sapphire crystal touchscreen	15	Battery cover release recess
7	Earpiece	16	Micro USB port
8	VOLUME keys	17	SIM access cover
9	Stereo speakers		

Preparing your phone for first use

This section describes the basic steps to start using your phone. For more details on using the features on your Chairman phone, see the relevant sections in the *User Guide*.

Inserting the SIM card

Caution: *Always switch off your Chairman phone before removing the SIM card or battery, to prevent damage to the phone and SIM card.*

1. Ensure that your Chairman phone is switched off.
2. With the front of the phone facing you, lift the left side of the SIM access cover.

Caution: *To avoid scratching the polished surface, never use a metal implement or sharp item to open the SIM access cover.*

3. Insert the SIM card with the notched edge towards the body of the phone and the gold contacts facing you, as shown in the diagram.
4. Push the SIM card fully into the phone, using the flat end of the tool provided, until it engages. You should hear a gentle click.



Note: The SIM card will not engage if inserted incorrectly. If you cannot insert the SIM card fully into the phone without exerting force, remove it and check that it is oriented correctly.

5. Close the SIM access cover.

Caution: Always keep the SIM card out of the reach of children.

To remove the SIM card

If you need to remove the SIM card, for example to insert a different SIM card into your Chairman phone, follow these instructions.

1. Ensure that your Chairman phone is switched off.
2. With the front of the phone facing you, lift the left side of the SIM access cover.
3. Using the flat end of the tool provided, press the edge of the SIM card until it pops up.
4. Gently slide the SIM card out of the slot.

Caution: Take care when handling the SIM card as it is delicate and may be damaged by rough handling.

Removing the battery cover

Your Chairman phone has been designed so that you should not need to remove the battery in normal use. However, if you need to remove the battery cover, follow these instructions.

1. With the back of the Chairman phone facing you, place the tip of the battery cover release tool in the smaller recess at the base of the phone and press firmly.

2. Grip the sides of the battery cover and slide it towards the base of the phone to release the tabs from the retaining lugs.
3. Lift off the battery cover.


Caution: *Keep the battery cover release tool and other small parts out of the reach of children.*

Inserting the battery

The battery is supplied separately in the sales package, though it will usually be inserted for you when you purchase your Chairman phone.

If you do need to insert the battery yourself, for example if you are replacing the battery, follow these instructions.

1. Remove the battery cover, if it is in place.
2. Discard any packaging from the battery.
3. Insert the battery with the label upwards, putting the side of the battery with the contacts into the phone first, so that they connect to the contacts in the phone.
4. Press the other edge of the battery gently into place so that the battery is flat.
5. Replace the battery cover.




Tip: *If you need to remove the battery for any reason, there is a notch on the side of the battery opposite the winding crown that enables you to lift the battery out of the phone more easily.*

Caution: *Dispose of batteries carefully. Do not dispose of the battery in fire or water, but follow local regulations regarding disposal or recycling.*

Replacing the battery cover

1. Place the battery cover on the back of the phone as shown, with the tabs on the sides of the cover aligned with the slots on the body of the phone.
2. Slide the cover towards the top of the phone, ensuring that the tabs on the side of the cover engage with the slots on the body of the phone and that the metal tabs at the top of the cover engage with the slots on the phone under the rotor cover.



As the cover closes fully, the retaining catch engages and you should hear a gentle click.

3. Ensure that the cover is correctly positioned by checking that the gap between the battery cover and the body of the phone is even all the way round.

Charging your Chairman phone

Your Chairman phone is provided with three adaptors that fit UK, EU and US power sockets, to enable you to charge your phone in many worldwide locations.

Note: *The charger provided is for indoor use only.*

Caution: *Only use a battery and charger that have been approved for use with your Chairman phone. Using unapproved charging equipment or batteries may damage your Chairman phone and invalidate your warranty.*

Before charging your phone, connect the appropriate adaptor to the charger body by sliding the socket adaptor into the charger body until the retaining catch clicks into place.

To remove the socket adaptor from the charger body, depress the retaining catch with your thumb and slide the adaptor off the charger body.

Caution: *Never charge your Chairman phone when the phone or the connector at the base of the phone is damp or wet.*

1. Insert the smaller end of the USB cable into the micro USB port on the base of the phone.
2. Insert the larger end of the micro USB cable into the charger body and plug the charger into an appropriate power source.

Note: *The charger provided is for indoor use only.*

or

Connect the larger end of the USB cable into a USB port on a computer.

Note: *When using a computer to charge your Chairman phone, ensure that the computer is turned on and active rather than in sleep or standby mode, to avoid discharging the phone's battery rather than charging it.*

3. When the phone is fully charged, disconnect it from the charger and disconnect the charger from the power source.

If you prefer, you can charge your Chairman phone using the docking station. For details see *Using your docking station* on page 29.

Switching your phone on and off

Switch the phone on and off using the POWER/END key on the top right of the keypad.

To switch your phone on

1. Press and hold the POWER/END key for a few moments until the screen illuminates. The Ulysse Nardin and Chairman logos appear while the phone is starting up.
2. Depending on your settings you may be asked to enter a PIN code for your SIM card before you can access the SIM card to make and receive calls.

Note: *If you start your Chairman phone without a SIM card installed, you cannot connect to a mobile phone network. You may connect to a Wi-Fi network, if one is available, in order to configure your phone. When prompted, touch **Connect to network**. For information on connecting to a Wi-Fi network, see the appropriate section in the User Guide.*

To switch your phone off

1. Press and hold the POWER/END key for a few moments. The **Phone options** menu appears.
2. Touch **Power off**.
3. To confirm that you want to switch off your phone, touch **OK**.

The Home screen

When you switch on your Chairman phone, the main Home screen appears. The Home screen displays a clock face, designed exclusively for the Chairman phone by Ulysse Nardin. Scroll left or right to see additional Home screen pages, which can be customised. For details on customising Home screen pages see the *User Guide*.

- 1 Battery level indicator**
- 2 Date indicator** – shows today's date.
- 3 Notification bar** – indicates the status of your Chairman phone.
- 4 Dual time indicator** – shows the hour at the dual time location.
- 5 Signal strength indicator**
- 6 Phone icon** – touch to use the **Phone** application to make calls.
- 7 Launcher icon** – touch the icon or slide it upwards to view icons for installed applications. The lights below the icon indicate which pane of the Home screen is currently displayed.
- 8 Messaging icon** – touch to start the **Messaging** application.



Customising the Home screen

The Home screen consists of the main pane and six additional panes that you can access by scrolling left or right from the main pane. You can customise the home screen to display different background wallpaper and add icons for the applications and features that you use most often. For details, see the *User Guide*.

The icons that are already present on the Home screen panes cannot be moved or deleted, but you can add up to nine icons for applications, items and folders to the empty panes.

Tip: *Touch and hold the POWER/END key to return to the main pane of the Home screen.*

Making and receiving calls

There are several ways you can make and receive calls. This section describes how to make and receive a call using the keypad and the virtual keypad in the **Phone** application, and how to answer an incoming call. For information on other ways to make a call see *Making and receiving calls* in the *User Guide*.


Caution: *It is not recommended, and may be illegal, to use your Chairman phone while driving. If you need to make or answer a call, or use any of the phone's other features, pull off the road and stop your vehicle in a safe place before using your phone.*

Making calls

Using the keypad

1. From the Home screen, use the keys on the keypad to enter the number you want to call. The number is shown on the display.
2. If you enter a number incorrectly, press the POWER/END key (2) to delete a single digit, or press and hold the POWER/END key to delete the whole number.
3. Press the SEND key (1) to place the call.

Tip: *When dialling an international number, press and hold the 0 key on the keypad to display the + symbol. This represents the international access number, which may differ depending on the country you are calling from.*



Using the touchscreen

1. From the Home screen or Launcher screen touch **Phone**.
2. If you are using the **Contacts** or **Call Log** features, touch the **Phone** tab.
3. Use the keypad on the screen to enter the number you want to call. The number is shown at the top of the display.
4. If you enter a number incorrectly, touch  to delete a single digit, or touch and hold  to delete the whole number.
5. Touch  to place the call.



Tip:

*When dialling an international number, touch and hold **0** to display the **+** symbol. This represents the international access number, which may differ depending on the country you are calling from.*

Making handsfree calls

When your Chairman phone is paired with a Bluetooth device such as your docking station you can make or receive calls using the touchscreen or keypad of your Chairman phone.

Caution: Do not put excessive force on the touchscreen while the phone is in the cradle, as doing so may force the lid of the docking station to close.

1. When making a call, or when in a call, touch **Speaker**. The call now uses the Bluetooth device's speakers and microphone.

Answering calls

When an incoming call is received, depending on your settings you hear a ringing tone, the phone vibrates and the key lights and rotor lights flash. The incoming call is also saved to the Call log. For details see the *User Guide*.

Using the keypad

To answer the call, press the SEND key.

Using the touchscreen

To answer the call, drag the phone icon  to the right.

Depending on your settings, if you are already in a call when you answer an incoming call the current call is placed on hold. For details on handling multiple calls and changing your call waiting settings, see the *User Guide*.

Messaging

You can use the **Messaging** application to exchange text and multimedia messages with other mobile phone users.

Note: *Messaging and multimedia messaging are network services. For information on enabling these services, contact your service provider.*

This section describes how to perform some of the basic tasks when working with messages. For details on composing multimedia messages and configuring message settings, see the *User Guide*.

Composing messages

You can use your Chairman phone to send text messages, or multimedia messages that contain text, pictures, recordings, audio files, videos or picture slideshows.

To compose a new text message

1. From the Home screen or Launcher screen touch **Messaging > New message**.
2. In the **To** field, enter the name of a contact from your Contacts list, or a mobile phone number. As you enter the name or number, matching contacts appear.

Note: *If you enter an email address, the phone automatically converts the message to a multimedia message. For details see the User Guide.*

3. Continue to enter the name or number, or touch the name of the contact you want to send the message to.
4. Touch the **Type to compose** field to open the onscreen keyboard and enter your message.
5. To send the message, touch **Send**.

Note: *If you touch the #/BACK key before sending a message, the message is saved as a draft.*

To continue a message thread

1. From the Home screen or Launcher screen touch **Messaging**.
2. Touch the thread you wish to continue.

The thread window opens showing the messages that have been exchanged.

3. Touch the **Type to compose** field to open the onscreen keyboard and enter your message.
4. Add media to your message if you are sending a multimedia message.
 - To add a media file, touch the fingerprint reader to bring up the menu and touch **Attach**. You can add a media file already stored on your phone, or create a new media file.
 - To capture a picture or video, or record a new audio clip, touch **Capture picture**, **Capture video** or **Record audio**. You can then capture or record a new media file which you can review and then add to the multimedia message, or discard and try again.

Tip: *If you want to add more than one picture, touch **Attach slideshow** and select up to 10 photos to add as a slideshow.*

5. To send the message, touch **Send**.

Receiving messages

When you receive a new message, a notification appears in the notification bar at the top of the screen.

To read a new message

1. Drag the notification bar down towards the bottom of the screen and touch the message notification.

The message thread opens.

Note: *If you have already exchanged messages with the same person, previous messages are included in the thread.*

To respond to a message

1. Touch the text entry field at the bottom of the screen. The virtual keyboard appears.
2. Enter the text of your reply and touch **Send**.

To see other options, touch the fingerprint reader to bring up the menu.

Deleting messages

You can delete a single message, delete an entire thread or delete all message threads.

To delete a single message

1. When the thread is open, touch and hold the message you want to delete. The **Message options** menu appears.
2. Touch **Delete message**. A confirmation dialog appears.
3. To confirm deletion, touch **Delete**, or touch **Cancel** to keep the message.

To delete an entire thread

1. When the thread is open, touch the fingerprint reader to bring up the menu and touch **More > Delete thread**. A confirmation dialog appears.

Note: *If you want to delete all message threads in the **Messaging** application, touch **All threads**.*

2. To confirm deletion, touch **Delete**, or touch **Cancel** to keep the thread.

Working with applications

Your Chairman phone is loaded with a number of pre-installed features and applications. You can access the features and applications from the Home screen or Launcher screen.


For details on the applications loaded onto your Chairman phone, see the *User Guide*.

Using your docking station

As well as charging your Chairman phone, you can use the docking station to make and receive handsfree calls, listen to music, and backup your phone data. You can also connect other Bluetooth-compatible devices to your docking station. For details on the docking station's features, see the *User Guide*.

Connecting the power supply

1. Connect the socket adaptor that you wish to use to the body of the power supply unit for the docking station.
2. Connect the power supply unit to a suitable power source.
3. Plug the 4mm jack at the other end of the cable into the lowest socket on the docking station.



When the power supply is connected, the docking station turns on automatically. The Bluetooth pairing button glows red if it is not paired with a device or blue if it is paired with a device.

To turn the docking station off

1. Press and hold the pairing button.

An audible alert can be heard and the light on the pairing button turns off.

Note: *If you are making or receiving a call, or in an active call, when you press and hold the pairing button the call is ended. Press and hold the pairing button again to turn off the docking station.*

To turn the docking station on


1. Press and hold the pairing button.

An audible alert can be heard and the light on the pairing button glows red when it is turned on.

Inserting the phone

1. Lift the lid of the docking station and slide the phone into the phone cradle in the direction indicated.
2. Press the phone firmly into the cradle, to ensure that the phone connects properly with the micro USB connector in the base of the cradle.

When the phone is docked, the battery indicator on your phone shows that the phone is charging.



To remove the phone from the docking station

To remove the phone from the docking station, grip the sides of the phone and slide it upwards in the opposite direction until the base of the phone is clear of the cradle's sides before lifting the phone out of the cradle.

Limited Warranty

This limited warranty agreement is given by UN Cells Limited (“UN Cells”) to the original purchaser (“Customer”) of the UN Cells mobile phone Chairman Product (“Product”) and any accessories supplied with the device including the docking station (“Accessories”).

1. This Warranty does not exclude or limit any of the Customer’s statutory rights or any of the Customer’s rights against the seller or dealer of the Product.
2. The Warranty for the Product shall last for the following warranty periods commencing on the date of original purchase of the Product (“Warranty Period”):
 - a. two (2) years for the Product and Accessories, excluding the parts and components referred to in clause 2.2;
 - b. one (1) year for the battery, charger, cables and cases.
3. Any claim under this Limited Warranty is subject to the Customer notifying UN Cells or an authorised service agent of the alleged defect within thirty (30) days of the defect coming to the Customer’s attention, and in any event no later than before the expiry of the relevant Warranty Period.
4. This Limited Warranty is only valid and enforceable in the country where the product is purchased, and provided UN Cells intended for the Product to be sold in that country. If the Product was purchased in the European Union, then this warranty will apply in all countries in the European Union.
5. During the Warranty Period, UN Cells will repair, modify or replace, at UN Cells’ sole option, any defective parts with new or refurbished replacement parts if such repair, modification or replacement is required due to product malfunction or failure during normal usage. Any parts that have been replaced will become the property of UN Cells. No charge will be made to the Customer for such repair, modification or replacement, or for the labour charges incurred in repairing, modifying or replacing the defective parts.
6. The Warranty Period for the repaired Product or Accessory shall be until the end of the original Warranty Period or for ninety (90) days from the date of repair, whichever is longer.
7. This Limited Warranty does not cover physical damage to the surface of the Product or Accessory, including, but not limited to, scratches or wear and tear on the camera lens, touchscreen or polished surfaces of the Product.

8. Before returning the Product for repair, the Customer shall be responsible for backing up any data stored on the Product. UN Cells may have to erase all applications and Data and UN Cells shall not be responsible for damage to or loss of any programs, applications or data stored on the Product when it has been sent for repair.
9. On UN Cells' request the Customer shall provide proof of the date of original purchase or delivery of the Product or Accessory. Such proof may be in the form of a legible, unmodified and dated Certificate of Ownership, or an invoice or a receipt from an authorised retailer showing the date of purchase or delivery, the Product's IMEI and/or Limited Edition number and the name and address of the authorised retailer that sold the Product to the Customer.
10. UN Cells shall bear the cost of returning the Product after completion of repair under this Limited Warranty to the location from which the Customer handed over the product to UN Cells.
11. This Limited Warranty shall not apply if:
 - a. the defect or damage was caused, or the repair or replacement is required, as a result of usage other than as described in the user documentation, rough handling, abnormal use or conditions, exposure to moisture, dampness, extremes of temperature, a rapid change in temperature, chemical agents, or spillage of food or liquid, improper storage, unauthorised modification or repair, connection to unauthorised devices, misuse, accident, alteration or any other actions beyond the reasonable control of UN Cells, including without limitation damage caused by shipping, dropping the Product, or deterioration of consumable parts such as batteries which by their nature have a limited lifespan.
 - b. the defect was caused as a result of installation of third party software products, applications or games, including, but not limited to, internet or computer viruses, Trojan horses, worms, bugs, spiders, bots or other malicious software.
 - c. the product was damaged by short-circuiting or leakage of the battery, or if the seals of the battery enclosure were damaged or tampered with, or if the battery has been used in devices other than that for which it has been specified.
 - d. the Product was damaged by external causes such as dropping the phone, or collision with an object, or fire, flooding, earthquake, lightning, wind storm, exposure to adverse thermal,

- environmental or weather conditions or an Act of God.
- e. the defect was caused by the Product being used with or connected to an accessory not approved or provided by UN Cells or being used in other than its intended use and where it can be shown by UN Cells that such defect is not the fault of the Product itself.
- f. the defect was caused by the simcard or by a defective cellular network or other wireless system, including but not limited to femtocells, picocells or wifi networks, or by a change in any of the aforesaid since the date of purchase of the Product.
- g. the bootloader was unlocked by the Customer or his/her agent (allowing third-party operating system installation) using the fastboot program.
- h. the Product software needs to be updated because of a change to the cellular network parameters.
- i. the Product's Limited Edition badge, IMEI label or the accessory data code has been removed, defaced, altered or is illegible.
- j. the Customer did not return the Product to the Customer Service Department (see www.uncells.com) or an authorised retailer within thirty (30) days of the appearance of the defect.
- k. The defect or damage was caused by unauthorised repair being carried out.
- l. The defect or damage was caused by failure to follow the instructions for care of the product, or by failure to follow safety instructions.
- m. the defect or damage was as a result of general wear and tear incurred in normal usage of the Product.

12. In the event that a problem arises within the Warranty Period, the Customer should take the following actions:

- a. Contact the UN Cells Customer Service Department (See www.uncells.com for details on how to do this.)
- b. Return the Product or Accessory to the place of purchase, or to the Service Centre if so advised by the Customer Service Department.
- c. UN Cells will repair or authorise the repair of the Product or Accessory under this Limited Warranty within thirty (30) days of receipt of the Product or Accessory by UN Cells or its authorised service centre, or within an extended period of time as notified to the Customer if the repair

requires a longer time period ("Timeframe"). If UN Cells cannot repair the product within the Timeframe, or if the same repair is repeatedly required, UN Cells may, at its sole option, provide a replacement Product or Accessory or refund the purchase price minus a reasonable sum for usage.

13. If the Product or Accessory is returned during the Warranty Period but it is found that the defect is not covered under the terms of this Limited Warranty, the Customer will be advised of the estimated cost of the repair and shipping charges and may elect to either pay for the repair and shipping or have the Product or Accessory returned freight collect.

14. If the Product or Accessory is returned to the Customer Service Department outside the Warranty Period, UN Cells' normal service policies shall apply and the Customer will be responsible for all costs of repair and replacement and for all shipping charges.

15. If the Product or Accessory is returned to the Customer Service Department outside the Warranty Period, UN Cells' normal service policies shall apply and the Customer will be responsible for all costs of repair and replacement and for all shipping charges.

16. THIS LIMITED WARRANTY STATES THE ENTIRE WARRANTY GIVEN BY UN CELLS TO THE CUSTOMER. ALL IMPLIED WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE RELEVANT WARRANTY PERIOD. IN NO EVENT SHALL UN CELLS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL LOSSES OR DAMAGES OF ANY NATURE WHATSOEVER (WHETHER SUCH LOSSES OR DAMAGE WERE NOTIFIED TO UN CELLS, FORESEEN, FORESEEABLE, KNOWN OR OTHERWISE), TO THE FULLEST EXTENT THAT THOSE LOSSES OR DAMAGES CAN BE DISCLAIMED BY LAW, INCLUDING BUT NOT LIMITED TO:

- a. PUNITIVE, SPECIAL OR CONSEQUENTIAL DAMAGES.
- b. THIRD PARTY CLAIMS.
- c. LOSS OF ANTICIPATED BENEFITS OR PROFITS.
- d. LOSS OF ACTUAL OR ANTICIPATED SAVINGS.
- e. LOSS OF REPUTATION.
- f. LOSS OF GOODWILL.
- g. LOSS OF OPPORTUNITY.
- h. LOSS OF BUSINESS.

- i. LOSS OF, CORRUPTION OF OR DAMAGE TO DATA.
 - j. LOSS OF USE OF THE PRODUCT OR ACCESSORY OR ANY ASSOCIATED FACILITIES OR EQUIPMENT.
- 17. To the extent permitted by applicable law, UN Cells maximum liability under this warranty shall be the price paid for the Product or Accessory, less a reasonable sum for usage. This limitation does not apply in the case of gross negligence, fraud, or death or personal injury arising from UN Cells negligence.
- 18. In the event that any term of, or any part of any term of, or any right arising from, this Limited Warranty shall be invalid or unenforceable, the validity or enforceability of all other terms or rights or the remainder of any such term or right shall continue in full force and effect except for the invalid provision or the extent of unenforceability of the provision.
- 19. The Product has not been designed, and is not sold, as a device whose sole or primary purpose is the making of receiving of emergency calls or data. As such, the Product should not be relied upon for making or receiving calls or data relating to emergency or life-threatening or critical situations.
- 20. UN Cells operates a policy of continuous development and reserves the right to make changes and improvements to any of the Products or Accessories without prior notice. All information relating to the warranty, product specifications and features are subject to change without notice. See the UN Cells website, www.uncells.com, for the latest product and warranty information.
- 21. Any questions relating to this Limited Warranty may be directed to the Customer Service Department. See the UN Cells website, www.uncells.com for information on how to contact the Customer Service Department.

UN Cells Limited
Lakeside House,
1 Furzeground Way
Stockley Park East,
Uxbridge
Middlesex,
UB11 1BD
United Kingdom

Learning more

This *Quick Guide* describes some of the basics to help you start using your Chairman phone and docking station.

To find more information on using your docking station and phone, see the *User Guide*. For the most up-to-date version of the *User Guide*, see www.uncells.com.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help