

02

Setting Up the Chime

The Amcrest Smart Home app connects your Amcrest chime to your Android or iOS mobile device, ensuring you are always connected to what matters most.

To get the app, search for **"Amcrest Smart Home"** in the Google Play or App Store.




Note: The Amcrest doorbell must be connected to your Amcrest Smart Home account before setup. For more information on how to set up a Amcrest doorbell, please visit: amcrest.com/doorbellssetup

Connecting to the Smart Home App

Open the Amcrest Smart Home app and tap "Register" to register an account. After registering an account, log into the app and tap "Add Device".

You will need to allow all notification and location permissions to allow the camera to connect to your mobile device.



6

Note: If a doorbell has already been added to your account, please tap on the (+) icon.

7

Note: Follow the on-screen prompts to add the chime to your Amcrest Smart Home account.

8

Scan the QR Code or Manually Enter the S/N

Scan the QR code located on your chime.

If you are unable to scan the QR code you can manually enter the serial number by tapping "Manually enter SN".

If you are manually entering your SN you will have to select the device you are adding.




9

Linking the Chime

Access the Wi-Fi doorbell on your Amcrest Smart Home account.

Tap on the settings icon (⚙) and access the Amcrest Chimes menu. Tap on "Link Digital/Mechanical Chime".

Since this is a digital chime, select Digital Chime to link the chime to your Amcrest doorbell.



10

03

FAQ

Q: How do I factory reset the chime?
Press the reset button on the side of the device with a safety pin or similar object and hold it down for 10 seconds. A blue light will illuminate for 3 seconds and then turn off. The device will automatically reboot and restore to its default settings.

Q: Why is the Device Showing as Offline?
If the device is registering as offline please check the status indicator light on the device. If the status indicator is flashing blue it means the device is not properly connected to your network. Verify that your wireless network is active and configure the device to your network.

Q: Why Does the Chime Keep Turning On?
During initialization, ensure the device has been placed into wireless configuration mode. To place the device into wireless configuration mode, press and hold the reset button for five seconds until the indicator light flashes green. This signifies that the hotspot for the device is active and ready to connect.

10

Regulatory Information

The regulatory information herein might vary according to the model you purchased. Some information is only applicable for the country or region where the product is sold.

FCC Information



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Conditions:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

FCC Compliance:

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication.

- For class B device, these limits are designed to provide reasonable protection against harmful interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.