



SRF-C220 use the following frequency for hopping frequency

Frequencies.freq[0]= 906250;	Frequencies.freq[1]= 923250;
Frequencies.freq[2]= 907750;	Frequencies.freq[3]= 924750;
Frequencies.freq[4]= 903750;	Frequencies.freq[5]= 920750;
Frequencies.freq[6]= 909250;	Frequencies.freq[7]= 904750;
Frequencies.freq[8]= 925250;	Frequencies.freq[9]= 904250;
Frequencies.freq[10]= 907250;	Frequencies.freq[11]= 905250;
Frequencies.freq[12]= 925750;	Frequencies.freq[13]= 903250;
Frequencies.freq[14]= 918750;	Frequencies.freq[15]= 906750;
Frequencies.freq[16]= 926750;	Frequencies.freq[17]= 908250;
Frequencies.freq[18]= 908750;	Frequencies.freq[19]= 912750;
Frequencies.freq[20]= 909750;	Frequencies.freq[21]= 910250;
Frequencies.freq[22]= 922250;	Frequencies.freq[23]= 910750;
Frequencies.freq[24]= 916250;	Frequencies.freq[25]= 911250;
Frequencies.freq[26]= 914250;	Frequencies.freq[27]= 911750;
Frequencies.freq[28]= 924250;	Frequencies.freq[29]= 912250;
Frequencies.freq[30]= 918250;	Frequencies.freq[31]= 913250;
Frequencies.freq[32]= 913750;	Frequencies.freq[33]= 914750;
Frequencies.freq[34]= 905750;	Frequencies.freq[35]= 915750;
Frequencies.freq[36]= 915250;	Frequencies.freq[37]= 916750;
Frequencies.freq[38]= 917250;	Frequencies.freq[39]= 920250;
Frequencies.freq[40]= 917750;	Frequencies.freq[41]= 919250;
Frequencies.freq[42]= 921250;	Frequencies.freq[43]= 919750;
Frequencies.freq[44]= 921750;	Frequencies.freq[45]= 922750;
Frequencies.freq[46]= 926250;	Frequencies.freq[47]= 923750;
Frequencies.freq[48]= 902750;	Frequencies.freq[49]= 902250;
Frequencies.freq[50]= 927750;	Frequencies.freq[51]= 927250;

The system shall hop to channel frequencies that are selected at the system hopping rate from a pseudo randomly ordered list of hopping frequencies. Each frequency must be used equally on the average by each transmitter.

FCC ID :2ADGD-SRFC220US

Signature :

Yang-Sheng, Huang