



i28 Ultra User Manual

Please read this manual carefully before use and keep it for future use.

Device maintenance

Please remember the following tips when you maintain your smart watch:

Clean the smart watch regularly, especially its inner side, and keep it dry. Adjust the smart watch tightness to ensure air circulation. Excessive skincare product should not be used for the wrist wearing the smart watch.

Please cease wearing the smart watch in case of skin allergy or any discomfort.

Why can not take a hot bath with the smartwatch?

P.S. The bath water has a relatively high temperature, and generates a lot of vapor which is in the gas phase with small molecular radius and can easily infiltrate into the smart watch from the shell gap. When the temperature drops down, the vapor will condensate into liquid-phase droplets which will easily cause the short circuit inside the smart watch and damage the circuit board and then damage the smartwatch.



Please scan the QR code, download the app, and follow the prompts to start using the smartwatch

Touch and button



Swipe down : Fast function interface

Swipe up : Notification

Swipe right : Function menu list

Swipe left : Main function interface

Long press : Dial switch



Button above

Power on: Long press for 3 seconds until the screen lights up



Shut down: Long press for 3 seconds, select [Power off]

Short press: Screen on/off

Button below: Function key

※ If the boot fails after you press and hold the power button for 3 seconds please charge and try again.

Function Menu List



Function menu list

You can use all the functions in the smart watch

Include: Activity, Exercise, Exercise Records, Sleep, Heart Rate, Blood

Pressure, SpO2, Phone Call, DA GPT, AI Voice, Stock, Weather, Messages,

Shutter, Player, Tools, Cycle Tracking, World Clock, Find Phone, Games,

Calculator, Calendar, Settings.

Function introduction



Dial switch

Press and hold for 2 seconds on the main screen to enter the watch face switching interface, swipe left and right to switch the watch face to be selected, and click the selected watch face. You can also switch by rotating the button in the upper right corner.



Control panel

Function summary: DND Mode, Low Power Mode, Brightness, Flashlight, E-card, Settings

※ You can swipe down on the home screen to enter this function.



Activity data

Shows the number of steps, calories and activity time on the day, and the goal can be set in the APP.

Function introduction



Exercise

Sports mode options: Walking, Running, Cycling, Skipping, Badminton, Basketball, Football, etc. Click the icon to start the exercise.



Exercise records

This interface saves your recent exercise records, and you can view data such as exercise duration, total steps, total calories, heart rate, and Total distance during exercise.



Sleep


This interface displays the sleep monitoring status of the day, the data is updated everyday, and the data can be uploaded and saved synchronously by connecting to the App.

Function introduction



Heart rate

Turn on the timing detection on the App, and the interface displays the heart rate data of the day;



Blood pressure

When entering the blood pressure measurement interface, the green light at the bottom lights up to start the measurement, and the measurement is completed within 30 to 60 seconds. The measurement at this time is based on the PPG technology.



Blood oxygen

When entering the blood oxygen measurement interface, the red light at the bottom lights up to start the measurement, and the measurement is completed within 30 to 60 seconds. The measurement at this time is based on the PPG technology.

Function introduction



Phone Call

You can see the Recent Call, Dial Pad, and Contacts in this interface.

Contact needs to be added through the app. You can add up to 8 contacts at most.



DA GPT

You can click the button, enter the voice according to the prompts, and start communication with DA GPT.

※ You need to connect to the app before you can use it.



AI Voice

You can click the button to say your instructions, and your mobile phone will execute the instructions you said. For example, open a certain app software, or ask today's weather

※ You need to connect to the app before you can use it.

Function introduction



Stock

You can find the stock code you need to view in the mobile app.

You can choose up to 6 stocks at most.

※ You need to connect to the app before you can use it.



Weather

After the watch is connected to the App and the location permission is turned on, this is the case. The weather interface will display the real-time weather temperature and weather type.

※ You need to connect to the app before you can use it.



Message

Turn on the push of relevant information on the App side, and the watch side can receive the corresponding message push, and the upper limit will be automatically over written.

※ You can swipe up on the home screen to enter this function.

Function introduction



Shutter

Can control the phone's camera to take a photo. You can click the screen or shake your watch.


※ You need to connect to the app before you can use it.



Music

Can control the phone's music playback.

※ You need to connect to the app before you can use it.



Tools

You can use: Prayer Timings, Prayer Beads, Wooden Fish, Timer, Alarm, Stopwatch, Flashlight.

※ Prayer timers, you need to connect to the app before you can use it.


Function introduction



Cycle Tracking

This function can view the physiological cycle of women

※ You need to connect to the app before you can use it.



World Clock

You can see the time you set in other cities you set in the app.

※ You need to connect to the app before you can use it.




Find Phone

After clicking the screen, you can find a mobile phone connecting this watch

※ You need to connect to the app before you can use it.

Function introduction



Game

There are several puzzle games on the watch.

※ You need to connect to the app before you can use it.



Calculator

You can use the calculator to do simple mathematical calculations.




Calendar

You can check the calendar of the whole month.

※ You need to connect to the app before you can use it.

Function introduction



Settings

Screen clock: You can choose the AOD dial and set the opening and closing time of the AOD function.

Tips: AOD, Always On Display.

Display: You can set the screen brightness, turn off screen time, dial, menu style, and the switch of the screen on the screen.

Vibrate & Ring: You can choose mute, vibration and ring, vibration, and the strength of vibration.

DND Mode: You can turn on/turn off the Do Not Disturb mode.

Low Power Mode: You can turn on/turn off the power saving mode.

Phone Call: You can turn on/turn off the call function, media audio and the phone call function reset.

System: You can restart, shut down, reset.

About: You can view device information, the QR code of the App downloaded

Notification introduction



Intake reminder

It can be turned on in the App [Intake Reminder].



Move reminder

It can be turned on in the App [Health-Reminders to Move].



Prayer reminder

It can be turned on in the App [Muslim].

※ You need to connect to the app before you can use it.

Common problem handling

Watch won't turn on

- Please press and hold the power button for more than 3 seconds.

- Maybe the battery is too low, please charge it in time.

Bluetooth is not connected or unable to connect

- Please try to restart the watch and reconnect.

- Please try to restart the phone's Bluetooth and connect again.

- Do not connect the phone to other Bluetooth devices at the same time.

Inaccurate heart rate/blood pressure/blood oxygen measurement

- Generally, it is caused by poor contact between the sensor of the watch and the human body during measurement.

- Please make sure that the sensor is in full contact with your wrist during measurement.

- Please keep your body still and the watch close to your wrist during measurement.

Precautions

Do not disassemble, repair, or modify the product without authorization.

Do not violently bump the product, so as not to cause damage to the product.

Please avoid strong magnetic field, direct light or high temperature environment.

This product is not used for disease diagnosis, treatment and prevention purposes.

The waterproof rating of this product is IP68, avoid prolonged immersion in water.

Please avoid wearing the watch strap too tightly and keep the place where the watch comes in contact with the skin clean.

Children please use this product under the guidance of their parents to avoid harm.



Warning: The smart watch should not be used for any medical purpose though it with dynamically monitor the heart rate at real time .

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



i28 Ultra