

## **H001 Massage underwear User Manual**

(Product name) : (Massage underwear)

(Product model) : H001

## 1. (Product overview)

This product is the electronic part Hongjie underwear Limited by Share Ltd intelligent massage underwear matching, the user can through the mobile phone application in Tencent Bao (Android version) or iTunes (IOS version) or search MORRIGAN or Hongjie health download, or through the product with charger two-dimensional code scanning can directly download the latest version of APP, this product by APP to set up your most comfortable massage, massage health care function to achieve.

## 2. (Product technical specification parameter)

(Technical project)	(Parameter standard)
(Battery voltage)	2.8V-4.2V
(Battery capacity)	120mAh
(Battery material)	(High temperature polymer lithium battery)
(Battery cut off voltage)	3.7V
(Maximum discharge current of battery)	220mA
(standby power)	53.96 $\mu$ A
(Standby time)	>30 day
(Maximum vibration standby time)	60min $\leq$ (standby time) $\leq$ 120min
(Charge distance)	3.0mm $\leq$ (Charge distance) $\leq$ 8.0mm
(Battery operating temperature)	$\leq$ 90 $^{\circ}$ C
(Charging mode)	USB (USB wire charging)
(Charge current range)	$\leq$ 500mA
(Charging time)	(Charging time) <3hour
(Charging line length)	1m $\leq$ (Charging line length) $\leq$ 1.2m
(Charging temperature)	$\leq$ 60 $^{\circ}$ C
(Charging line to bear the pulling force)	>100N
(Bluetooth line to bear the pulling force)	>45N
(Bluetooth connection distance)	$\leq$ 3M
(Keep on and on Bluetooth)	7M $\leq$ (Bluetooth connection distance)
(Silica gel environmental protection class)	(Food grade silica gel)

## 3. (Usage method and requirements)

### 1. (Use requirements)

(Must have a smart phone, and the phone system: Android 4.4 and above IOS and above 8.)

### 2. (Environmental requirements)

2.1 (Module temperature is not less than -10 $^{\circ}$ C, and not more than 60 $^{\circ}$ C)

2.2 (Module to hand wash, do not use washing machine)

### 3. (Usage method)

3.1Download and install APP for MORRIGAN or Hongjie health

3.2Registered account and Login APP.

---

3.3 Open the phone Bluetooth, search and connect module

3.4 Choice vibration mode

(Manner)		
(Manual mode)	(strong)	(Free choice of left and right)
	(Middle)	(Free choice of left and right)
	(weak)	(Free choice of left and right)
(Automatic mode)	(Gently soft)	(Left and right together)
	(wave)	(Left and right together)
	(weak)	(Left and right together)
	(Strong)	(Left and right together)
	(Dynamic)	(Left and right together)
(With the music shaking)	(According to the type of music)	(Left and right together)

#### 4. (Matters needing attention)

##### 4.1

Connect a minute later, the module will be bound with the phone, this time the module can not be tied to other mobile phone connection, you need to bind the phone after the remove binding can be restored

##### 4.2

Each access your account round requires a network

##### 4.3

If you can not search for the device, please check the phone Bluetooth is turned on, and the module is full of electricity after the test again, if you can search the device but can not be connected, then this device may be bound by others.

#### FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- 
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.  
The device can be used in portable exposure condition without restriction.